



Philips  
USB power bank

**20,000 mAh**  
3 USB charging ports  
QC 3.0 and PD 3.0  
PPS

**DLP7721C**



## Powerful power bank

with a portable back-up power pack

Large 20,000m Ah capacity with safe Li-polymer battery. No more hassle when your mobile phone is out of battery. Fast-charge your device with USB-C PD 3.0 Max 20 W or USB-A port with QC 3.0 Max 18 W output.

### Superior Charging Design

- 50% charge in 30 minutes
- Charging using USB-C Programmable Power Supply (PPS)
- Smart protection against overheating, overvoltage and overcurrent
- 3 USB ports charge three devices simultaneously
- USB-A with QC fast charging
- USB-C PD 20 W charging port

### Portable power

- Works anywhere - great when you're not near a power source

### Confirm operation at a glance

- LED power-indicator light

# PHILIPS

USB power bank  
20,000 mAh 3 USB charging ports, QC 3.0 and PD 3.0, PPS

# Specifications

## Compatibility

- Works with the following: USB-charged devices

## Power

- Output: USB-C Max 20W USB-A Max 18 W
- Power input: Type-C 5 V/3 A, MicroUSB 5 V/2 A
- Battery Capacity: 20,000 mAh 74 Wh

## Packaging dimensions

- Number of products included: 1
- Type of shelf placement: Both
- Packaging dimensions (W x H x D):  
9.5 x 17 x 3.5 cm
- Packaging dimensions (W x H x D):  
3.7 x 6.7 x 1.4 inch
- EAN: 48 95229 13553 6

## Outer Carton

- Number of consumer packages: 18
- Outer carton (L x W x H): 34 x 24 x 22.5 cm
- Outer carton (L x W x H): 13.4 x 9.4 x 8.9 inch
- GTIN: 1 48 95229 13553 3



## Inner Carton

- Number of consumer packages: 6
- Inner carton (L x W x H): 22 x 10.7 x 20.5 cm
- Inner carton (L x W x H): 8.7 x 4.2 x 8.1 inch
- GTIN: 2 48 95229 13553 0

## Accessories

- User Manual: User Manual
- Cables: USB-C charging cable

## Product dimensions

- Product dimensions (W x H x D):  
6.8 x 13.6 x 2.75 cm
- Product dimensions (W x H x D):  
2.7 x 5.4 x 1.1 inch
- Weight: 0.355 kg
- Weight: 0.783 lb

## Design and finishing

- Materials: PC + ABS

DLP7721C/00

# Highlights

## USB-C PD 20 W charging port.\

Equipped with USB-C (Power Delivery) PD 20 W fast charging port.

## USB-A with QC fast charging

Quick Charge (QC) fast-charging technology delivers faster charging by increasing voltage and current. It uses the Quick Charge protocol to optimise charging speeds for compatible devices, reducing charge times.

## 50% charge in 30 min

Fast charging - charge your mobile phone from 0 to 50% in 30 minutes time.

## Programmable Power Supply PPS

PPS (Programmable Power Supply) is a standard for fast charging technology for USB-C devices. This technology adjusts the voltage and current in real time, depending on a device's charging status, feeding it with maximum power. A smart way to safely reduce charging time.

## Smart Protection

Smart protection against overheating, overvoltage and overcurrent

## LED power-indicator light

The discreet LED light glows softly to let you know at a glance that the unit is charged.



Issue date 2023-10-11

Version: 3.3.2

12 NC: 8670 001 89995  
EAN: 48 95229 13553 6

© 2023 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)