

Philips
DVD home theater system



HTS6600



High performance surround sound

with Ambisound

Featuring Ambisound, the HTS6600 delivers an embracing multi-channel surround experience from just two speakers, in any sort of room. Providing excellent sound and picture quality, the easy-setup wall-mountable system fits into any home.

Bring audio and video to life

- Ambisound for surround sound from fewer speakers
- 1080i HDMI with high definition video upconversion
- Smart Surround optimizes surround settings automatically
- DoubleBASS for an extended, deep bass experience

Fits any space, any lifestyle

- Vertical speakers that can be wall-mounted with your Flat TV
- Sophisticated design that matches any flat TV
- Quick and easy set-up for no-fuss installation

Connect and enjoy multiple sources

- Connect your iPod for audio and video playback
- USB Direct plays photos and music from USB flash drives
- MP3 Line-in for music playback from Portable Media Players



asimpleswitch.com

PHILIPS

Highlights

Ambisound

Ambisound technology produces truly embracing multi-channel surround sound from fewer speakers. It delivers an immersive 5.1 sound experience without the constraints of sitting position, room shape or size, and without the clutter of multiple speakers and cables. Through the combined effect of psychoacoustic phenomena, array processing and precisely angled driver positioning, Ambisound delivers more sound from fewer speakers.

1080i HDMI

HDMI stands for High Definition Multimedia Interface. It is a direct digital connection that can carry digital HD video as well as digital multichannel audio. By eliminating the conversion to analog signals it delivers perfect

picture and sound quality, completely free from noise. HDMI is fully backward-compatible with DVI (Digital Video Interface).

Connect your iPod

This unique connection allows you to hook up the Philips dock to the home theater system for media playback from your iPod. With Extended User Interface, you can also enjoy the convenience of direct access and viewing of your iPod content on your TV screen.

USB Direct

Simply plug your device into the USB port on your Philips DVD system. Your digital music and photos will be played directly from the device. Now you can share your favorite moments with family and friends.

Smart Surround

Enjoy the best possible listening experience without having to make surround setting changes every time you change a disc or switch between movies and music. Unlike normal 5.1 systems that feature default multi-channel surround settings, Smart Surround automatically changes the surround settings to suit your music encoded in stereo or your movie with multi-channel content.

DoubleBASS

DoubleBASS ensures you hear even the deepest bass tones from compact-sized subwoofers. It captures low frequencies and recreates them in the audible range of the subwoofer - delivering sound with more boom and panache, and ensuring you a full, uncompromised listening experience.



Specifications

Picture/Display

- Picture enhancement: High Def (720p, 1080i), Video upscaling, Progressive scan

Sound

- Sound System: Ambisound, Dolby Digital, DTS, Dolby Prologic II, Stereo
- Sound Enhancement: Smart Surround, DoubleBass, Treble and Bass Control
- Equalizer settings: Action, Rock, Concert, Classic, Drama, Jazz, MTV, RnB, Gaming, Party, Cartoon, Lounge, Sports, News

Loudspeakers

- Loudspeaker types: 2x Vertical Speakers
- Speaker Drivers: 8 x 2" Full Range woofers
- Speaker impedance: 6 ohm
- Subwoofer type: Active
- Subwoofer driver: 1 x 6.5" Long Throw woofer
- Subwoofer impedance: 4 ohm
- Subwoofer freq range: 30-120 Hz

Video Playback

- Compression formats: DivX 3.11, DivX 4.x, DivX 5.x, DivX 6.0, DivX Ultra, MPEG1, MPEG2
- Playback Media: DVD-Video, DVD+R/+RW, DVD-R/-RW, Video CD/SVCD, CD-R/CD-RW
- Video disc playback system: NTSC, PAL

Audio Playback

- Compression format: MP3, WMA
- Playback Media: Audio CD, CD-R/RW, USB flash drive
- MP3 bit rates: 32-256 kbps and VBR

Still Picture Playback

- Picture Compression Format: JPEG
- Playback Media: CD-R/RW, DVD+R/+RW, USB flash drive
- Picture Enhancement: Slideshow with music playback, Rotate, Zoom

Tuner/Reception/Transmission

- Tuner Bands: AM, FM

Connectivity

- Front / Side connections: Dock connector, MP3 Line-in, USB
- Rear Connections: HDMI output, Component Video output, Composite video (CVBS) output, TV in (audio, cinch), Interconnect (to Power Box)
- Subwoofer (Power Box): Coaxial Digital input, AUX In (cinch, 2 pairs), FM Antenna, AM/MW Antenna, Easy Fit Speaker connectors, Interconnect (to Main Unit)

Dimensions

- Set dimensions with stand (W x H x D): 370 x 242 x 180 mm
- Set weight (with stand): 3.5 kg
- Speaker width (with stand): 180 mm
- Speaker height (with stand): 420.5 mm
- Speaker depth (with stand): 180 mm
- Speaker weight (with stand): 2.32 kg
- Subwoofer dimensions (W x H x D): 295 x 443 x 295 mm
- Subwoofer Weight: 9.1 kg
- Packaging dimensions (W x H x D): 841 x 359 x 527 mm
- Weight incl. Packaging: 22.5 kg

Accessories

- Included accessories: Quick start guide, User Manual, Dock for iPod, Remote Control, Batteries for remote control, HDMI cable, CVBS video cable, MP3 Line-in cable, AM antenna, FM antenna, Interconnect cable, Speaker Cables, Power cord, Wall mounting bracket, Product Registration Card

Power

- Power supply: 120V, 60Hz
- Standby power consumption: <1 W



Issue date 2014-02-06

Version: 3.0.12

12 NC: 8670 000 25313
UPC: 6 09585 12206 2

© 2014 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com