

Philips
DVD Micro Theater



MCD802

Complete cinema experience

with HDMI 1080p upscaling

Featuring HDMI 1080p and 2x200W RMS total output power, the Philips DVD Micro theater MCD802 elevates the cinematic experience right in your living room. Its one-touch MP3 recording function is handy for your music listening pleasure.

Enrich your movie experience

- Play DVD, DivX® Ultra, MP3/WMA-CD, CD and CD-RW
- HDMI 1080p upscales to high definition for sharper pictures
- Progressive Scan component video for optimized image quality
- Dolby Digital for ultimate movie experience

Enrich your sound experience

- 2x200W RMS / 6500W PMPO
- MAX Sound for instant power boost
- Digital Sound Control for optimized music style settings
- Dynamic Bass Boost for deep and dramatic sound

Continuous enjoyment of your favorite music

- One touch MP3 recording, no PC needed
- USB Direct for easy MP3 music playback
- MP3 Link for portable music playback
- Karaoke for endless singing entertainment at home

PHILIPS

sense and simplicity

Highlights

Dolby Digital

Because Dolby Digital, the world's leading digital multi-channel audio standards, make use of the way the human ear naturally processes sound, you experience superb quality surround sound audio with realistic spatial cues.

HDMI 1080p

HDMI 1080p upscaling delivers images that are crystal clear. Movies in standard definition can now be enjoyed in true high definition resolution - ensuring more details and more true-to-life pictures. Progressive Scan (represented by "p" in "1080p") eliminates the line structure prevalent on TV screens, again ensuring relentlessly sharp images. To top it

off, HDMI makes a direct digital connection that can carry uncompressed digital HD video as well as digital multichannel audio, without conversions to analog - delivering perfect picture and sound quality, completely free from noise.

MAX Sound

MAX Sound technology produces an instant boost in bass, maximizing volume performance and instantly creating the most impressive listening experience with just the touch of a button. Its sophisticated electronic circuitry calibrates existing sound and volume settings, instantly boosting bass and volume to maximum levels without distortion. The end result is a noticeable amplifying of both sound

spectrum and volume and a potent audio boost that will add mileage to any music.

MP3 Link

The MP3 link connectivity allows direct playback of MP3 content from portable media players. Besides the benefit of enjoying your favorite music in the superior sound quality delivered by the audio system, the MP3 link is also extremely convenient as all you have to do is to plug your portable MP3 player to the audio system.

One touch MP3 recording

One touch MP3 recording, no PC needed



Specifications

Sound

- Output Power: 2x200W RMS / 6500W PMPO
- Sound Enhancement: Digital Sound Control 4 modes, Dynamic Bass Boost, Loudness, MAX Sound
- Sound System: Dolby Digital, DTS, Stereo

Loudspeakers

- Main Speaker: Bass Reflex Speaker System, Speaker grilles detachable, 3 way, 5.25" woofer, Cone Dome Tweeter

Video Playback

- Playback Media: DivX, DVD+RW, DVD-Video, Picture CD, Video CD/SVCD, DivX Ultra
- Disc Playback Modes: A-B Repeat, Angle, PBC, Slow Motion, Zoom, Parental control, Dynamic Range Compression
- DVD Region.: 3
- Video Enhancement: Progressive Scan
- USB Direct Playback: JPEG

Audio Playback

- Playback Media: WMA-CD, MP3-CD, CD, CD-R, CD-RW, USB flash drive
- Disc Playback Modes: 20-Track Programmable, Repeat/one/all/program, Shuffle Play
- Loader Type: Motorised, Tray
- USB Direct Modes: Fast Backward/Fast Forward, Play/Pause, Previous/Next, Repeat, Shuffle, Stop

Audio Recording

- Audio file format: MP3
- Bit rate: 64k - 320k
- Recording Media: USB device
- Recording speed: 3X
- USB recording sources: CD

Tuner/Reception/Transmission

- Tuner Bands: FM Stereo
- Auto digital tuning
- Station presets: 40

Connectivity

- Video Output - Analog: Component Y Pb Pr (cinch), Composite CVBS (yellow cinch), S-Video (on Hosiden), SCART
- Aux in: 2x(L/R)/ RCA
- Other connections: FM Antenna, Line out, Digital audio out, HDMI out
- Headphone: 3.5 mm
- Microphone: Microphone socket
- USB: USB host

Convenience

- Alarms: CD Alarm, Sleep timer
- Clock: On main display
- OSD Languages: English, Traditional Chinese
- Display Type: VFD display
- Indications: DIM mode
- Eco Power Standby: 1 watt

Accessories

- Included accessories: Composite video cable (Y), Control cable, FM antenna, AC Power Cord
- Remote control: 49-key with 2xAAA batteries

Dimensions

- Set dimensions (W x H x D): 270 x 190 x 323 mm
- Main speaker dimensions (W x H x D): 189 x 406 x 340 mm
- Packaging dimensions (W x H x D): 730 x 486 x 397 mm
- Weight incl. Packaging: 19.2 kg

Power

- Power supply: 100-240VAC, 50/60Hz



Issue date 2011-07-21

Version: 2.0.4

12 NC: 8670 000 49294
EAN: 87 12581 46219 2

© 2011 Koninklijke Philips Electronics N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

www.philips.com

* Music with Digital Right Management not supported.