

PHILIPS

Micro music system

CD, MP3-CD, USB, FM

USB port for charging

15 W max

MCM2300



Relax to great music

Obsessed with sound

Listen to your favourites on this compact, all-in-one Philips music system equipped with USB, Audio in and CD playback. Enjoy powerful music with Bass Reflex speakers and Digital Sound Controls for optimised sound settings.

Easy to use

- Digital tuning with preset stations for extra convenience
- Motorised CD loader for convenient access

Enrich your sound experience

- Bass Reflex Speaker System delivers a powerful, deeper bass
- 15 W maximum output power
- Digital Sound Control

Enjoy your music from multiple sources

- Play MP3-CD, CD and CD-R/RW
- Audio-in for portable music playback
- USB Direct for easy MP3 music playback

Highlights

Bass Reflex Speaker System



Bass Reflex Speaker System delivers a deep bass experience from a compact loudspeaker box system. It differs from a conventional loudspeaker box system in the addition of a bass pipe that is acoustically aligned to the woofer to optimise the low frequency roll-off of the system. The result is deeper controlled bass and lower distortion. The system works by causing the air mass in the bass pipe to vibrate like a conventional woofer. Combined with the response of the woofer, the system extends the overall low frequency sounds to create a completely new dimension of deep bass.

Audio-in



The Audio-in connectivity allows direct playback of Audio-in content from portable media players. Besides the benefit of enjoying your



favourite music in the superior sound quality delivered by the audio system, the Audio in is also extremely convenient as all you have to do is to plug your portable MP3 player into the audio system.

USB Direct for easy MP3 music



Thanks to the complete file transferability, you can easily enjoy the convenience and fun of accessing more digital music via the built-in USB Direct.

Digital Sound Control

Digital Sound Control offers you a choice of pre-set balanced, clear, powerful, warm and bright controls you can use to optimise the frequency ranges for different musical styles. Each mode uses graphic equalising technology to automatically adjust the sound balance and enhance the most important sound frequencies in your chosen music style. Ultimately, Digital Sound Control makes it easy for you get the most out of your music by precisely adjusting the sound balance to match the type of music you are playing.

Specifications

Sound

Sound enhancement: digital sound control
Maximum output power (RMS): 15 W

Loudspeakers

Speaker drivers: 3" woofer
Speaker types: bass reflex speaker system

Connectivity

USB: USB host
Audio in (3.5 mm)

Audio playback

Disc playback modes: fast forward/reverse, next/previous track search, repeat/shuffle/programme
Playback media: CD, CD-R/RW, MP3-CD, USB flash drive
USB Direct playback modes: fast reverse/fast forward, play/pause, previous/next, repeat, shuffle, stop

Tuner/Reception/Transmission

Antenna: FM fixed pigtail antenna
Tuner bands: FM mono, FM stereo
Station presets: 20
Tuner enhancement: auto digital tuning, auto scan

Convenience

Alarms: CD Alarm, Radio Alarm, USB alarm
Clock: On main display, sleep timer
Loader type: tray
Display type: LED display

Power

Power supply: 100-240 VAC, 50/60 Hz

Accessories

Included accessories: AC Power Cord, FM antenna, User Manual
Remote control: 21-key remote

Dimensions

Gross weight: 4.67 kg
Net weight: 3.55 kg
Main speaker depth: 125 mm
Main speaker width: 150 mm
Main unit depth: 247 mm
Main unit height: 121 mm
Main unit width: 180 mm
Packaging height: 312 mm
Packaging width: 577 mm
Packaging depth: 185 mm
Main speaker height: 238 mm

