

Soundbar 2.1 with wireless subwoofer

- 2.1 CH wireless subwoofer
- HDMI ARC
- Dolby Audio
- 140W

TAB6305/98



Ultra slim. Big on sound.

Got a TV that sits on a low stand? This ultra-slim soundbar is low enough to sit under almost any TV and comes with a wireless subwoofer. You get sound that's big enough to bring your favorite shows, movies, and music to life.

Benefits

Ultra-low profile. Richer, deeper, clearer sound.

- 2.1 channels. Wireless subwoofer for deeper bass
- Ultra-slim design. Fits under almost any TV
- Dolby Audio. Be in the heart of the action
- Robust metal grille for clear sound

Music and movies

- HDMI ARC. Control the soundbar with your TV remote
- Connect your favorite sources for bigger sound
- Audio-in. Optical in. Bluetooth

- IR repeater included, with pass-through cable

[See it. Hear it. Love it.](#)

- Integrated wall brackets
- Place on your TV table, the wall, or any flat surface
- Soundbar dimensions: 650x35x81 mm
- Subwoofer dimensions: 120x402x300 mm

Features

2.1 channels

The thunder of explosions. The roar of a crowd. 2.1 channels bring richer, deeper, clearer sound to your favorite movies and shows. The compact wireless subwoofer delivers rich bass.

Ultra-slim design

This soundbar has a profile of just 35 mm, making it perfect for TVs with lower stands. When it comes to placement, the integrated wall brackets keep your options open. The compact design of the powerful subwoofer makes it easy to conceal.

PHILIPS

Dolby Audio

Be immersed in your favorite shows and movies. This soundbar with wireless subwoofer supports the Dolby Digital format for a more expansive and involving experience. Voices will be clearer. Effects will be more impressive.

HDMI ARC

This soundbar connects to your TV via HDMI ARC, allowing you to control soundbar volume with the same remote you use for your TV. The included IR

repeater lets you use your TV remote even if you place the soundbar in front of the TV's IR sensor.

Connect your favorite source

Stream playlists from your mobile device via Bluetooth. Connect audio sources via audio-in, optical input, or USB. Whatever you love, it will sound great through this soundbar.

Specifications

[field not found 'disclaimer_text']

Sound

Speaker system output power	288W max / 140W RMS (10 % THD)
Total harmonic distortion	10%

Loudspeakers

Number of sound channels	2.1
Front drivers	2 middle range (L+R) 2 tweeters (L+R)
Soundbar freq range	180 - 20k Hz
Soundbar impedance	2x 8 ohm
Subwoofer type	Active Wireless subwoofer
External subwoofer enclosure	Bass reflex
Subwoofer driver	1 x 5.25" woofer
Subwoofer freq range	40 - 180 Hz
Subwoofer impedance	4 ohm

Connectivity

Bluetooth	Receiver
Bluetooth version	4.2
Bluetooth profiles	A2DP AVRCP
Optical input x 1	Yes
HDMI Out (ARC) x 1	Yes
EasyLink (HDMI-CEC)	Yes
USB playback	Yes
Audio in	1x 3.5mm
IR port	IR out 2.5mm jack
Wireless speaker connection	Subwoofer
Subwoofer out	No
Smart Home	None
DLNA Standard	No
Multiple speaker connection	No

Compatibility

Smartphone/tablet APP control	No
-------------------------------	----

Convenience

EasyLink (HDMI-CEC)	Audio Return Channel Automatic audio input mapping One touch standby Remote Control-Passthrough
Night mode	No
Remote Control	Yes

Design

Wall mountable	Yes
Color	Dark grey

Power

Main unit power consumption	18 W
-----------------------------	------

Main unit power supply	100-240V AC, 50/60 Hz
Main unit standby power	< 0.5 W
Subwoofer power consumption	20 W
Subwoofer power supply	100-240V AC, 50/60 Hz
Subwoofer standby power	< 0.5 W
Auto standby	Yes

Accessories

Included accessories	Power cord Remote Control 2 x AAA Batteries Wall mount bracket Power adapter Quick start guide Warranty Card
IR repeater	Yes, with pass-through cable and bracket

Supported Audio Formats

HDMI ARC	Dolby Digital LPCM 2ch
Optical	Dolby Digital LPCM 2ch
Bluetooth	SBC
USB	MP3 WAV FLAC

Video

3D pass-through	No
-----------------	----

Dimensions

Main Unit (W x H x D)	650 x 35 x 81 mm
Main Unit Weight	1 kg
Subwoofer (W x H x D)	120 x 402 x 300 mm
Subwoofer Weight	4.8 kg

Packaging dimensions

EAN	48 95229 10988 9
Height	42.5 cm
Width	73.5 cm
Depth	14.5 cm
Gross weight	8 kg
Nett weight	5.9 kg
Tare weight	2.1 kg
Packaging type	Carton
Type of shelf placement	Laying
Number of products included	1

Outer Carton

GTIN	1 48 95229 10988 6
Number of consumer packagings	2

Length	75.5 cm	Tare weight	5.2 kg
Width	31.5 cm	Nett weight	11.8 kg
Height	45.5 cm		
Gross weight	17 kg		



data subject to change
2023, June 20

Version: 7.0.2
EAN: 4895229109889

© 2023 Koninklijke Philips N.V.
All rights reserved.

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

www.philips.com