



Philips  
docking entertainment  
system

Dock for iPod and GoGear  
dual alarms



AJ300D

## Play and charge your iPod

wOOx technology for powerful bass

Free your portable music at home! Dock your iPod or GoGear player into the compact AJ300D Docking Entertainment System with powerful bass supported by 12W RMS power. Enjoy great sounds and choose to kick-start each day with music.

### Rich and clear sound

- Play and charge your iPod and GoGear
- wOOx™ loudspeaker Technology for deep and powerful bass
- Aux-in connection for your portable MP3 music player

### Start the day your way

- Wake up to your iPod or GoGear music
- Dual alarm time
- Digital tuning for station presets

### Easy to use

- 5 one touch buttons for easy access to favorite radio tunes
- Single remote control for the system and iPod

**PHILIPS**

Docking entertainment system  
Dock for iPod and GoGear dual alarms

AJ300D/05

# Specifications

## iPod compatibility

- Compatible with: iPod, iPod mini, iPod nano, iPod with color display, iPod 5th Generation

## GoGear compatibility

- Compatible with: HDD6330/ HDD6320/ HDD1850/ HDD1840/ HDD1835/ HDD1830/ HDD1820/ HDD1635/ HDD1630/ HDD1620/ HDD1420/ SA9100/ SA9200

## Tuner/Reception/Transmission

- Tuner Bands: FM
- Auto digital tuning
- Station presets: 5
- Antenna: FM Antenna

## Audio Playback

- Cradle playback mode: Charging iPod, Charging GoGear, Play and Pause, Next and Previous track, Fast forward and backward

## Convenience

- Clock/Version: Digital
- Alarms: 24 hour alarm reset, Dual alarm time, Buzzer Alarm, Radio Alarm, Repeat alarm (snooze), Sleep timer
- Display Type: LCD

- Backlight
- Backlight color: Blue

## Sound

- Output power (RMS): 2 x 6W
- Sound System: Stereo
- Volume Control: Volume Control up/down

## Loudspeakers

- Built-in speakers: 5
- Loudspeaker Enhancement: wOOx Bass Radiator
- Neodymium magnet system

## Connectivity

- Aux in: Line-in, 3.5 mm

## Power

- Mains power
- Adaptor type: 100-240V 50/60Hz

## Dimensions

- Product dimensions (W x H x D): 161 x 191 x 164 mm
- Weight: 1.34 kg
- Packaging dimensions (W x H x D): 248 x 224 x 212 mm
- Weight incl. Packaging: 1.94 kg

# Highlights

## wOOx™ Technology

wOOx technology is a revolutionary loudspeaker concept that allows you to hear and feel profoundly deep bass that is richer than any other audio system. Special speaker drivers work in harmony with the wOOx bass radiator, and precise tuning between the main driver and the tweeter ensures smooth transitions from low-mid to high frequencies. Dual suspension and a totally symmetrical sandwich construction deliver low and precise base without noticeable distortion. wOOx produces exceptionally deep and dynamic bass by using the speaker box full volume to truly magnify the impact of the music.

## Aux-in connection

Aux-in connection for your portable MP3 music player

## Wake up to iPod/GoGear music

Wake up to your iPod or GoGear music

## Digital tuning for presets

Digital tuning for station presets

## 5 one-touch radio presets

Access your favorite stations with simple one touch operation



Issue date 2014-02-12

Version: 2.1.9

12 NC: 8670 000 29384  
EAN: 87 12581 33142 9

© 2014 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)