



### Philips Portable Radio

FM/MW, Analogue tuning  
Micro USB port for charging  
Flashlight  
Self-powered/ Battery operated



AE1120

## Perfect companion for outdoor activities

with this portable radio

The Philips AE1120/00 portable radio is built for the outdoors. Kinetically powered, it eliminates the need for batteries and features a built-in siren for attracting attention and USB charger to keep devices charged and connected.

#### Perfect for outdoor activities

- Kinetic power generation for effortless charging
- Integrated flashlight for illuminating nighttime activity
- Built in siren to keep you safe
- Built-in micro USB cable for recharging any USB-device

#### Pocket-size radio

- FM/MW tuner for radio enjoyment
- Built-in speaker to enjoy radio out-loud in good sound

# PHILIPS

# Specifications

## Tuner/Reception/Transmission

- Tuner bands: FM, MW
- Antenna: Rod

## Sound

- Volume control: rotary (analogue)
- Output power: 300 mW RMS

## Loudspeakers

- No. of built-in speakers: 1

## Connectivity

- Micro USB: for DC charging
- Micro USB cable: for charging mobile phones

## Convenience

- Kinetic power
- Flashlight
- Siren

## Power

- Battery voltage: 1.5 V
- Number of batteries: 3
- Battery type: AAA
- DC input voltage: 5 V

## Accessories

- Warranty: Warranty Certificate
- Others: Quick start guide, User Manual

## Dimensions

- Product dimensions (WxDxH): 120 x 47 x 76 mm
- Packaging dimensions (WxDxH): 130 x 59 x 84 mm
- Product weight: 0.26 kg
- Weight incl. Packaging: 0.32 kg

AE1120/00

# Highlights

## Kinetic power generation



Harness your own power with the device's innovative, kinetically driven power source - an environmentally friendly alternative to battery-powered devices. Providing power for radio, flashlight or to charge up a phone or other device is an easy-to-use way to keep charged up.

## Integrated flashlight



Don't be kept in the dark. With its built-in flashlight, the device keeps things going long after the sun has set. This device takes the risk out of poorly-lit nighttime activities and can be just the thing in the event of power outages. Kinetic power generation keeps things automatically charged and eliminates worries about batteries going flat.

## Built in siren



Keeping safe often means being locatable. The device's built-in siren attracts attention, meaning that help is never far away. Kinetically powered to prevent unexpected battery problems, the siren is an addition designed to give you peace of mind and make your safety a top priority.

## Built-in micro USB cable

It's difficult to unplug entirely - and now you don't have to. Finding a charger for a mobile phone or other device in the outdoors can be a hassle, which is why the device has a handy micro-USB built in, meaning you'll always have enough power for music and movies, or just for your peace of mind. It's also great to act as a backup in the case of power outages. Take advantage of the device's kinetically-charged power source to keep powered up and connected.



Issue date 2014-06-24

Version: 4.0.9

12 NC: 8670 000 90672  
EAN: 08 71258 16464 31

© 2014 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)