

Philips  
MP3/WMA Mini Hi-Fi  
System

FWM575



## Enjoy digital music via USB Direct playback

Fulfill all your music needs with this MP3/WMA Mini Hi-Fi System. Enjoy your digit music in a high power system via the USB Direct plus savor 60 hours of your favorite MP3/WMA-CD music. Intuitive ease-of-use make this set a joy to use!

### **Powerful sound you can hear and feel**

- 360 watts total system power
- 3-way Speaker System with MAX bass port

### **Longer listening, greater enjoyment**

- Enjoy MP3/WMA music directly from your portable USB drives
- 3-disc changer for convenient multi-disc playback
- 60 hours of WMA-CD or 30 hours of MP3-CD music playback
- Dual Logic Tape Deck with auto replay

### **Personalized sound settings**

- MAX Sound for instant power boost
- 3-step Dynamic Bass Boost for deep bass experience
- Incredible Surround™ for enhanced audio enjoyment
- Virtual Ambience Control provides simulated sound settings

# PHILIPS

# Highlights

## 360 watts total system power

360 watts total system power

## 3-way spk sys with MAX port

3-way Speaker System with MAX bass port

## USB Direct for MP3/WMA music

Simply plug in your device to the USB port on your Philips Hi-Fi system. Your digital music will be played directly from the device. Now you can share your favorite moments with family and friends.

## 3-disc changer

With a three-disc changer for music playback, you can choose between three different CDs inside the device at any one time. This convenient feature allows you to savor a variety of music while saving you precious time from changing CDs frequently.

## 60 hours of WMA-MP3-CD music

60 hours of WMA-CD or 30 hours of MP3-CD music playback

## Dual Logic Tape Deck

Dual Logic Tape Deck with auto replay

## MAX Sound

MAX Sound technology produces an instant boost in bass, maximizing volume performance and instantly creating the most impressive listening experience with just the touch of a button. Its sophisticated electronic circuitry calibrates existing sound and volume settings, instantly boosting bass and volume to maximum levels without distortion. The end result is a noticeable amplifying of both sound spectrum and volume and a potent audio boost that will add mileage to any music.

## 3-step Dynamic Bass Boost

Dynamic Bass Boost maximizes your music enjoyment by emphasizing the bass content of the music throughout the range of volume settings - from level one to level three - at the touch of a button! You can customize the bass level that fits your style. Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.

## Incredible Surround™

Incredible Surround is an audio technology from Philips that dramatically magnifies the sound field to immerse you in the audio. Using state-of-the-art electronic phase shifting, Incredible Surround mixes sounds from left and right in such a way that it expands the virtual distance between the two speakers. This wider spread greatly enhances the stereo effect and creates a more natural sound dimension. Incredible Surround allows you to experience total surround with greater depth and width of sound, without the use of additional speakers.

## Virtual Ambience Control

Virtual Ambience Control (VAC) creates a virtual sound environment which digitally mimics the acoustic characteristic of special rooms or environments such as concert halls, the cinema, arcades, discos, etc. By realistically recreating the sound ambience of these different settings, VAC will dramatically enhance your enjoyment of your favorite music.



# Specifications

## Sound

- Output Power: 360W total system power
- Sound Enhancement: MAX Sound, Incredible Surround, Dynamic Bass Boost 3 steps, Digital Sound Control 4 modes, Virtual Ambience Control

## Loudspeakers

- Main Speaker: 6.5" woofer, 2" tweeter, Piezo, 3 way, Bass Reflex Speaker System
- Number of Loudspeakers: 2

## Audio Playback

- Loader Type: 3 CD Carousel
- Number of Discs: 3
- Playback Media: CD, CD-R, CD-RW, MP3-CD, WMA-CD
- Disc Playback Modes: 99-Track Programmable, Repeat/one/disk/program, Shuffle Play
- ID3-tag support
- Compression format: MP3, WMA
- USB Direct Modes: Play/Pause, Previous/Next, Fast Backward/Fast Forward, Stop, Repeat, Shuffle, Program Play
- Cassette Deck Technology: Full Logical
- Number of decks: 2

## Audio Recording

- Tape Recording Enhancement: Automatic Recording Level, CD Synchro Start Recording

## Tuner/Reception/Transmission

- Auto digital tuning
- Station presets: 40

- Tuner Bands: FM, AM
- Tuner Enhancements: Auto Store, Easy Set (Plug & Play)

## Connectivity

- USB: USB host
- Aux in: Line in
- Headphone: 3.5 mm
- Other connections: FM Antenna, AM Antenna

## Convenience

- Alarms: CD Alarm, Radio Alarm, Sleep timer
- Clock: On main display
- Display Type: FTD
- Indications: DIM mode

## Accessories

- Included accessories: AC Power Cord, Quick Use Guide, Guarantee booklet, AM antenna, FM antenna
- Remote control: 32-key with 2xAA Batteries
- User Manual: English/ Spanish/ B-Portugese

## Dimensions

- Set dimensions (W x H x D): 265 x 310 x 395 mm
- Main speaker dimensions (W x H x D): 248 x 310 x 195 mm
- Packaging dimensions (W x H x D): 611 x 411 x 440 mm
- Weight incl. Packaging: 16.1 kg

## Power

- Power supply: 110-240V, 50/60 Hz



Issue date 2014-02-05

Version: 3.0.5

12 NC: 8670 000 26365  
EAN: 87 12581 30835 3

© 2014 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)