Clock Radio AJ3600

Wake Up and Beam!

with Time Projection

Because everyday is unique for you, the friendly AJ3600 makes a special morning companion. Its Time Projection feature beams the time on any surface - just wake up, open your eyes and you'll see the time! Good mornings just got better!

Breezy, easy mornings start with time projection

- · Project the time in any direction you wish
- · Rotate and reverse the projected image
- · Backlit LCD for better viewing of time

Wake to your favourite tune

• Digital tuning with 15 presets

Start the day your way

- Gentle Wake (increasing alarm volume)
- Sleep Timer
- · Repeat alarm













AJ3600/00C/05/14/17/01

Technical specifications

Sound

- Output power (RMS): 80mW
- · Sound system: Mono
- · Volume control: Rotary

Loudspeakers

• Main speaker: 1 x 64mm (2.5")

Tuner / Reception

- Tuning technology: Anologue
- Turner bands: FM MW

Convenience

· Alarm:

Dual

Radio/buzzer alarm

 Alarm enhancements: Alarm Time Display Sleep Timer Gentle Wake
 24 hour alarm reset

Repeat alarm
Time/alarm set

- · Clock: Quartz-operated clock setting
- Display: 4-Digit LCD
- Display enhancements: Brightness control
- · Backlight: Amber

Power

- · AC/DC operation
- · Battery type:

 3×1.5 V, AA/R6/LM-3 cell (not included)

Dimensions

- · Packaging type: D-box
- Product dimensions (WxHxD): 85 x 106 x 118 mm
- Product weight (kg): 0.5 kg
- Package dimensions (WxHxD): 100 x 158 x 222 mm

Product highlights

Time Projection

Time Projection lets you project the time on any surface at any angle. The innovative projection system ensures that the time will always be positioned and orientated correctly. Unlike conventional LCD displays, the negative LCD display allows light to pass through without significant distortion. A powerful LED luminously lights up the negative LCD to project the light within a certain distance. With its accurate lens, the clock projects the image and even adjusts the focus to your satisfaction. No need to get up and check the time - just open your eyes!

Alarm Time Display

Alarm Time Display always shows both the current time and the time that your alarm is set to go off. The constant display eliminates the need to press a button in order to check whether the alarm has been set and at what time it will go off. Alarm Time Display constantly reassures you that your alarm is set correctly and that it will wake you up at the intended time.

Sleep Timer

Sleep Timer lets you decide how long you want to listen to music or a radio station of your choice before falling asleep. Simply set a time limit (up to 1 hour) and choose a CD or radio station to listen to while you drift off to sleep. The set will continue to play for the selected duration and then automatically switch off to a power-efficient, silent stand-by mode. Sleep Timer lets you fall asleep to your favorite CD or radio DJ without counting sheep or worrying about wasting power.

Wake-Up Timer

Wake-Up Timer is an alarm clock feature on your audio set that lets you set the alarm function of the built-in digital clock to activate the tape, CD or radio to wake you up at any time you want. With Wake-Up Timer you can wake up to your favorite music or radio station every day.

