

Philips
MP3 Mini Hi-Fi System



FWM986

Rip and play music instantly

with USB Rip-All

Fulfill all your music needs with FW986 MP3 Mini Hi-Fi System, which delivers 1200Wrms total power. Plus the freedom to savor 30 hours of your favorite MP3-CD music and intuitive ease-of-use make this set a joy to use!

Powerful sound you can hear and feel

- 3-way Speaker System with MAX bass port
- 1200W RMS total output power
- Dual subwoofers for superb deep bass

Longer listening, greater enjoyment

- 3-disc changer for convenient multi-disc playback
- Digital tuning with 40 preset stations for extra convenience
- 60 hours of WMA-CD or 30 hours of MP3-CD music playback
- Rip music from CDs, radio and karaoke onto a USB device

Personalized sound settings

- 3-step Dynamic Bass Boost for deep bass experience
- Digital Sound Control for optimized music style settings
- Incredible Surround™ for enhanced audio enjoyment
- MAX Sound for instant power boost

PHILIPS

Highlights

3-disc changer

With a three-disc changer for music playback, you can choose between three different CDs inside the device at any one time. This convenient feature allows you to savor a variety of music while saving you precious time from changing CDs frequently.

40-preset digital tuning

Digital radio offers you additional music options to your music collection on your Philips audio system. Simply tune into the station that you want to preset, press and hold the preset button to memorize the frequency. With preset radio stations that can be stored, you can quickly access your favorite radio station without having to manually tune the frequencies each time.

3-step Dynamic Bass Boost

Dynamic Bass Boost maximizes your music enjoyment by emphasizing the bass content of the music throughout the range of volume settings - from level one to level three – at the touch of a button! You can customize the bass level that fits your style. Bottom-end bass frequencies usually get lost when the volume is

set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.

Digital Sound Control

Digital Sound Control offers you a choice of pre-set Jazz, Rock, Pop and Classic controls you can use to optimise the frequency ranges for different musical styles. Each mode uses graphic equalizing technology to automatically adjust the sound balance and enhance the most important sound frequencies in your chosen music style. Ultimately, Digital Sound Control makes it easy for you get the most out of your music by precisely adjusting the sound balance to match the type of music you are playing.

3-way spk sys with MAX port

3-way Speaker System with MAX bass port

Incredible Surround™

Incredible Surround is an audio technology from Philips that dramatically magnifies the sound field to immerse you in the audio. Using state-of-the-art electronic phase shifting, Incredible Surround mixes sounds from left

and right in such a way that it expands the virtual distance between the two speakers. This wider spread greatly enhances the stereo effect and creates a more natural sound dimension. Incredible Surround allows you to experience total surround with greater depth and width of sound, without the use of additional speakers.

MAX Sound

MAX Sound technology produces an instant boost in bass, maximizing volume performance and instantly creating the most impressive listening experience with just the touch of a button. Its sophisticated electronic circuitry calibrates existing sound and volume settings, instantly boosting bass and volume to maximum levels without distortion. The end result is a noticeable amplifying of both sound spectrum and volume and a potent audio boost that will add mileage to any music.

60 hours of WMA-MP3-CD music

60 hours of WMA-CD or 30 hours of MP3-CD music playback



Specifications

Sound

- Output Power: 12000W PMPO
- Total Sound Power (RMS): 1200 W
- Sound Enhancement: MAX Sound, Dynamic Bass Boost 3 steps, Incredible Surround, Digital Sound Control 4 modes, Virtual Ambience Control

Loudspeakers

- Main Speaker: 2 x 6.5" woofer, 2x2" tweeters, 3 way, Bass Reflex Speaker System
- Subwoofer type: Passive
- Subwoofer driver: 10" woofer
- Number of Loudspeakers: 6

Audio Playback

- Loader Type: 3 CD Carousel
- Number of Discs: 3
- Playback Media: CD, CD-R, CD-RW, MP3-CD, WMA-CD
- Disc Playback Modes: 40-Track Programmable, Repeat/one/disk/program, Shuffle Play
- USB Direct Modes: Play/Pause, Stop, Previous/Next, Fast Backward/Fast Forward, Repeat, Shuffle, Delete

Audio Recording

- Recording Media: USB device
- USB recording modes: Instant record, Single track, Single disc, Programmed tracks, Schedule radio program
- USB recording sources: CD, Tuner, Aux, Microphone in

Tuner/Reception/Transmission

- Auto digital tuning
- Station presets: 40
- Tuner Bands: FM, MW
- Tuner Enhancements: Auto Store, Easy Set (Plug &

Play)

Connectivity

- Audio Connections: RCA Aux in
- USB: USB host
- Microphone: Dual Microphone sockets
- Headphone: 3.5 mm
- Other connections: FM Antenna, MW Antenna

Convenience

- Alarms: CD Alarm, Radio Alarm, USB alarm, Sleep timer
- Clock: On main display
- Display Type: FTD
- Indications: DIM mode
- Karaoke: MIC volume, Echo control

Accessories

- Remote control: 36-key with 2xAAA batteries
- User Manual: Spanish, B-Portuguese
- Guarantee booklet: Global version
- Included accessories: AC Power Cord, FM/MW Antenna, Batteries for remote control, *Flat pin adaptor, Microphone
- Quick start guide: Spanish, B-Portuguese

Dimensions

- Set dimensions (W x H x D): 269 x 311 x 412 mm
- Main speaker dimensions (W x H x D): 235 x 457 x 260 mm
- Subwoofer dimensions (W x H x D): 303 x 455 x 357 mm
- Surround Speaker dimensions (W x H x D): 140 x 311 x 250 mm
- Weight incl. Packaging: 51.5 kg

Power

- Power supply: 100-240VAC, 50/60Hz



Issue date 2014-02-05

Version: 5.0.12

12 NC: 8670 000 32609
EAN: 87 12581 35350 6

© 2014 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com

* Avoid extensive use of the set in a volume higher than 85 decibel because this may damage your hearing.