

Philips  
Neckband Headphones



SHJ055



## More bass, less tangling

Extra large speakers provide you deep bass

These Nike Sport Duro headphones provide the ultimate bass with extra large speakers and unobtrusive rear- exit cable arrangement so you can focus on your activities.

Swiveling earshells and further comfort.

### Innovation for Athletes

- 30mm speaker driver delivers big sound performance
- Lightweight design improves comfort for prolonged use.
- for comfortable wearing, great sound, and style
- Neodymium magnet enhances bass performance and sensitivity
- Rear cable exit enhances comfort and convenience
- for use in active sports
- A 1.2m long cable that is ideal for outdoor use
- improves wearing comfort by automatic adjustment

**PHILIPS**  
sense and simplicity

## Specifications

### Packaging dimensions

- EAN: 87 12581 35483 1
- Number of products included: 1
- Packaging type: Blister
- Packaging dimensions (W x H x D): 17 x 17 x 6 cm
- Nett weight: 0.046 kg
- Gross weight: 0.134 kg
- Tare weight: 0.088 kg

### Outer Carton

- EAN: 87 12581 35484 8

- Number of consumer packagings: 12
- Outer carton (L x W x H): 39.4 x 39.4 x 21.6 cm
- Nett weight: 0.552 kg
- Gross weight: 3.2 kg
- Tare weight: 2.648 kg

### Sound

- Magnet type: Neodymium
- Frequency response: 10 - 24 000 Hz
- Impedance: 32 ohm
- Maximum power input: 100 mW
- Sensitivity: 106 dB

## Highlights

### 30 mm speaker driver

Compact for wearing comfort yet big enough to deliver crisp, powerful sound, the 30 mm speaker driver is a perfect size for non-distorted listening enjoyment.

### Lightweight design

The durable, lightweight quality materials enhance comfort for extended wearing.

### Rear cable exit

The headphone cable is centered at the back of the neckband so you're hardly aware it's even there.

### 1.2m cable

The ideal cable length to give you the freedom to put your audio device where you want.



Issue date 2010-12-03

Version: 1.0.12

12 NC: 8670 000 32758  
EAN: 87 12581 35483 1

© 2010 Koninklijke Philips Electronics N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips  
Electronics N.V. or their respective owners.

[www.philips.com](http://www.philips.com)