

Philips Portable CD Player

AX2420



Jogproof

with FM radio headphones

The irresistibly classic AX2420 CD player with LCD display lets you savor smooth, skip-free music. Its stylish round form will appeal to all music lovers and it also comes with FM radio headphones for a super music experience on the go

Jogproof

• 45-second ESP™

Enjoy your FM music wherever you go

• FM radio headphone for use with any portable audio player

Enhanced bass performance

• Dynamic Bass Boost for deep and dramatic sound

Enjoy all kinds of discs

• Play CD, CD-R and CD-RW discs



Specifications

Sound

- D/A converter: 1-bit
- Frequency response: 20 20 000 Hz
- Signal to noise ratio: > 82dB
- Sound Enhancement: Dynamic Bass Boost
- Output Power: 2 x 4mW RMS
- Volume Control: digital
- Acoustic Feedback

Audio Playback

- Playback Media: CD, CD-R, CD-RW
- Disc Playback Modes: 30-Track Programmable, Fast Forward/Backward, Hold, Repeat Play, Resume Playback from stop, Shuffle Play, Scan
- Electronic Skip Protection(CD): 45

Tuner/Reception/Transmission

- · Tuner Bands: FM
- Frequency range: 87.5 108 MHz

Connectivity

- DC in: 4.0 mm, 4.5V, centre +
- · Headphone: 3.5 mm
- Line-out: 3,5 mm





Convenience

- Display Type: LCD
- Indications: battery status, Cd functions, DBB, ESP, time, track

Accessories

- · Headphones: AE500 FM radio headphones
- Included accessories: User Manual

Dimensions

- Master carton dimensions: $195 \times 345 \times 244$ mm
- Master carton weight: 1.6 kg
- Master carton quantity: 3
- Packaging dimensions (W x H x D): 204 x 305 x 70 mm
- Packaging type: Clamshell
- Product dimensions (WxDxH): 140x140x27.5mm
- Product weight: 0.2 kg

Power

- Battery Playing Time CD: 20
- Battery type: AA, LR6, UM3

Highlights

45-second ESP™

Electronic Skip Protection is a convenient feature that ensures skip-free music even when your CD player is subjected to knocks and jolts while you're jogging or on the move. Devices with Electronic Skip Protection have an intelligent electronic buffer that adjusts both its contents and laser spin speeds automatically to guarantee uninterrupted music listening.

FM radio headphones

Enjoy the convenience of listening to your favorite FM radio stations anytime, without having to carry your portable audio player with FM tuner. This combination of tuner functionality into the headphones allow you to enjoy FM music. Or you can switch off the radio, and simply plug them into your portable audio player to enjoy your own music. Savor up to 15 hours of non-stop FM music, thanks to its replaceable button battery.

Dynamic Bass Boost

Dynamic Bass Boost maximizes your music enjoyment by emphasizing the bass content of the music throughout the range of volume settings - from low to high – at the touch of a button! Bottomend bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.



Issue date 2013-01-31

Version: 2.0.5

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

12 NC: 9073 101 02642 UPC: 6 09585 11243 8

www.philips.com

 st Battery life varies by use and settings.