

Philips
Mini Hi-Fi System



FWCI39



Rich sound experience

Set your sights on the attractive FWCI39 Mini Hi-Fi System, which delivers superbly rich sound. You'll appreciate how easy it is to operate and control, just sit back, relax and enjoy your music all day, your way!

Enrich your sound experience

- 2x10W RMS/ 2x20W music power
- Full range Bass Reflex Speaker System

Continuous enjoyment of your favourite music

- AM/FM tuner
- Stereo cassette deck
- Plays CD, CD-R and CD-RW discs

Personalised sound settings

- Digital Sound Control for optimized music style settings
- Dynamic Bass Boost for deep and dramatic sound

PHILIPS
sense and simplicity

Specifications

Sound

- **Output power (RMS):** 2x10W RMS
- **Sound Enhancement:** Dynamic Bass Boost, Digital Sound Control

Loudspeakers

- **Main Speaker:** 4" woofer, Bass Reflex Speaker System, Full range
- **Number of Loudspeakers:** 2

Audio Playback

- **Number of Discs:** 1
- **Loader Type:** Tray
- **Playback Media:** CD, CD-R, CD-RW
- **Disc Playback Modes:** Next/Previous Track Search, Fast Forward/Backward, Repeat Play, Shuffle Play
- **Programmable Tracks:** 20
- **Number of decks:** 1
- **Cassette Deck Technology:** Mechanical

Audio Recording

- **Recording Media:** Tape
- **Tape Recording Enhancement:** CD Synchro Start Recording, Automatic Recording Level

Tuner/Reception/Transmission

- **Tuner Bands:** FM, FM Stereo, MW

Connectivity

- **Headphone:** 3.5 mm

Convenience

- **Alarms:** CD Alarm, Radio Alarm, Sleep timer
- **Clock:** On main display
- **Display Type:** LCD

Accessories

- **User Manual:** English
- **Included Accessories:** Remote Control, Guarantee booklet

Dimensions

- **Set dimensions (W x H x D):** 220 x 292 x 285 mm
- **Speaker Width:** 190 mm
- **Speaker Height:** 292 mm
- **Speaker Depth:** 182 mm
- **Packaging dimensions (W x H x D):** 510 x 350 x 416 mm
- **Weight incl. Packaging:** 9.333 kg

Power

- **Power supply:** 200-240 V, 50Hz

Product highlights

AM/FM tuner

Stereo cassette deck

Digital Sound Control

Digital Sound Control offers you a choice of pre-set Jazz, Rock, Pop and Classic controls you can use to optimise the frequency ranges for different musical styles. Each mode uses graphic equalizing technology to automatically adjust the sound balance and enhance the most important sound frequencies in your chosen music style. Ultimately, Digital Sound Control makes it easy for you get the most out of your music by precisely adjusting the sound balance to match the type of music you are playing.

Dynamic Bass Boost

Dynamic Bass Boost maximises your music enjoyment by emphasising the bass content of the music throughout the range of volume settings - from low to high – at the touch of a button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.

2x10W RMS/ 2x20W music power

Full range Bass Reflex Speaker

Plays CDs, CD-R and CD-RW



Issue date 2009-01-21

Version: 1.0.4

12 NC: 8670 000 32546
EAN: 87 12581 35290 5

© 2009 Koninklijke Philips Electronics N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

www.philips.com