

Philips  
Micro Hi-Fi System

MP3

MCB240



## Digital Sound from DAB Stations

Unique style and wall mountable

Enjoy superb clarity with built-in DAB tuner with this Micro system. With MP3-CD playback, have the freedom to personalise your sound settings to your tastes. Coupled with wall mounting flexibility, this system will leave you awed.

### Enjoy crystal clear digital radio

- Tune into near CD-quality radio stations
- DAB and FM compatible for fully radio experience

### Longer listening, greater enjoyment

- 10 hours of MP3-CD music

### Enrich your sound experience

- Digital Sound Control for optimised music style settings
- Dynamic Bass Boost for deep and dramatic bass
- 2x5W RMS/2x10W music power/400W PMPO

### Watch your disc spin

- Front motorised CD door with viewing window
- Super sleek and flexible design which can be wall-mounted

**PHILIPS**  
sense and simplicity

# Highlights

## DAB and FM compatible

DAB (Digital Audio Broadcasting) digital radio is, on top of FM analog transmission, a new way of broadcasting radio via a network of terrestrial transmitters. It provides listeners with more choices and information delivered in crystal clear, crackle-free sound quality. The technology allows the receiver to lock on to the strongest signal it can be find. With DAB digital stations there are no frequencies to remember, and sets are tuned by station name, so there is no returning on the move.

## 10 hours of MP3-CD music

MP3 stands for "MPEG 1 Audio layer-3".MP3 is a revolutionary compression technology by which large digital music files can be made up to 10 times smaller without radically degrading their audio quality. MP3 has become the standard audio compression format used on the world wide web, allowing quick and easy audio file transfer.

## Digital Sound Control



Digital Sound Control offers you a choice of pre-set Jazz, Rock, Pop and Classic controls you can use to optimise the frequency ranges for different musical styles. Each mode uses graphic equalizing technology to automatically adjust the sound balance and enhance the most important sound frequencies in your chosen music style. Ultimately, Digital Sound Control makes it easy for you get the most out of your music by precisely adjusting the sound balance to match the type of music you are playing.

## Dynamic Bass Boost



Dynamic Bass Boost maximizes your music enjoyment by emphasising the bass content of the music throughout the range of volume settings - from low to high – at the touch of a button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.

# Specifications

## Sound

- Output Power: 2x10 watts music power
- Sound Enhancement: Digital Sound Control 4 modes, Dynamic Bass Boost

## Loudspeakers

- Main Speaker: 2 way, Bass Reflex Speaker System, 3" woofer, Piezo tweeter

## Audio Playback

- Playback Media: CD, CD-R, CD-RW, MP3-CD
- Disc Playback Modes: Repeat/one/all/program, Shuffle Play, 20-Track Programmable
- ID3-tag support
- Loader Type: Front, Motorised

## Tuner/Reception/Transmission

- DAB: Band III, Info display, Menu, Smart Scan
- Tuner Bands: FM Stereo
- Auto digital tuning
- RDS: Station Name, Program Type, Radio Text
- Station presets: 40
- Tuner Enhancements: Auto Store
- Antenna type: Dipole

## Connectivity

- Aux in: Line in
- Headphone: 3.5 mm
- Other connections: Fixed FM & DAB T-shape antenna

## Convenience

- Alarms: CD Alarm, Radio Alarm, Sleep timer
- Clock: On main display
- Backlight color: White
- Eco Power Standby: 1 watt
- Display Type: Dot Matrix LCD

## Accessories

- Included Accessories: Screws for wall mounting x2
- Remote control: 23-key with battery

## Dimensions

- Set dimensions (W x H x D): 250 x 245 x 96 mm
- Main speaker dimensions (W x H x D): 166 x 245 x 90 mm
- Packaging dimensions (W x H x D): 330 x 313 x 303 mm
- Weight incl. Packaging: 5.6 kg



Issue date 2009-03-15

Version: 3.0.6

12 NC: 9073 100 12875  
EAN: 87 10895 90636 4

© 2009 Koninklijke Philips Electronics N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips  
Electronics N.V. or their respective owners.

[www.philips.com](http://www.philips.com)