



Philips 5000 series
Blu-ray Disc/ DVD player

Smart TV Plus
3D



BDP5500



Blu-ray 3D and the best of Internet on your TV

Be amazed by the Philips 3D Blu-ray DVD Player BDP5500 movie experience at home. Enjoy the best of Internet on your TV with Smart TV Plus, hassle-free with built-in WiFi-n. And playback more than ever before with DivX Plus HD.

See more

- Blu-ray 3D Disc playback for a full HD 3D experience at home
- DivX Plus HD Certified for high definition DivX playback
- Smart TV Plus to enjoy online services & multimedia on TV
- Instant 2D to 3D conversion for a lifelike movie experience
- DLNA Network Link to enjoy photos and videos from your PC

Hear more

- Dolby TrueHD and DTS-HD MA for HD 7.1 surround sound

Engage more

- Built-in WiFi-n for faster, wider wireless performance
- SimplyShare to connect & stream all entertainment wirelessly
- USB 2.0 plays video/music from USB flash/hard disk drive
- Turn your Smartphone into a remote for Philips AV products
- USB keyboard connectivity for easy Smart TV and Web Browsing

PHILIPS

Highlights

Blu-ray 3D Disc playback



Full HD 3D provides the illusion of depth for a heightened, realistic cinema viewing experience at home. Separate images for the left and right eyes are recorded in 1920 x 1080 full HD quality and alternately played on screen at a high speed. By watching these images through special glasses that are timed to open and close the left and right lenses in synchronization with the alternating images, the full-HD 3D viewing experience is created.

DivX Plus HD Certified



DivX Plus HD on your Blu-ray player and/or DVD player offers the latest in DivX technology to let you enjoy HD videos and movies from the Internet direct to your Philips HDTV or PC. DivX Plus HD supports the playback of DivX Plus content (H.264 HD video with high-quality AAC audio in an MKV file container) while also supporting previous versions of DivX video up to 1080p. DivX Plus HD for true HD digital video.

USB keyboard connectivity



Internet browsing is now more convenient. Without having to turn on your PC/MAC, you can surf all you want - in the living room, on your widescreen TV. Simply insert your wireless keyboard dongle or wired keyboard's USB plug into your player's USB port, and you can use a Qwerty keyboard to travel the information highway. Smart TV browsing is also made easier, since a remote control only allows words to be keyed in using its nine alphanumeric keys. There is now no need to carry the laptop around or squint at your mobile device's small screen to enjoy Internet content.

Smart TV Plus



Philips home theater & Blu-ray player with Smart TV Plus offer you an array of enhanced features, including Net TV, SimplyShare & MyRemote. Net TV brings a wide range of online information & entertainment to your TV for services like video-on-demand. With SimplyShare, you can access photos, music & movies stored on your PC from the comfort of

your couch. You can also use your smartphone/tablet to control your home theater via Philips MyRemote app.

Instant 2D to 3D conversion



Enjoy 3D movie excitement in your home using your existing 2D movie collection. Instant 3D conversion uses the latest digital technology to analyze 2D video content to distinguish between foreground and background objects. This detail generates a depth map that converts normal 2D video formats, into exciting 3D. Along with your compatible 3D TV, you are now ready to experience full HD 3D.

SimplyShare



Philips SimplyShare lets you share your music, movies & photos from tablet, smartphone & PCs to your home theater & Blu-ray player. You can stream all entertainment directly from your DLNA-enabled devices or use remote control to access & stream media files from your PC. For the best wireless experience, install the SimplyShare app on your tablet/smartphone. You are now ready to enjoy all your entertainment effortlessly.

Specifications

Accessories

- Included accessories: 2 x AAA Batteries, CD-R (User Manual), Power cord, Product Registration Card, Quick start guide, Remote Control, User Manual
- Optional accessories: QWERTY keyboard

Audio Playback

- Compression format: AAC, MP3, Ogg Vorbis, PCM, WAV, WMA

Still Picture Playback

- Compression format: GIF, JPEG, JPEG HD, JPEG Progressive, PNG
- Picture Enhancement: Rotate, Slideshow with music playback, Zoom

Video Playback

- BD Region Code: B
- DVD Region Code: 2
- Compression formats: DivX Plus™ HD, H.264, MPEG1, MPEG2, MPEG4, XviD
- Disc Playback Modes: A-B Repeat, Angle, Disc Menu, Pause, Repeat, Resume Playback from Stop, Search forward/reverse, Skip, Slow Forward, Standard Play, Zoom
- Video Enhancement: Deep Color, Progressive Scan, Video Upscaling, x.v. Color

File Format

- Audio: aac, mka, mp3, wma
- Picture: GIF, JPEG, JPG
- Video: asf, avi, divx, flv, m2ts, mkv, mov, mp4, mpg, mpg, wmv

Optical Playback Media

- Playable Discs: AVCHD, BD, BD R / BD RE, CD, CDDA, CD-R/CD-RW, DVD, DVD +R/+RW, DVD -R/-RW, SVCD, VCD

Connectivity

- Front Connections: USB 2.0
- Network connections: 802.11 b/g/n, Built-in WiFi
- Rear Connections: Analog audio Left/Right out, Composite video (CVBS) output, Digital coaxial out, Ethernet, HDMI output, SD/SDHC Card slot, USB 2.0

- PC network link: DLNA 1.5 certified
- Smart TV Plus: MyRemote App, Net TV, SimplyShare

Convenience

- BD-Live(1GB USB memory needed)
- Child Protection: Parental Control
- Ease of Use: Fast wake up, MyRemote app
- EasyLink (HDMI-CEC): One touch play, One touch standby, 21:9 format subtitle support, Remote Control-Passthrough
- Firmware upgradeable: Firmware upgradeable via USB, Online firmware upgrade
- On-Screen Display languages: Czech, Danish, Dutch, English, Finnish, French, German, Italian, Norwegian, Polish, Portuguese, Romanian, Russian, Slovak, Spanish, Swedish, Turkish, Greek, Hungarian

Dimensions

- Product (W x H x D): 435 x 38 x 213 mm
- Product weight: 1.82 kg
- Packaging (W x H x D): 495 x 87 x 300 mm
- Weight incl. Packaging: 2.26 kg

Picture/Display

- Aspect ratio: 4:3, 16:9, 21:9
- D/A converter: 12Bit/148MHz
- Blu-ray 3D: 2D to 3D conversion, Full HD 1080p
- Picture enhancement: High Def (720p, 1080i, 1080p), Progressive scan, Video upscaling

Power

- Power consumption: 20 W
- Power supply: 220-230V, 50Hz
- Standby power consumption: 0.3 W

Sound

- D/A converter: 24 bit, 192 kHz
- Dynamic Range (1kHz): ≈90 dB
- Frequency response: (20kHz): = |0.2|dB (Max./Min. 2ch, DVD) Hz Hz
- Signal to noise ratio: = 100 dB
- Sound Enhancement: Night Mode
- Sound System: Dolby Digital 5.1, Dolby Digital Plus, Dolby True HD, DTS Digital Surround, DTS-HD High Resolution Audio, DTS-HD Master Audio



Issue date 2014-08-28

Version: 10.2.8

12 NC: 8670 000 83739
EAN: 87 12581 62474 3

© 2014 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com