

Philips
Micro Hi-Fi System

Bluetooth
built-in speakers for calls

BTM177



Enjoy wireless music via Bluetooth® technology

from mobile phone or PC

Featuring Bluetooth® technology, the BTM177 Micro Hi-Fi System lets you enjoy music from your mobile phone and PC wirelessly. Complete audio system functions feature built-in mic for hands-free calls and switching between calls and music.

Enjoy freedom with Bluetooth® wireless technology

- Playback mobile phone and PC music via Bluetooth® technology
- Built-in microphone and speakers for hands-free mobile calls
- Auto switch between telephone calls and music playback

Organize your home digital music collection

- One-touch MP3 digital recording in 2X speed - no pc needed

Enrich your sound experience

- Enjoy MP3/WMA music directly from your portable USB devices
- Play MP3/WMA-CD, CD and CD-RW
- Digital Sound Control for optimized music style settings
- Dynamic Bass Boost for deep and dramatic sound
- Loudness for bass and treble enhancement
- 2x25W RMS/2x50W Music Power

Refined in sound and look

- Elegant wood-finished speakers

PHILIPS

Highlights

USB Direct for MP3/WMA music

Simply plug in your device to the USB port on your Philips Hi-Fi system. Your digital music will be played directly from the device. Now you can share your favorite moments with family and friends.

Digital Sound Control

Digital Sound Control offers you a choice of pre-set Jazz, Rock, Pop and Classic controls you can use to optimise the frequency ranges for different musical styles. Each mode uses graphic equalizing technology to automatically adjust the sound balance and enhance the most important sound frequencies in your chosen music style. Ultimately, Digital Sound Control

makes it easy for you get the most out of your music by precisely adjusting the sound balance to match the type of music you are playing.

Dynamic Bass Boost

Dynamic Bass Boost maximizes your music enjoyment by emphasizing the bass content of the music throughout the range of volume settings - from low to high – at the touch of a button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.

Loudness for bass and treble

In the sound spectrum, high and low frequencies are relatively less audible to human ears - especially at low volumes. By activating the Loudness feature, the bass and treble will be amplified so you can savor a more balanced sound perception overall.

One-touch 2x recording speed

Simply plug in your USB mass storage device to the USB port on Philips audio system and start recording your favorite music from CDs to your USB device or MP3 player in 2X speed - with one touch operation and no computer needed.



Specifications

Sound

- Output Power: 2x25W RMS / 2x50W music power
- Sound Enhancement: Digital Sound Control 4 modes, Dynamic Bass Boost, Loudness

Loudspeakers

- Main Speaker: 4" woofer, Bass Reflex Speaker System

Audio Playback

- Playback Media: WMA-CD, MP3-CD, CD, CD-R, CD-RW
- Disc Playback Modes: 20-Track Programmable, Repeat/one/all/program, Shuffle Play, Fast Forward/Backward, Next/Previous Track Search
- Loader Type: Top
- USB Direct Modes: Fast Backward/Fast Forward, Play/Pause, Previous/Next, Program Play, Repeat, Shuffle, Stop

Audio Recording

- Recording Media: USB device
- Recording speed: 2 x
- USB recording modes: Instant record, Programmed tracks, Single disc, Single track
- USB recording sources: CD

Tuner/Reception/Transmission

- Auto digital tuning
- Station presets: 20
- Tuner Bands: FM Stereo
- Tuner Enhancements: Auto Store

Connectivity

- Other connections: FM Antenna
- Headphone: 3.5 mm
- Audio Connections: 3.5mm Line in, Analogue Audio In (L/R)
- USB: USB host

Convenience

- Display Type: LCD
- Alarms: CD Alarm, Radio Alarm, Sleep timer, USB alarm
- Clock: On main display
- Backlight color: Blue
- Eco Power Standby: 1 watt

Accessories

- Included accessories: FM antenna, World Wide Warranty leaflet
- Remote control: 40-key with Lithium batteries
- Quick start guide: English, German, Dutch, French, Spanish, Italian
- User Manual: 16 languages
- AC/DC Adaptor: Switching power supply

Dimensions

- Set dimensions (W x H x D): 232 x 85 x 275 mm
- Main speaker dimensions (W x H x D): 160 x 250 x 180 mm
- Packaging dimensions (W x H x D): 554 x 405 x 275 mm
- Weight incl. Packaging: 6.9 kg

Power

- Power supply: 100-240VAC, 50/60Hz



Issue date 2017-04-07

Version: 1.0.6

12 NC: 8670 000 37578
EAN: 87 12581 39995 5

© 2017 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com