



Philips  
Portable speaker

Blue  
USB



SBM130BLU



## Your all-in-one portable speaker

Enjoy listening to music from the Philips all-in-one portable speaker. Play your favorite tunes via USB/ MicroSD card/aux-in connectivity. The wOOx™ technology speaker is compact and comes with rechargeable battery and multiple colors.

### Enjoy music from multiple sources

- Easy playback from USB/MicroSD Card
- Built-in Digital FM radio
- AUX-in for easy connection to almost any electronic device

### Rich and clear sound

- wOOx™ Loudspeaker Technology for deep and powerful bass
- 3W RMS total output power

### Easy to use

- Built-in rechargeable battery
- Stereo headphone jack for better personal music enjoyment
- Compact and mobile
- Clear and bright LED display

# PHILIPS

Portable speaker  
Blue USB

# Specifications

## Left/Right speakers

- Speaker driver: 1 x wOOx driver, 2 x 1.5" Full range
- Driver power range: 0-5W x 1
- Frequency range: 100Hz-20kHz

## Audio systems

- Sound enhancement: wOOx technology
- Audio power amplifier: Class "AB" digital amplifier
- Output power in total: 3W RMS (maximum)
- Frequency range: 20Hz-20kHz
- Signal/Noise ratio: > 70dB
- THD: < 1%
- Input sensitivity: 600mV

## Audio Playback

- Audio supported format: MP3
- Playback Media: USB flash drive, MicroSD card
- Playback mode: Fast forward and backward, Next/previous track search

## Convenience

- Display type: LED display

## Connectivity

- Aux in
- Headphone out
- USB charging

## Tuner/Reception/Transmission

- Tuner bands: FM

## Accessories

- USB cable: for charging
- 3.5mm jack antenna
- 3.5mm audio cable

## Power

- Battery type: Built-in lithium
- Music playtime: 6 hr

## Product dimensions

- Product dimensions (W x H x D): 6,1 x 2,8 x 1,5 inch
- Product dimensions (W x H x D): 15,5 x 7,1 x 3,7 cm
- Weight: 0,191 kg
- Weight: 0,421 lb

SBM130BLU/00

# Highlights

## USB/MicroSD card

Simply load the USB or MicroSD card with the desired content, plug it into your player - and never have to worry about running out of entertainment choices again.

## Digital FM radio

Digital Radio is, on top of FM analog transmission, a new way of broadcasting radio via a network of terrestrial transmitters. It provides listeners with more choices and information delivered in clear, crackle-free sound quality. The technology allows the receiver to lock on to the strongest signal it can be find. With digital stations there are no frequencies to remember, and sets are tuned by station name, so there is no returning on the move.

## 3W RMS



This system has 3W RMS total output power. RMS refers to Root Mean Square which is a typical measurement of audio power, or rather, the electrical power transferred from an audio amplifier to a loudspeaker, which is measured in watts. The amount of electrical power delivered to the loudspeaker and its sensitivity determines the sound power that is generated. The higher the wattage, the better the sound power emitted by the speaker.

## wOOx™ Loudspeaker Technology

wOOx™ technology is a revolutionary loudspeaker concept that allows you to hear and feel profoundly deep bass that is richer than any other audio system. Special speaker drivers work in harmony with the wOOx bass radiator, and precise tuning between the main driver and the tweeter ensures smooth transitions from low-mid to high frequencies. Dual suspension and a totally symmetrical sandwich construction deliver low and precise base without noticeable distortion. wOOx produces exceptionally deep and dynamic bass by using the speaker box full volume to truly magnify the impact of the music.



Issue date 2015-01-25

Version: 2.0.5

12 NC: 8670 000 95211  
EAN: 06 92341 07179 83

© 2015 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)