

Philips  
Portable DVD Player



PET944



## Superior picture quality

with high density (800x480) pixel LCD

Enjoy movies and more on the go with the Philips Portable DVD player PET944. The 22.9cm/9" digital color LCD display brings images to life. Display and share your digital photos easily. Lightweight and compact with up to 6hrs playback time.

### Play your movies, music and photos on the go

- DVD, DVD+/-R, DVD+/-RW, (S)VCD, CD compatible
- DivX Certified for standard playback of DivX videos
- Play MP3/WMA-CD, CD and CD-RW
- View JPEG images from picture disc

### Easily display your digital photos

- 22.9 cm (9") high density (800x480 pixels) LCD display
- 180-degree swivel screen for improved viewing flexibility
- Display photos and photo slideshows
- View photos directly from memory cards, DVDs and CDs

### Extra touches for your convenience

- Enjoy up to 6 hours continuous non-stop playback\*
- SD/SDHC card slot for music, photo and video playback
- Smart Car Mount for ease-of-use
- AC adaptor, car adaptor and AV cable included

# PHILIPS

# Specifications

## Picture/Display

- Diagonal screen size (inch): 9 inch
- Resolution: 800(W)x480(H)x3(RGB)
- Display screen type: LCD TFT
- Brightness: 200 cd/m<sup>2</sup>
- Contrast ratio (typical): 250:1
- LCD panel type: Anti-glare polarizer
- Effective viewing area:  
198.240(W)x111.735(H)mm
- Response time (typical): 30 ms

## Sound

- Output Power: 600mW RMS(built-in speakers)
- Output power (RMS): 5mW RMS(earphone)
- Signal to noise ratio: >80dB(earphone), >62dB(built-in speakers)

## Video Playback

- Playback Media: DVD, Picture CD, SVCD, Video CD, DVD-R/-RW, MP3-CD, CD-R/CD-RW, DVD+R/+RW, CD, WMA
- Disc Playback Modes: A-B Repeat, Angle, Disc Menu, Fast Backward, Fast Forward, OSD, Repeat, Shuffle Play, Zoom
- Video disc playback system: NTSC, PAL
- Compression formats: Divx, MPEG4

## Audio Playback

- Compression format: Dolby Digital, MP3, WMA
- MP3 bit rates: 32 - 320 kbps
- WMA bit rates: 32 - 192 kbps
- Playback Media: CD, CD-RW, MP3-CD, CD-R, WMA-CD
- File systems supported: ISO-9660, Joliet

## Connectivity

- DC in: 9V, 1.5A
- Headphone jack: 3.5mm Stereo Headphone x 2
- AV output: Composite (CVBS) x1
- SD/MMC card slot: SD/SDHC card slot

## Convenience

- Battery charging indication
- Shock proof

## Accessories

- AC/DC Adaptor: DC 9V, 1.5A, 110-240v, 50/60Hz
- Car kit: cigarette outlet adaptor, 12vDC
- Remote control: AY5509 slim remote
- Cables: 1 x AV Cables
- User Manual: Multi-languages
- Smart car mount

## Power

- Battery Type: Built-in battery
- Battery lifetime: Up to 6 hours\*

## Dimensions

- Master carton dimensions: 225 x 295 x 280 mm
- Master carton quantity: 3
- Master carton weight: 5.9 kg
- Packaging dimensions (W x H x D):  
272 x 285 x 70 mm
- Product dimensions (W x H x D):  
238 x 32 x 175 mm
- Packaging type: D-box
- Product weight: 1.2 kg

# Highlights

## 180-degree swivel screen

The screen swivels 180° to give you the optimum viewing angle for watching movies and photos. Rotate the screen or adjust it up and down to cut down on glare and get the best viewing angle possible.

## 22.9 cm (9") HD LCD display

The high resolution (800 x 480 pixel) color LCD display brings images to life, showing off your treasured photos, favorite movies and music with the same 'real life' rich detail and vibrant colors as high quality prints.

## Display photos

Simply insert your disc or memory card into the player and your digital photos will be played directly on the device.

## Play MP3/WMA-CD, CD and CD-RW

Audio compression technology allows large digital music files to be reduced up to 10 times in size without radically degrading their audio quality. MP3 or WMA are two of the compression formats that let you enjoy a world of digital music on your Philips player. Download MP3 or WMA songs from authorized music sites on the Internet or create your own MP3 or WMA music files by ripping your audio CDs and transferring them onto your player.

## Smart Car Mount

To enjoy entertainment on the go, why not bring your portable DVD player from home on the road with you? A unique Car Mount system ensures ease-of-use, with a quick-release arm that facilitates easy removal of the player when not in use. You can bring the portable DVD player with you, leaving just the Mount behind in the car.

## Up to 6 hrs movies playback

This Philips player comes with a compact built-in rechargeable battery for long-lasting power. Up to 6 hours of continuous movie, photo and music playback enjoyment can be achieved on a single charge. Just plug in the power cable to recharge the player - it's that simple.

## DivX Certified

With DivX® support, you are able to enjoy DivX® encoded videos. The DivX media format is an MPEG4-based video compression technology that enables you to save large files like movies, trailers and music videos on media like CD-R/RW, and DVD recordable discs.



Issue date 2020-12-07

Version: 1.1.6

12 NC: 8670 000 52383  
EAN: 87 12581 48155 1

© 2020 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)

\* DivX, DivX Certified, and associated logos are trademarks of DivXNetworks, Inc. and are used under license.  
\* Windows Media and the Windows logo are trademarks, or registered trademarks of Microsoft Corporation in the United States and/or other countries.  
\* Rechargeable batteries have a limited number of charge cycles and may eventually need to be replaced. Battery life and number of charge cycles vary by use and settings.  
\* Battery life varies by use and settings.  
\* Battery life of playtime is approximate and may vary depending on application condition. To optimize battery life, user should turn LCD backlight to minimum, connect to headphones (not built-in speakers) and listen at medium volume level, and use the product at room temperature.