



Philips Design collection
Cordless phone answer
machine

ID9371B

When beauty meets sound...

Follow your instinct, be impulsive, the ID9 is pure indulgence crafted exclusively with you in mind. No need to justify, no need to be reasonable, go on treat yourself. Calling takes on a whole new meaning with the ID9.

Incomparable sound

- XHD sound
- Enhanced speakerphone for real-life hands-free conversations

Peace of mind

- 15-minute recording time
- SIM-card copying facility

Pure indulgence

- Unique "soft touch" feel
- Stunning white backlit inverse display
- Exclusively crafted design

PHILIPS
sense and simplicity

Specifications

Picture/Display

- Backlight
- Backlight colour: White
- Display colours: 65 536 colours
- Main Display Resolution: 128 x 128 pixel
- Main Display Technology: CSTN
- Main Display Type: Graphic

Sound

- Handset ringers: Instrumental, Polyphonic
- Volume Control: Volume Control up/down

Convenience

- Alarms: Alarm Clock
- Base Station keys: Paging key
- Base Station Mem. Card Reader: SIM Card Reader
- Battery charging indication
- Call Management: Call Waiting, Caller ID, Microphone mute
- Ease of Use: Full Duplex Hands-free, Graphical User Interface, Keypad Lock, Menu Control
- Embedded Games: 3
- Function: Baby Call
- Multi-base capability: Up to 4 bases
- Multi-handset capability: Up to 6 handsets
- Personalisation/Customisation: Wallpaper
- Signal strength indication
- VIP group with own melody: Yes, 3 groups
- Backlit keypad: Yes (White)

Network Features

- Antenna: Integrated on base, Integrated on handset

- Compatible: GAP
- Dialling: Tone, Pulse
- Messaging: SMS (Short Message Service)

Operator Requirements

- Name and Caller ID
- Caller ID on call waiting

Answering Machine

- Plug and Play Answering machine
- Recording time capacity: Up to 15 min

Memory Capacity

- SMS storage capacity: 50
- Call log entries: 30
- Phonebook: 250 names and numbers
- Number of SMS Boxes: 10

Dimensions

- Base dimensions: 127 x 77 x 33 mm
- Handset dimensions: 167 x 55 x 46 mm

Power

- Battery capacity: 650 mAh
- Battery type: AAA NiMH
- Kind of Battery: Rechargeable
- Mains power: AC 220-240 V - 50 Hz
- Number of batteries: 2
- Standby time: Up to 140 hours
- Talk time: Up to 12 hours

Highlights

15-minute recording time

Records up to 15 minutes of incoming messages

XHD sound

No matter where you are, you can have a phone conversation that is free from noise, with incredible loudness and sound purity in the voice. Thanks to a high-quality speaker, sophisticated technology and to a real acoustic chamber, you can enjoy the unbelievable sound quality in every phone conversation.

Enhanced speakerphone

Combine a high-quality speaker, sophisticated signal processing, a real acoustic chamber and full duplex hands-free and you'll get the most natural reproduction of a conversation. Both sides can speak and be heard at the same time, as in a face-to-face conversation.

Unique "soft touch" feel

Unique "soft touch" feel

White backlit inverse display

The white characters are displayed clearly on the black backlit display of your phone.

Exclusively crafted design

Bring a joy not only to your ears but also to your eyes, with an exclusively crafted design.

SIM-card copying facility

With the SIM-card copying facility, you can transfer your whole mobile phonebook on to your home telephone in a matter of seconds.



Issue date 2011-04-05

Version: 8.0.10

12 NC: 9961 400 05938
EAN: 87 10895 94923 1

© 2011 Koninklijke Philips Electronics N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips
Electronics N.V. or their respective owners.

www.philips.com