

Philips  
DVD Micro Theater



MCD515

## Rich Sound and Movie Experience

You're in touch with the latest and the coolest - now get a load of the hot Micro Theatre with DVD, DivX and MP3-CD/WMA-CD playback! Relax to your favorite movies and music. Home entertainment will never be the same again!

### **Enrich your movie experience**

- Play DVD, DivX®, (S)VCD, MP3-CD, WMA-CD, CD(RW) & Picture CD
- Dolby Digital for ultimate movie experience

### **Enrich your sound experience**

- Incredible Surround™ for enhanced audio enjoyment
- Digital Sound Control for optimized music style settings
- Dynamic Bass Boost for deep and dramatic sound
- 50W RMS total output power

### **Start the day your way**

- Wake up and sleep timer functions
- Logic tape deck
- Digital tuning with 40 preset stations for extra convenience

# PHILIPS

# Highlights

## Incredible Surround™

Incredible Surround is an audio technology from Philips that dramatically magnifies the sound field to immerse you in the audio. Using state-of-the-art electronic phase shifting, Incredible Surround mixes sounds from left and right in such a way that it expands the virtual distance between the two speakers. This wider spread greatly enhances the stereo effect and creates a more natural sound dimension. Incredible Surround allows you to experience total surround with greater depth and width of sound, without the use of additional speakers.

## Digital Sound Control

Digital Sound Control offers you a choice of pre-set Jazz, Rock, Pop and Classic controls you can use to optimise the frequency ranges for different musical styles. Each mode uses graphic equalizing technology to automatically adjust the sound balance and enhance the most important sound frequencies in your chosen music style. Ultimately, Digital Sound Control makes it easy for you get the most out of your music by precisely adjusting the sound balance to match the type of music you are playing.

## Dynamic Bass Boost

Dynamic Bass Boost maximizes your music enjoyment by emphasizing the bass content of the music throughout the range of volume settings - from low to high – at the touch of a button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.



# Specifications

## Sound

- Output Power: 2x25 watts RMS / 2x50 watts music power
- Sound Enhancement: Incredible Surround, Digital Sound Control 4 modes, Dynamic Bass Boost
- Sound System: Dolby Digital

## Loudspeakers

- Main Speaker: 2 way, Bass Reflex Speaker System, 4" woofer, Piezo tweeter, Speaker grilles detachable

## Video Playback

- Playback Media: DVD+RW, DVD-Video, Video CD/SVCD, Picture CD, DivX
- DVD Region.: 2
- Disc Playback Modes: Zoom, Slow Motion, A-B Repeat, Angle, Parental control, PBC
- Loader Type: Top

## Audio Playback

- Playback Media: CD, CD-R, CD-RW, MP3-CD, WMA-CD
- Disc Playback Modes: Repeat/one/all/program, Shuffle Play, 16-Track Programmable
- Cassette Deck Technology: Logic
- Cassette Playback Modes: Electronic Speed Control

## Audio Recording

- Recording Media: Tape
- Tape Recording Enhancement: CD Synchro Start Recording, Automatic Recording Level, One-Touch Recording

## Tuner/Reception/Transmission

- Tuner Bands: MW, FM Stereo
- Auto digital tuning
- Station presets: 40
- Tuner Enhancements: Auto Store
- RDS: Radio Text, RDS Clock Set, Station Name

## Connectivity

- Aux in: 1x(L/R)/RCA
- Video Output - Analog: S-Video (on Hosiden), Composite CVBS (yellow cinch), SCART
- Headphone: 3.5 mm
- Other connections: Active subwoofer Pre-out, Line out, FM Antenna, MW Antenna, Digital coaxial out

## Convenience

- Alarms: Sleep timer
- Clock: On main display
- OSD Languages: English, French, Spanish, Turkish, Swedish, Portuguese, Italian, German, Dutch
- Eco Power Standby: 1 watt
- Display Type: VFD display

## Accessories

- Included accessories: Composite video cable (Y), Audio Cable, FM/MW Antenna
- Remote control: 45-key with 2xAA batteries

## Dimensions

- Set dimensions (W x H x D): 175 x 252 x 305 mm
- Main speaker dimensions (W x H x D): 170 x 252 x 214 mm
- Packaging dimensions (W x H x D): 528 x 351 x 400 mm
- Weight incl. Packaging: 10.5 kg



Issue date 2014-02-11

Version: 2.0.4

12 NC: 9073 100 13089  
EAN: 87 10895 93814 3

© 2014 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)