



Philips  
Extension socket

### 4 outlets

charge two devices at once  
individual switch  
4 ft. power cord

SPN6348WD



## Power and charge your electronics

Expand your number of sockets to 4

Featuring 4 grounded outlets, 2 USB ports, 4 ft power cord and individual power control switch, built-in circuit breaker shuts off power to sockets in case of overloading or short circuit.

#### Plug more

- Expands 1 grounded outlet into 4
- 2 USB charging ports

#### Built-in convenience

- 4 ft. power cord
- USB Charging 2.1

#### Dependable protection

- 6-amp circuit breaker

#### Simplicity

- Individual on/off switch
- Integrated automatic child safety outlets

# PHILIPS

Extension socket

4 outlets charge two devices at once, individual switch, 4 ft. power cord

# Specifications

## Packaging dimensions

- EAN: 48 95185 62581 2
- Packaging dimensions (W x H x D): 12 x 39 x 4.5 cm
- Gross weight: 0.463 kg
- Nett weight: 0.387 kg
- Number of products included: 1
- Tare weight: 0.076 kg
- Type of shelf placement: Hanging
- Packaging type: Carton

## Outer Carton

- Gross weight: 6.69 kg
- GTIN: 1 48 95185 62581 9
- Outer carton (L x W x H): 40 x 29.5 x 25.5 cm
- Number of consumer packagings: 12
- Tare weight: 2.046 kg
- Nett weight: 4.644 kg

## Product dimensions

- Product dimensions (W x H x D): 8 x 34.5 x 3.39 cm
- Weight: 0.387 kg

SPN6348WD/94

# Highlights

## automatic child safety outlets

Helps keep children safe from accidental shock.

## 1 grounded outlet into 4

A power multiplier that expands 1 grounded outlet in to 4 grounded outlets by plugging directly into the wall

## USB Charging 2.1

USB Charging ports rated at 2.1 amps enable you to charge your mobile devices-compatible with smart phones, iPOD, iPhone, and iPad

## 2 USB charging ports

USB charging port allows you to charge USB devices.

## 4 ft. power cord

Provides power to the unit which can be 4 feet from the AC outlet.

## Individual on/off switch

This individual switch controls each outlet on the power multiplier

## 6-amp circuit breaker

Internal 6-amp circuit breaker shuts off power to the outlets in case of overloading or short circuit. Press the reset button located on the extension socket to restore power after the circuit breaker shuts off.



Issue date 2022-05-15

Version: 3.0.5

12 NC: 8670 001 41898  
EAN: 69 59033 84232 0

© 2022 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)