

Philips PhotoFrame

10.2" LCD

9.4" v.area 3:2 frame ratio

10FF2XLE

Every picture tells your story

Luxury design, superb performance! The limited edition 10FF2XLE combines the ultimate in elegant, exquisite design and craftsmanship with a superb large-screen digital photo display to create a prized personal possession or a gift to remember.

Luxurious design to complement your photos

- · Aesthetically pleasing hand-etched floral wave pattern
- Exquisite materials and finishing add value to your photos
- · Auto photo orientation to fit portrait or landscape modes

Top-quality display for print-like pictures

- · High pixel density for sharp and detailed photo display
- Perfect digital colours for rich and stunning photo display

Easily display and manage your digital photos

- Play slideshows, single photo, thumbnails or show clock
- Create albums and slideshows and manage your photos
- Store up to 1000 photos in internal memory
- Rotate, zoom, crop, mask and add effects to your photos

Simple intuitive operation and great convenience

- Have fun with collages: display multiple photos in one view
- Operate on AC power or cordlessly with rechargeable battery



Specifications

Picture/Display

- Effective viewing area: 199.8 x 132.48 mm
- Resolution: viewing area resolution: 720 x 480
- Viewing angle: @ C/R > 10, 120° (H)/110° (V)
- Lifetime, to 50% brightness: 20,000 hr
- Brightness: 200 cd/m²
- · Aspect ratio: 3:2
- Panel resolution: 800 x 480
- Pixel density: 91.5 ppi
- Contrast ratio (typical): 300:1

Connectivity

• USB: To PC/Mac (USB 2.0)

Storage Media

- Memory Card Types: Compact Flash type I, Micro Secure Digital (SD), Multimedia Card, Secure Digital (SD), Secure Digital (SDHC), xD card, Memory Stick, Memory Stick Pro, Memory Stick Duo (via adapter), MS Pro Duo (via adapter)
- Built-in memory capacity: 128 MB (for 510-1020 photos, around 26 MB used by system)

Convenience

- · Card Reader: Built in (2x)
- Photo format supported: JPEG photo, Up to 10 MB JPEG files, Up to 16 Megapixels
- Placement supported: Landscape, Photo auto orientation, Portrait
- Buttons and controls: 2 buttons, 5-way mini joystick
- Playback mode: Full screen browse, Slideshow, Thumbnail browse
- Album management: Create, Delete, Edit, Rename
- Photo edit: Copy, Crop, Delete, Move, Rotate, Zoom & crop
- Photo effects: Black and White, Frames, Sepia
- Slideshow management: Create slideshow, Delete slideshow. Rename slideshow
- Slideshow setting: Collage (multiple pictures), Random, Sequential, Transition effect

- Screen background: Black, Grey, White
- Setup function: Auto on/off on weekday/weekend, Beep on/off, Brightness adjustment, Clock display enable/disable, Event reminder with snooze, Language, Photo source, Set time and date, Status
- System status: Battery level, Firmware version, Power source, Remaining memory
- Connected media status: Connected media, Remaining memory
- Plug & Play Compatibility: Mac OS X, Windows 2000/XP or later, Windows Vista
- Regulatory Approvals: BSMI, CCC, CE, C-Tick, FCC, GOST, PSB, UL, VCCI
- · Adjustable stand: Rotating, Adjustable tilt
- Other convenience: Kensington lock compatible
- Firmware upgradeable: Firmware upgradeable via USB
- On-Screen Display languages: Danish, Dutch, English, French, German, Italian, Japanese, Russian, Simplified Chinese, Spanish

Accessories

 Included Accessories: AC-DC Adapter, PC/Mac software CD, Quick start guide, USB cable, User manual

Dimensions

- Set dimensions with stand (W \times H \times D): 299 \times 221 \times 126 mm
- Weight: 1.37 kg
- Temperature range (operation): 0°C to 45°C
- Temperature range (storage): -20°C to 60°C

Electricity

- Power consumption: (System on and battery charging) 7.5 W
- · Operating time on battery: 1* hr
- Battery LED indicator: Charging Flashing
- Power LED indicator: Operation Blue
- Power mode supported: AC powered, Battery powered

Highlights

High Pixel Density Display

The very best high-density screen shows off your treasured photos with the same 'real life' rich detail and vibrant colours as high-quality prints.

Perfect digital colour

Full colour display brings out the best in your photos with vibrant, real-life colours by displaying the same full range of colours found in professionally printed photos.

Auto orientation

Automatic landscape/portrait recognition employs a sensor that recognises PhotoFrame orientation and displays each photo in its proper mode.

Smart Album

Smart Album allows you to create and manage albums, as well as set up and adjust transition effects for your photo slideshows.

Smart photo storage

Smart photo storage employs smart software that minimises required storage space without compromising photo display quality.

PhotoEffect Wizard



The PhotoEffect Wizard is an easy-to-use feature that allows you to rotate, zoom in, crop and even adjust photo colour tones to black and white or sepia within PhotoFrame itself.

















Issue date 2009-08-13

Version: 2.0.6

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

12 NC: 8670 000 33103 EAN: 87 12581 35747 4

www.philips.com