

Philips Micro Hi-Fi System

CD playback wall-mountable

MC235B

## Obsessed with sound

## Sound that fits your home

Trendy and progressive, unique innovation and style appeals to you. The vividly and chic Philips sleek micro music system, with dynamic sound performance, is packed in a sleek design that can also be wall mounted.

### **Enrich your sound experience**

- Play CD, CD-R and CD-RW discs
- Digital Sound Control for optimized music style settings
- Dynamic Bass Boost for deep and dramatic sound
- 10W RMS total output power

### Start the day your way

- Wake up and sleep timer functions
- Digital tuning with 40 preset stations for extra convenience

### Design that blends into your interior

- Wall-mountable option for flexible placement
- Motorized sliding front door adding style and elegance



# Specifications

- Output power: 10 W total power, 2 x 5 W RMS
- · Sound enhancement: digital sound control 4 modes, Dynamic Bass Boost

#### Loudspeakers

- · Speaker drivers: 3" woofer, Piezo tweeter
- · Loudspeaker enhancement: 2-way
- Speaker types: bass reflex speaker system

#### Audio playback

- Playback media: CD, CD-R, CD-RW
- Disc playback modes: repeat/shuffle/program

#### Tuner/Reception/Transmission

- Tuner bands: FM stereo, AM
- Station presets: 40
- · Antenna: AM antenna, FM antenna
- Tuner enhancement: auto digital tuning, auto scan

#### Connectivity

- Audio/Video output: Headphone (3.5mm)
- MP3 Link: 3.5mm stereo line in

#### **Convenience**

· Alarms: CD alarm, radio alarm

- · Backlight color: blue
- · Loader type: front, motorised
- · Clock: on main display, sleep timer
- · Display type: LCD display

#### Accessories

- · Remote control: 23-key with lithium battery
- · User Manual: English, French, Spanish
- · Others: AM/FM antenna, screws for wall mounting

#### **Dimensions**

- · Gross weight: 5.3 kg
- Packaging width: 330 mm
- · Packaging height: 313 mm
- Packaging depth: 300 mm
- Main speaker dimensions (W  $\times$  D): 166  $\times$  90 mm
- Main speaker height: 245 mm
- Main unit depth: 96 mm
- · Main unit height: 245 mm
- · Main unit width: 250 mm

• Power supply: 120V, 60Hz

## Highlights

MC235B/37

#### **Digital Sound Control**

Digital Sound Control offers you a choice of pre-set Jazz, Rock, Pop and Classic controls you can use to optimise the frequency ranges for different musical styles. Each mode uses graphic equalizing technology to automatically adjust the sound balance and enhance the most important sound frequencies in your chosen music style. Ultimately, Digital Sound Control makes it easy for you get the most out of your music by precisely adjusting the sound balance to match the type of music you are playing.

#### **Dynamic Bass Boost**

Dynamic Bass Boost maximizes your music enjoyment by emphasizing the bass content of the music throughout the range of volume settings from low to high - at the touch of a button! Bottomend bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.















Issue date 2014-03-14

Version: 2.1.8

© 2014 Koninklijke Philips N.V. All Rights reserved.

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

12 NC: 8670 000 29962 UPC: 6 09585 13302 0

www.philips.com