



Philips  
PhotoFrame

5.6" LCD

4:3 frame ratio

6FF3FPW

## Share your memories

How many digital pictures are hidden on your PC? See, share, organise and relive your memories with Philips PhotoFrame™, the easiest way to share your memories by displaying your digital photos in stunning quality - without a PC.

### Top quality display for print-like pictures

- 4:3 aspect ratio for optimal distortion-free display
- ImagEn for sharp and vibrant colour
- Add new glow to old memories with RadiantColor
- SmartContrast: Optimised contrast for visual clarity

### Easily display and manage your digital photos

- Play slideshows, single photo, thumbnails or show clock
- Have fun with collages: display multiple photos in one view
- View photos directly from memory cards - no PC required
- View USB flash drive photos without a PC

### Simple intuitive operation and great convenience

- Intuitive UI, 5-way-keypad for easy navigation and operation

### Green design

- Auto turning display on/off at preset times for power saving

# PHILIPS

sense and simplicity

# Specifications

## Picture/Display

- Viewing angle: @ C/R > 10, 130° (H) / 110° (V)
- Lifetime, to 50% brightness: 20000 hr
- Aspect ratio: 4:3
- Brightness: 200 cd/m<sup>2</sup>
- Contrast ratio (typical): 300:1
- Panel resolution: 320 x 234

## Connectivity

- USB: USB 2.0 Host

## Storage Media

- USB: USB flash drive
- Memory Card Types: Secure Digital (SD), Secure Digital (SDHC), Multimedia Card, xD card, Memory Stick, Memory Stick Pro

## Convenience

- Card Reader: Built-in (2x)
- Photo format supported: JPEG photo, Up to 10MB JPEG files, Up to 20 Megapixels
- Placement supported: Landscape, Portrait, Photo auto orientation
- Buttons and controls: 3 buttons, 4-way navigation key and enter
- Playback mode: Full screen browse, Slideshow, Thumbnail browse
- Photo edit: Copy, Delete, Rotate, Zoom & crop
- Photo effects: Black and White, Frames, Sepia, Radiant colour
- Slideshow setting: Random, Sequential, Transition effect
- Screen background: Black, White, Gray, Ambient colour, Auto-fit
- Setup function: Brightness adjustment, Language, Status, Beep on/off, Set time and date, Clock display enable/disable, Alarm, Auto on/off
- System status: Firmware version, Remaining memory
- Connected media status: Connected media,

## Remaining memory

- Plug & Play Compatibility: Windows 2000/XP or later, Windows Vista, Mac OS X
- Regulatory Approvals: BSMI, C-Tick, CCC, CE, FCC, GOST, PSB, Switzerland, UL/cUL
- On-Screen Display languages: Danish, Dutch, English, French, German, Italian, Simplified Chinese, Spanish, Japanese, Russian

## Accessories

- Included Accessories: AC-DC Adapter, Quick start guide, Stand, User Manual

## Dimensions

- Temperature range (operation): 0°C to 40°C
- Temperature range (storage): -20°C to 70°C
- Set dimensions with stand (W x H x D): 167.8 x 135.3 x 100.73 mm

## Power

- Power consumption: 3 W
- Power mode supported: AC powered

## Outer Carton

- Gross weight: 5.338 kg
- GTIN: 1 87 12581 41302 3
- Outer carton (L x W x H): 52.6 x 24.3 x 25.2 cm
- Nett weight: 3.618 kg
- Number of consumer packagings: 6
- Tare weight: 1.72 kg

## Packaging dimensions

- Packaging dimensions (W x H x D): 22.2 x 21.5 x 8 cm
- EAN: 87 12581 41302 6
- Gross weight: 0.723 kg
- Nett weight: 0.603 kg
- Number of products included: 1
- Packaging type: Carton
- Tare weight: 0.12 kg



# Highlights

## Multiple viewing modes

Flexible display modes give you the freedom to display your photos one image at a time, in thumbnail mode for quick, easy searches, or to create a slideshow of your most treasured photos.

## Multiple-photo collage effect

It's a slideshow effect to show photos in collage form that automatically and randomly compiles different photos together to avoid unattractive borders that may result from photos which are smaller than screen size.

## 4:3 perfect frame ratio

Philips digital PhotoFrame ensures your photo to be displayed in 4:3 ratio for the best viewing experience.

## ImagEn technology

ImagEn is exclusive Philips photo enhancement technology that automatically analyses your photos to correct colour and adjust for optimal contrast: ImagEn separates colours to avoid "crosstalk" adjusts brightness distribution for great visual contrast and corrects Gamma for colour accuracy.

## RadiantColor

RadiantColor is an exclusive Philips technology for displaying smaller photos in the optimal 4:3 ratio by extending the colour on the edges of a less-than-full-screen photo to the sides of the screen, eliminating black bars and aspect ratio distortion.

## SmartContrast

SmartContrast is Philips technology that analyses the contents you are displaying, automatically adjusting colours and controlling backlight intensity to dynamically enhance contrast for the best digital images and optimum contrast for more entertainment fun when viewing videos or playing games where dark hues are displayed; when you select the Economy mode, contrast is adjusted and backlighting fine-tuned for just-right display of everyday office applications and lower power consumption.

## SmartPower

A timer turns PhotoFrame on and off at the hours you select, reducing energy consumption for the sake of our environment saving up to one third of your PhotoFrame energy costs. Three programmable weekday timeslots along with one weekend timeslot give you flexibility to fit your personal schedule.

## Viewing photos in USB flash

A USB connector for easy viewing and sharing of photos stored on USB flash drive.



Issue date 2009-03-09

Version: 2.0.7

12 NC: 8670 000 39107  
EAN: 87 12581 41302 6

© 2009 Koninklijke Philips Electronics N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

[www.philips.com](http://www.philips.com)