



Philips  
PhotoFrame

7"

7FF1CWO



## Every picture tells your story

How many digital pictures are hidden on your PC? See, share and relive your memories with Philips PhotoFrame™, the easiest way to display your digital photos in stunning quality — without a PC.

### Top-quality display for print-like pictures

- High pixel density for sharp and detailed photo display
- Display all the crisp colours of professional printed photos

### Luxurious design to complement your photos

- Exquisite materials and finishing add value to your photos
- Elegant look — your choice of landscape or portrait display

### Easily display your digital photos

- View photos directly from memory cards - no PC required
- USB connector for easy photo downloading from your PC
- Create a slideshow for all stored photos
- Play slideshows, single photo, thumbnails or show clock

### Great convenience

- Operate on AC power or cordlessly with rechargeable battery
- Automatically turn the display on and off at preset times daily

**PHILIPS**  
sense and simplicity

## Specifications

### Picture/Display

- **Effective viewing area:** 137 x 91 mm
- **Resolution:** 800 x 480 pixels (viewing area 720 x 480)
- **Viewing angle:** @ C/R > 5, 170° (H)/170° (V)
- **Lifetime, to 50% brightness:** 20,000 hr
- **Brightness:** 200 cd/m<sup>2</sup>

### Connectivity

- **USB:** To PC

### Storage Media

- **Memory Card Types:** Compact Flash type I, Memory Stick, Memory Stick Pro, Multimedia Card, Secure Digital (SD)
- **Built-in memory capacity:** 50 photos or more

### Convenience

- **Card Reader:** Built in (2 x)
- **Photo format supported:** JPEG photo (in DCF structure), Up to 12 Megapixels
- **Placement supported:** Landscape, Portrait
- **Buttons and controls:** 6 buttons
- **Playback mode:** Full screen browse, Slideshow, Thumbnail browse
- **Photo edit:** Copy, Delete, Rotate, Show in slideshow
- **Setup function:** Brightness adjustment, Language, Slideshow, Status, Auto on/off daily
- **OSD Languages:** English, French, German, Italian,

- Japanese, Russian, Simplified Chinese, Spanish
- **Plug & Play Compatibility:** Windows 2000/XP or later
- **Regulatory Approvals:** BSMI, C-Tick, CCC, CE, FCC, GOST, PSB, UL, VCCI
- **Other convenience:** Kensington lock compatible

### Accessories

- **Included Accessories:** AC-DC Adapter, User manual & PC software CD, Quick start guide, Stand, USB cable
- **Optional accessories:** Exchangeable frames

### Dimensions

- **Set dimensions with stand (W x H x D):** 212 x 164 x 105 mm
- **Weight:** 0.73 kg
- **Temperature range (operation):** 0°C to 45°C
- **Temperature range (storage):** -20°C to 60°C

### Electricity

- **Power consumption:** (System on and battery charging) 12 W
- **Operating time on battery:** 0.8 hr
- **Battery LED indicator:** Charging - Amber, Not charging - Off
- **Power LED indicator:** Operation - green
- **Power mode supported:** AC powered, Battery powered

## Product highlights

### High pixel density display

The very best high-density screen in the industry displays 88% more pixels per square inch than even a high-end 17-inch LCD monitor – showing off your treasured photos with the same 'real life' rich detail and vibrant colours as high-quality prints.

### Rich, vibrant colours

Full colour display brings out the best in your photos with vibrant, real-life colours by displaying the same full range of colours found in professionally printed photos.

### Quality design and materials

High-quality design and exquisite materials include a solid stylish stand, designer frame and detailed finishing that convey an impression of value and refined taste, adding lustre to the photos displayed in PhotoFrame.

### Elegant table-top design

Decor enhancing design combines form and function in an elegant, eye-catching package that complements refined, stylish home decor — whether you're displaying your photos in landscape or portrait orientation.

### Memory card slots

Two memory card readers are built in for easy viewing and sharing of photos stored on memory cards. One memory card slot accepts Compact Flash I (CF) cards while the second accommodates Memory Stick (MS), SD Card and Multi Media Cards (MMC).

### Easy USB connectivity

A USB connector is built into the device for easy and quick downloading of photos from a PC.

### Create slideshows

A slideshow is a collection of images arranged in sequence for presenting to an audience. Pressing the button and selecting the slideshow function automatically displays all photos stored on your PhotoFrame page by page.

### Multiple viewing modes

Flexible display modes give you the freedom to display your photos one image at a time in thumbnail mode for quick, easy searches, or to create a slideshow of your most treasured photos.

### Runs on built-in battery or AC

AC and onboard battery power give you the choice of operating your PhotoFrame on standard AC power or cordlessly with the onboard rechargeable battery.

### On-off timer

A built-in clock turns your PhotoFrame™ on or off at times you select.

