



Philips
HiFi Stereo Headphone

SHP805



HiFi

Large speaker driver

When you're looking for a comfortable HiFi stereo headphone, the SHP 805 is a perfect choice. Its large 40 mm diameter speaker driver delivers impressive sound quality for a personal listening experience that brings your music to life.

The perfect listening experience

- 40mm speaker driver delivers sound without distortion

You'll forget you're wearing them!

- Ergonomic cushions improve wearing comfort and bass
- Easy adjustable headband ensures optimum fit and comfort

Always ready

- The 3m-long cable is ideal for use with headsets
- Single-sided cable reduces tangling and improves comfort

PHILIPS
sense and simplicity

Specifications

Sound

- **Acoustic system:** Open
- **Diaphragm:** Mylar dome
- **Frequency response:** 10 - 28 000 Hz
- **Magnet type:** Ferrite
- **Maximum power input:** 1500 mW
- **Speaker diameter:** 40
- **Voice coil:** CCAW
- **Sensitivity:** 104
- **Impedance:** 32
- **Type:** Neodymium

Connectivity

- **Cable Connection:** One-sided
- **Cable length:** 3 m
- **Connector:** 3.5 & 6.3 mm stereo
- **Finishing of connector:** 24k Gold-plated
- **Type of cable:** OFC
- **Detachable cable:** N

Accessories

- **Adaptor plug:** 3.5-6.3 mm

Product highlights

40 mm speaker driver

The 40 mm speaker driver is made of a composite mylar material for a highly sensitive yet powerful element that delivers sound without audible distortion.

Ergonomically shaped cushions

The ergonomic earcushion shape and luxurious materials ensure a more comfortable fit and better bass performance thanks to reduced audio leakage.

Easy adjustable headband

The easily adjustable mechanism provides a comfortable close fitting acoustic seal between the ear cushion and ear, ensuring optimal performance.

3m cable

A handy cable length to make it easier for you to move freely around while using your headphones.

Single-sided cable

The cable is conveniently connected to just one side, considerably reducing the risk of tangling and simplifying winding the cable up for storage.



Issue date 2008-04-12

Version: 1.0.3

12 NC: 9082 100 03926
EAN: 87 10895 86650 7

© 2008 Koninklijke Philips Electronics N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips
Electronics N.V. or their respective owners.

www.philips.com