

Philips  
CD Soundmachine

**MP3-CD**

Tape  
Digital tuning

**AZ3068**



## Great portable sound

Uncomplicated yet comprehensive, this rugged player delivers superb sound performance with quality 2-way speakers. Enjoy your favorite MP3 or WMA-CD, 30 preset FM stations on the digital tuner in enriched sound - anytime, anywhere.

### **The ultimate listening experience**

- Autostop cassette deck
- Digital tuning with preset stations for extra convenience
- 10 hours of MP3-CD or 20 hours of WMA-CD music

### **Powerful bass you can hear and feel**

- 2-step Dynamic Bass Boost for a deeper bass experience
- 10.2 cm (4") full range speakers for powerful sound
- Bass Reflex Speaker System delivers a powerful, deeper bass

### **Easy to use**

- Handy remote control
- Line-in connection
- Stereo headphone socket

# PHILIPS

# Specifications

## Sound

- Sound system: stereo
- Volume control: rotary (digital)
- Sound enhancement: Dynamic Bass Boost 2 steps
- Output power: 2 x 4 W (mains power) / 2 x 2 W (battery)

## Loudspeakers

- No. of built-in speakers: 2
- Loudspeaker enhancement: 2-way bass reflex speaker
- Speaker grille finishing: metal

## Audio playback

- Playback media: CD, CD-R, CD-RW, MP3-CD, WMA-CD
- Disc playback modes: fast forward/backward, next/previous track search, repeat/shuffle/program
- Number of decks: 1
- Cassette deck technology: mechanical

## Audio recording

- Recording media: tape
- Tape recording enhancement: CD synchro start recording

## Tuner/Reception/Transmission

- Station presets: 30
- Antenna: FM antenna
- Tuner bands: FM, MW
- Tuner enhancement: auto digital tuning

## Connectivity

- Audio/Video output: Headphone (3.5mm)
- MP3 Link: 3.5mm stereo line in

## Convenience

- Loader type: top
- Display type: LCD display

## Accessories

- Cables/Connection: power cord
- Remote control: 20-key with lithium battery
- Others: User Manual
- Warranty: Warranty Certificate

## Power

- Battery type: D size (LR20)
- Battery voltage: 1.5 V
- Number of batteries: 6
- Power type: AC Input

## Dimensions

- Gross weight: 4.4 kg
- Packaging depth: 314 mm
- Packaging height: 210 mm
- Packaging width: 493 mm
- Weight: 3.3 kg
- Main unit depth: 263 mm
- Main unit height: 174 mm
- Main unit width: 435 mm

# Highlights

## Handy remote control

Handy remote control

## Line-in connection

Line-in connection

## 2-step Dynamic Bass Boost

2-step Dynamic Bass Boost for a deeper bass experience

## Bass Reflex Speaker System

Bass Reflex Speaker System delivers a deep bass experience from a compact loudspeaker box system. It differs from a conventional loudspeaker box system in the addition of a bass pipe that is acoustically aligned to the woofer to optimize the low frequency roll-off of the system. The result is deeper controlled bass and lower distortion. The system works by resonating the air mass in the bass pipe to vibrate like a conventional woofer. Combined with the response of the woofer, the system extends the overall low frequency sounds to create a whole new dimension of deep bass.

## MP3-CD or WMA-CD playback

MP3 is a revolutionary compression technology by which large digital music files can be made up to 10 times smaller without radically degrading their audio quality. A single CD can store up to 10 hrs of music. MP3 has become the standard audio compression format, allowing quick and easy audio file transfer. Windows Media Audio (WMA) is a highly compressed digital audio format from Microsoft that delivers great sound with music files that take up half the disk space and download in half the time. A single CD can store up to 20 hours of good quality WMA music recorded at a bit rate of 64 Kbps.



Issue date 2014-02-06

Version: 1.0.6

12 NC: 9073 101 02578  
EAN: 87 10895 95976 6

© 2014 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)