

Philips
CD Soundmachine with
Dynamic Bass Boost



AZ1031



Program your favourite music

You take pleasure in the simple things in life and delight in convenience. The sleek and portable AZ1031 lets you indulge in the pleasures of enjoying your favourite music with the help of easy-to-use functions.

Enjoy favourite music from three different sources

- Player compatible with CD-Recordable and CD-ReWritable
- FM/MW stereo tuner
- Autostop stereo cassette deck

Enhanced bass performance

- Dynamic Bass Boost for deep and dramatic bass

Easy to use

- CD to tape synchro-start recording
- Multi-functional LCD display
- Stereo headphone socket

PHILIPS
sense and simplicity

Specifications

Audio Playback

- **Loader Type:** Top
- **Playback Media:** CD, CD-R, CD-RW
- **Programmable Tracks:** 20
- **Disc Playback Modes:** Fast Forward/Backward, Next/Previous Track Search, Repeat Play
- **Cassette Deck Technology:** Mechanical
- **Number of decks:** 1

Audio Recording

- **Recording Media:** Tape
- **Tape Recording Enhancement:** CD Synchro Start Recording

Tuner/Reception/Transmission

- **Tuner Bands:** FM, MW
- **Antenna:** FM Antenna

Sound

- **Output power (RMS):** 2X1.2W
- **Sound Enhancement:** Dynamic Bass Boost
- **Sound System:** Stereo
- **Speaker diameter:** 3"
- **Volume Control:** rotary

Convenience

- **Display Type:** LCD
- **Display Digits:** 2

Connectivity

- **Headphone:** 3.5 mm

Power

- **Battery type:** LR14
- **Battery voltage:** 1.5 V
- **Mains power**
- **Number of batteries:** 6

Accessories

- **Included Accessories:** AC Power Cord, User Manual, Warranty certificate

Dimensions

- **Packaging dimensions (W x H x D):** 324 x 190 x 271 mm
- **Product dimensions (W x H x D):** 290 x 150 x 212 mm
- **Weight incl. Packaging:** 2.7 kg
- **Product weight:** 2 kg

Product highlights

CD-Rewritable Compatible

CD-Rewritable Compatible means that your audio set can play both CD-Recordable (CD-R) and CD-Rewritable (CD-RW) discs. CD-R discs are recordable once and can be played on any audio CD player while CD-RW discs can be recorded and rewritten multiple times and can only be played back on compatible audio CD players. The laser pick-up and CD decoder circuitry of CD-RW compatible players are specially designed to read the special audio CD-RW phase-change recording layer, ensuring you can always play your home-recorded discs on your audio CD system.

FM/MW stereo tuner

Autostop stereo cassette deck

Dynamic Bass Boost

Dynamic Bass Boost maximizes your music enjoyment by emphasizing the bass content of the music throughout the range of volume settings - from low to high - at the touch of a button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.

CD synchro-start recording

Multi-functional LCD display

Stereo headphone socket



Issue date 2007-12-06

Version: 1.0

12 NC: 9073 101 02244
EAN: 87 10895 91849 7

© 2007 Koninklijke Philips Electronics N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

www.philips.com