

Philips
DVD home theater system

LX3700D

# The full cinematic sound experience

This compact full digital home entertainment system plays practically any disc in high quality Dolby or dts surround sound. So, relax and enjoy the full cinematic experience in your own personal environment.

# Superb audio and video performance

- · Dolby Digital for movies or concerts in full surround sound
- DTS Digital Surround for multi-channel surround sound
- Dolby Pro Logic II for surround sound from stereo sources
- Class 'D' digital amplifier for quality sound performance
- Progressive Scan component video for optimized image quality

# Plays practically any disc format

- Movies: DVD, DVD+R/RW, DVD-R/RW, (S)VCD
- Music: CD, CD-R/RW and MP3-CD
- $\bullet$  Picture CD (JPEG) with music (MP3) playback

# Quick and easy set-up

- Easy set-up to initialize your total home entertainment
- Easy-fit<sup>™</sup> connectors with color-coding for a simple set-up



# Specifications

# Picture/Display

- Aspect ratio: 4:3, 16:9 • D/A converter: 10 bit
- Sound
- D/A converter: 24 bit, 96 kHz
- Equalizer settings: Action, Classic, Concert, Digital, Drama, Jazz, Rock, Sci-Fi
- Frequency response: 30-20000 Hz
- Signal to noise ratio: >60 dB
- Sound System: Dolby Digital (AC-3), Dolby Prologic II, DTS, MPEG2
- Total Sound Power (RMS): 300 W

# Loudspeakers

- Satellite Speaker: Magnetically shielded front
- Satellite speaker freq range: 120-20000 Hz
- · Satellite speaker impedance: 4 ohm
- Satellite speaker drivers: 3/4" tweeter, 2x 2" mid range woofers
- · Center Speaker: 2 way
- Center freq range: 120-20000 Hz
- Center speaker drivers: 1.75" tweeter, 2x 2" mid range woofers
- Subwoofer freq range: 30-120 Hz
- · Subwoofer impedance: 8 ohm
- Subwoofer driver: 6.5" high efficiency woofer

# Video Playback

- Compression formats: MPEG1, MPEG2
- Playback Media: DVD+RW, DVD+R, DVD-RW (Video mode), DVD-R, DVD-Video, SVCD, Video
- Disc Playback Modes: A-B Repeat, Repeat
- · Loader Type: Tray
- Number of Discs: 1
- · Video disc playback system: NTSC, PAL

# **Audio Playback**

· Compression format: Dolby Digital, DTS, MP3, PCM

- Playback Media: CD, CD-R, CD-RW, MP3-CD
- Disc Playback Modes: Fast Forward/Backward, Next/Previous Album Search, Next/Previous Track Search, Repeat one/album/all, Shuffle Play
- MP3 bit rates: 32-256 kbps and VBR

# **Still Picture Playback**

- Playback Media: Picture CD
- Picture Compression Format: IPEG
- Slide show: with music (MP3)

# Tuner/Reception/Transmission

- · Auto digital tuning
- Auto store
- Number of Preset Channels: 20
- Tuner Bands: FM Stereo, MW

# **Connectivity**

· Other connections: Analog audio Left/Right in, Composite video (CVBS) out, Digital coaxial in, Digital coaxial out, Digital optical out, FM Antenna, Line out, MW Antenna, S-Video out, Subwoofer

# **Convenience**

- Child Protection: Parental Control
- Display Type: FTD, On Screen (OSD)
- Remote Control: Multi-functional

# **Accessories**

- Included accessories: 1x center speaker, 1x subwoofer, 2x front satellite speakers, 2x rear satellite speakers, AC Power Cord, Audio Cable, FM/MW Antenna, Quick Use Guide, Remote Control, User Manual, Video Cable, Warranty certificate
- · Included batteries: 2x Longlife AA

- Power supply: 110-240V, 50/60 Hz
- Standby power consumption: < 1 W











Issue date 2014-02-10

Version: 2.0.4

12 NC: 9073 100 11222 EAN: 87 10895 74221 4 © 2014 Koninklijke Philips N.V. All Rights reserved.

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

www.philips.com

# Highlights

# **Dolby Digital Surround**

Because Dolby Digital and DTS, the world's leading digital multi-channel audio standards, make use of the way the human ear naturally processes sound, you experience superb quality surround sound audio with realistic spatial cues.

# **DTS Digital Surround**

DTS delivers superior surround sound with your DVD movies.

# **Dolby Pro Logic II Surround**

Dolby Pro Logic II is an advanced matrix decoder that derives five channels of surround sound, including two full-range surround channels, from any stereo source.

# Class 'D' Amplifier

Class 'D' Digital Amplifier takes an analog signal, converts it into a digital signal and then amplifies the signal digitally. The signal then enters a demodulation filter to give the final output. The amplified digital output delivers all the advantages of digital audio, including improved sound quality. In addition, Class 'D' Digital Amplifier has greater than 90% efficiency compared to traditional AB amplifiers. This high efficiency translates into a powerful amplifier with a small footprint.

# **Progressive Scan**

Progressive Scan doubles the vertical resolution of the image resulting in a noticeably sharper picture. Instead of sending a field comprising the odd lines to the screen first, followed by the field with the even lines, both fields are written at one time. A full image is created instantaneously, using the maximum resolution. At such a speed, your eye perceives a sharper picture with no line structure.

# **Multi-format Movies**

Multi-format playability allows you to play most disc formats for maximum disc compatibility and viewing pleasure.

# **Multi-format Music**

Multi-format playability allows you to play most disc formats for maximum disc compatibility and listening

Picture CD with MP3 Playback
Picture CD is a CD-R or CD-RW disc on which you can store your MP3 and digital pictures. When inserting a Picture CD in the DVD player, a screen menu will pop up, showing your JPEG's and/or MP3 files on the disc. Just select the music and pictures files you wish to enjoy and press play or OK. You can watch your pictures on TV with your music playing simultaneously.

# **Quick Start Guide**

To guide you through the initial set-up of your system, Philips delivers a Quick Start Guide that uses an easy approach with clearly defined graphics and colors to guide you through the basic steps of connection and obtaining picture and sound. These basic steps are clearly described on one page in the packaging box, making setup quick and simple.

# Easy-fit™ connectors

Color-coded connectors provide a simple and userfriendly solution to connect the speakers and subwoofer to the center unit of the home entertainment system simply by plugging the connectors in the matching colored interface at the rear of the center unit.