



Philips  
Universal remote control

6in1

SRU5060



# Full replacement remote

Operates more than 1000 brands

A truly excellent universal remote control that gives you complete control over up to six devices from most brands. It has dedicated menu keys and learns codes from your old remote.

## **Ideal replacement for your old remote**

- 6-in-1 remote for your TV, DVD, STB, AMP, VCR and CD
- Convenient IR learning from another remote
- Ready for use with Philips equipment

## **Great convenience**

- Eye-catching chrome finish
- Dedicated keys for moving around menus
- A light indicates current active device mode
- Battery low indication shows when to refresh batteries

## **Quick and easy set-up**

- Automatically searches for your equipment brand
- Batteries are included for unwrap-and-zap
- For questions and assistance call our URC service line
- URC support service via dedicated website

# PHILIPS

# Specifications

## Convenience

- Supported devices: TV, VCR, DVD, SAT, CABLE, CD/MD, RECEIVER, AMP
- TV functions: Program up/down, Volume up/down, mute, Power/standby, Digit keys, AV selection, external, Menu control, Color/Brightness control, Teletext keys, Fast text keys, Previous program, Sleep/timer, 16:9, Guide, info
- Teletext enhancements: Fast text
- DVD functions: Transport keys, System menu control, Disc menu control, Digit keys
- VCR functions: Transport keys (6), Showview, VCR plus, Menu control
- SAT/CBL functions: Digit keys, Menu control, Guide, info, Favourites, Text functions
- Ease of Installation: Autosearch
- Installation steps: 2
- Copy key function
- Language support: GB/I/E/P/GR/RU/CZ/PL
- Number of keys: 40
- Preprogrammed for Philips
- Regulatory approvals: CE Mark
- Splash proof

## Accessories

- Battery: Yes, 1.5V Battery R03/AAA

## Infrared Capabilities

- Operating distance: 33 ft (10 m)

- Transmitting LEDs: 1
- Universal IR code database
- Number of brands in database: Over 1100
- Carrier frequency range: 24 - 55 kHz
- Transmission angle: 90 degree
- Learning IR codes
- Learning frequency range: 20 kHz to 70 kHz and 455 kHz

## Power

- Battery lifetime: 12 Months
- Number of batteries: 2
- Battery type: AAA

## Outer Carton

- Quantity: 6
- EAN/UPC/GTIN: 87 10895 93608 8
- Height: 172 mm
- Length: 312 mm
- Width: 151 mm

## Packaging Data

- 12NC: 908210006488
- EAN/UPC/GTIN: 87 10895 93607 1
- Length: 304 mm
- Height: 33 mm
- Width: 157 mm

# Highlights

## 6-in-1 remote control

Replace a table full of remote controls with one robust unit that'll operate your TV, DVD player/recorder, satellite receiver, digital terrestrial receiver or cable set-top box (STB), amplifier/receiver and CD player regardless of the brand or model.

## Learning functionality

Learning functionality refers to the process through which a remote control captures and stores infrared signals from other remotes for later use. When device codes are not included in the on-board database, they can always be learned from the original remote, simply by pointing to it.

## Pre-programmed for Philips

If you have Philips equipment, you can use your universal remote control without programming it because all keys are pre-set for Philips.

## Chrome finish

Stylish chrome finish that looks good and complements the latest equipment design.

## Dedicated menu keys

Dedicated keys to move easily around your equipment's menus mean simple one finger operation without having to press shift or function shift keys

## Device mode indicator

Small lights keep you informed about which device mode is currently active.

## Battery-low indication

To know in time when the batteries need to be recharged or replaced.

## Auto brand search

Getting your new remote control working is simply a case of having your remote automatically search for the most suitable code for your equipment.



Issue date 2014-02-06

Version: 1.0.6

12 NC: 9082 100 06488  
EAN: 87 10895 93607 1

© 2014 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)