



In-ear headphones with mic

- Three-way hybrid
- acoustic architecture
- High resolution audio

S3/00

## Superb in-ear sound

Wherever you go

These audiophile-grade in-ear headphones match a spacious, natural soundstage with exceptional comfort and fit. Twisted-pair cables and included MMCX connectors let every glorious detail shine through when you connect your hi-res player.

### Benefits

#### Immersive full-range sound

- Spacious, natural soundstage
- 6 mm dynamic bass driver. Dual balanced-armature drivers
- Balanced midrange. Impeccably detailed high frequencies
- Tight, impactful bass

#### Crafted to reveal more detail

- Perfect seal, perfect fit
- Beautiful design. Carry pouch included
- Comply™ memory foam ear-tip covers in S, M, and L

- Secure ear-hook design keeps the earphones in place

#### Immerse in any source

- Hi-Res Audio. Hear every detail
- Connect to any source. From phone to headphone amp
- In-line remote. For music and calls
- Removable twisted-pair cables. MMCX and 3.5 mm adapters

**PHILIPS**

## Features

### Spacious, natural soundstage

Get ready for an immersive in-ear musical experience. The 6 mm dynamic driver is dedicated to delivering tight, impactful bass. Dual balanced-armature drivers create a balanced midrange and impeccably detailed high frequencies.

### Perfect fit

An oval acoustic tube and three sizes of Comply memory foam ear-tip covers create a perfect seal. You'll enjoy every subtle detail in your music, even when listening in noisier environments. The ear-hook design keeps the headphones in place.

### Hear every detail

These headphones let you feel the full impact of every note. When wired to a high-resolution source, you'll get the full benefit of lossless audio-for a performance that's as close to the original recording as possible.

### Connect to any source

Immerse in your favorite albums-however you like to listen. The detachable, low-impedance twisted-pair cables minimize distortion, revealing more detail in your music. MMCX connectors are included for connection to high-resolution audio devices.

### Carry pouch included

The high-quality metal ear housing is finished to an attractive sheen, and bears the Fidelio logo embossed in metallic letters. The included carry pouch helps to protect against scratches when not in use.

### In-line remote

Take a call without missing a beat. The in-line remote with mic lets you control music playback, and take calls in crystal-clear sound.

## Specifications

[field not found 'disclaimer\_text']

### Design

Color Black

### Sound

Speaker diameter 6 mm  
Acoustic system Semi-closed  
Frequency response 5-40000 Hz  
Impedance 16 ohm  
Sensitivity 107 dB/mW

### Accessories

Storage pouch Yes

### Connectivity

Cable Connection 1.3 m cable with 3.5 mm connectors  
Compatible with: iPhone®, BlackBerry®, HTC, LG, MOTOROLA, Sony, Nokia\*, SAMSUNG\*. \*Extra connector available through customer support for Sony Ericsson, older models from NOKIA and SAMSUNG

### Packaging dimensions

Width 15.8 cm

Height 22.8 cm  
Depth 5 cm  
Nett weight 0.058 kg  
Gross weight 0.342 kg  
Tare weight 0.284 kg  
EAN 48 95229 10838 7  
Number of products included 1  
Packaging type Carton  
Type of shelf placement Both

### Outer Carton

Length 17 cm  
Width 11.1 cm  
Height 21.9 cm  
Nett weight 0.116 kg  
Gross weight 0.765 kg  
Tare weight 0.649 kg  
GTIN 1 48 95229 10838 4  
Number of consumer packagings 2



data subject to change  
2023, June 18

Version: 1.1.4  
EAN: 4895229108387

© 2023 Koninklijke Philips N.V.  
All rights reserved.

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

[www.philips.com](http://www.philips.com)