



Philips  
Webcam

VGA  
CMOS

SPC710NC



# Boost your video chat experience

With face-tracking and digital zoom

When you want to stay in touch with your friends and family, nothing beats this webcam. It guarantees you truly excellent, high resolution images. The special face-tracking feature and 5x digital zoom will make you feel like you're on TV.

#### Superb video chatting experience

- Add top-quality video and speech to calls
- Face tracking automatically follows your face
- Rotating lens for perfect aiming and natural images
- Built-in digital microphone for quality sound

#### Enhanced image quality

- Smooth image with 30 frames per second video
- Super VGA resolution for high-quality images
- Precision glass lens offers sharper image quality

#### Perfectly user-friendly

- 5x digital zoom for superb close-ups
- Stable mount on any monitor, laptop or desk
- Create V-mails and control your webcam with VLounge Premium
- VLounge QuickLaunch button for instant operation
- Compatible with MSN, Skype and other free messaging services

**PHILIPS**  
sense and simplicity

# Highlights

## Add top-quality video

The webcam has been designed to add video to your Internet calls so you can see as well as hear your friends and family online. It works easily and instantly and is entirely future-proof!

## Automatic face tracking

The state-of-the-art camera software automatically detects your face and moves the lens to follow you as you move. You stay in the centre of the image even if you move during a video conference. It gives you the freedom to express yourself and converse naturally.

## Rotating lens

Rotating lens for perfect aiming and natural images. You can get the right camera angle quickly and easily without having to put things underneath it to change the tilt.

## Built-in digital microphone

The built-in digital microphone allows you to talk naturally and freely or to add sound to a video clip recording.

## 30 frames per second video

Sit back and enjoy superior viewing with 30 frames per second video. This gives you smoother video images and a better all-round video chatting experience.

## Super VGA resolution

The webcam captures Video Graphics Array (VGA) quality (640x480) snapshots and flicker-free video clips for video mails. With VGA resolution, your webcam becomes a professional-level camera. Add high-quality photos to documents, webpages and e-mails in an instant, or print out photo-quality images.

## Precision glass lens

Sharp, crisp and clear. Precision glass lens guarantees you high image quality for all applications - from snapshot to video messaging. The finished lenses are coated with a special film to extend their working life and protect them from wear and tear and dust accumulation.

## 5x digital zoom

Zoom in and out to get the perfect framing for any image. You control the zoom entirely via the on-screen interface while you are looking at the image so you can adjust it perfectly.

## Stable mount

The multifunctional stand makes it easy for you to mount the webcam on any monitor, laptop, notebook or flat surface.

## VLounge Premium

Create and send V-mails in seconds. VLounge is sophisticated software for capturing, managing and archiving snapshots and video clips with just a couple of mouse clicks. You can also use it to operate face tracking and digital zoom for maximum control.

## VLounge QuickLaunch button

To start up the VLounge application, simply press the QuickLaunch button

## Compatible with MSN and Skype

The webcam and its software have been designed with all messaging systems in mind. Add video to Skype, MSN Messenger, Yahoo!, AOL Messenger and other free messaging services. It also works with Windows Messenger and NetMeeting for multi-person video conferencing and is designed to be future-proof.

# Specifications

## Video & snapshot capturing

- Sensor: CMOS
- Sensor resolution: VGA
- Video resolution: VGA
- Snapshot resolution: VGA
- Interpolated snapshot res.: SVGA
- Max. frame rate: 30 fps
- Lens: F2.8, D50°
- White balance: 2600 – 7600 K
- Min. illuminance: < 5 lux
- Colour depth: 24 bit

## Mechanics

- Laptop clamp
- LCD clamp
- CRT stand
- Desktop stand
- Built-in digital microphone
- QuickLaunch button
- Snapshot button

## Accessories

- Included Accessories: Quick install guide, User Manual

## Software

- VLounge: Premium
- Add video to: MSN Messenger, Yahoo! Messenger, AOL Messenger, Skype

## System Requirements

- Operating System: Microsoft Windows 98, Microsoft Windows ME, Microsoft Windows 2000, Microsoft Windows XP
- Processor: Pentium II 500 MHz or faster
- RAM memory: 128 MB RAM
- Sound card
- USB: Free USB port
- Internet connection
- Hard disk space: 200 MB
- CD-ROM or DVD-ROM Drive

## Connectivity

- Cable length: 2.1 m
- PC Link: USB 1.1

## Dimensions

- Product dimensions (W x H x D): 74 x 142 x 74 mm
- Product weight (g): 110

## Packaging Data

- 12NC: 908210008637
- EAN/UPC/GTIN: 87 10895 97714 2
- Gross weight: 0.435 kg
- Height: 230 mm
- Length: 190 mm
- Width: 90 mm
- Quantity: 1
- Tare weight: 0.325 kg

## Outer Box

- EAN/UPC/GTIN: 87 10895 97986 3
- Quantity: 6
- Gross weight: 3.210 kg
- Tare weight: 2.550 kg
- Length: 387 mm
- Width: 285 mm
- Height: 248 mm



Issue date 2009-05-31

Version: 2.0.5

12 NC: 9082 100 08637  
EAN: 87 10895 97714 2

© 2009 Koninklijke Philips Electronics N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

[www.philips.com](http://www.philips.com)