

Philips  
VCD Mini Hi-Fi System



FWV182

## Video CD and MP3-CD Playback

Savor the magic of movies and music on the FWV182 with VCD and MP3-CD playback or to be a Karaoke Star. Enjoy music powerfully enhanced by Dynamic Bass Boost and 1000W PMPO.

### Enrich your sound experience

- 2x25W RMS/1000W PMPO
- Full range Bass Reflex Speaker System

### Longer listening, greater enjoyment

- 10 hours of MP3-CD music
- Stereo cassette deck
- AM/ FM tuner for radio enjoyment
- VCD2.0 playback

### Personalized sound settings

- Dynamic Bass Boost for deep and dramatic sound

### Be a singing sensation

- Karaoke for endless singing entertainment

**PHILIPS**  
sense and simplicity

# Specifications

## Sound

- Output Power: 2x25 W RMS / 1000W PMPO
- Sound Enhancement: Dynamic Bass Boost

## Loudspeakers

- Main Speaker: 4" woofer, Full range, Bass Reflex Speaker System

## Video Playback

- Playback Media: Video CD, SVCD
- Loader Type: Motorised
- Number of Discs: 1
- Disc Playback Modes: A-B Repeat, PBC, Search forward/reverse
- Video disc playback system: NTSC, PAL

## Audio Playback

- Playback Media: CD, CD-R, CD-RW, MP3-CD
- Disc Playback Modes: Repeat/Shuffle/Program
- Programmable Tracks: 40
- Cassette Deck Technology: Mechanical
- Number of decks: 1
- Cassette Playback Modes: Automatic Stop

## Audio Recording

- Recording Media: Tape
- Tape Recording Enhancement: CD Synchro Start Recording

## Tuner/Reception/Transmission

- Auto digital tuning: No
- Tuner Bands: FM Stereo, MW

## Connectivity

- Aux in: Line in
- Headphone: 3.5 mm
- Microphone: Microphone socket
- Other connections: Composite video (CVBS) out, MW Antenna

## Convenience

- Alarms: CD Alarm, Radio Alarm, Sleep timer
- Clock: On main display
- Display Type: LCD
- Karaoke: MIC volume

## Accessories

- Included accessories: AM antenna, Video Cable
- Remote control: 42-key
- User Manual: English, Simplified Chinese
- Guarantee booklet: Global version

## Dimensions

- Set dimensions (W x H x D): 265 x 310 x 384 mm
- Main speaker dimensions (W x H x D): 207 x 310 x 190 mm
- Packaging dimensions (W x H x D): 567 x 413 x 460 mm
- Weight incl. Packaging: 13.5 kg

## Power

- Power supply: 100-240VAC, 50/60Hz

# Highlights

## 2x25W RMS/1000W PMPO

2x25W RMS/1000W PMPO

## Full range Bass Reflex Speaker

Bass Reflex Speakers delivers a deep bass experience. Differ from conventional loudspeakers, the addition of a bass pipe that is acoustically aligned to the woofer optimizes the low frequency roll-off. The result is a deep controlled bass and low distortion. Combined with the response of the woofer, it extends the overall low frequency sounds to create a whole new dimension of deep bass.

## 10 hours of MP3-CD music

MP3 stands for "MPEG 1 Audio layer-3".MP3 is a revolutionary compression technology by which large digital music files can be made up to 10 times smaller without radically degrading their audio quality. MP3 has become the standard audio compression format used on the world wide web, allowing quick and easy audio file transfer.

## Stereo cassette deck

Stereo cassette deck

## AM/ FM tuner

AM/ FM tuner for radio enjoyment

## VCD2.0 playback

VCD2.0 playback

## Dynamic Bass Boost

Dynamic Bass Boost maximizes your music enjoyment by emphasizing the bass content of the music throughout the range of volume settings - from low to high - at the touch of a button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.

## Karaoke

The Karaoke feature on your DVD player provides endless entertainment and maximum audio and singing enjoyment. You can enhance your performance by adding an 'echo' effect to your voice. The key controls allows you to choose the optimal key for your personal vocal range.



Issue date 2011-04-09

Version: 2.0.5

12 NC: 9073 100 12983  
EAN: 87 10895 92114 5

© 2011 Koninklijke Philips Electronics N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

[www.philips.com](http://www.philips.com)