



#### CD Soundmachine

- Bluetooth® and NFC
- USB Direct
- 12W

AZ700T/98

## Enjoy powerful music wirelessly wherever you go

The Philips Portable CD Sound Machine is a powerful sound system you can take with you everywhere. It frees your music with wireless One-Touch NFC connectivity for effortless Bluetooth pairing. Or play back your tunes on USB, CD and MP3-CD.

### Benefits

#### Enjoy your music from different sources

- Stream music wirelessly via Bluetooth™ from your smartphone
- USB Direct for MP3 music playback
- Play MP3-CD, CD and CD-R/RW
- More music with Digital FM radio with 20 stations preset

#### Easy to use

- One-Touch with NFC-enabled smartphones for Bluetooth pairing
- CD Shuffle/Repeat for personalized music enjoyment

- 20-track CD programmable
- Handy remote control for extra convenience
- Stereo headphone jack for better personal music enjoyment

#### Powerful sound you can hear and feel

- Bass Reflex Speaker System delivers a powerful, deeper bass
- Dynamic Bass Boost for deep and dramatic sound

**PHILIPS**

## Features

### Stream music via Bluetooth™



Bluetooth is a short range wireless communication technology that is both robust and energy-efficient. The technology allows easy wireless connection to iPod/iPhone/iPad or other Bluetooth devices, such as smartphones, tablets or even laptops. So you can enjoy your favorite music, sound from video or game wireless on this speaker easily.

### NFC technology



Pair Bluetooth devices easily with one-touch NFC (Near Field Communications) technology. Just tap the NFC enabled smartphone or tablet on the NFC area of a speaker to turn the speaker on, start Bluetooth pairing, and begin streaming music.

### USB Direct for MP3 music

### Bass Reflex Speaker System



Bass Reflex Speaker System delivers a deep bass experience from a compact loudspeaker box system. It differs from a conventional loudspeaker box system in the addition of a bass pipe that is acoustically aligned to the woofer to optimize the low frequency roll-off of the system. The result is deeper controlled bass and lower distortion. The system works by resonating the air mass in the bass pipe to vibrate like a conventional woofer. Combined with the response of the woofer, the system extends the overall low frequency sounds to create a whole new dimension of deep bass.

### Handy remote control



With a handy remote control for greater convenience at your fingertips, all you have to do is sit back and relax.

## Specifications

[field not found 'disclaimer\_text']

### Audio playback

Playback media	CD CD-R CD-RW MP3-CD
Disc playback modes	fast forward/backward next/previous album search next/previous track search repeat/shuffle/program

### Tuner/Reception/Transmission

Tuner bands	FM
Antenna	FM antenna

### Sound

Sound system	stereo
Volume control	rotary (digital)
Output Power	12W max

### Loudspeakers

No. of built-in speakers	2
Speaker grille finishing	metal

### Connectivity

USB	USB host
3.5mm headphone jack	Yes

Audio in (3.5mm)	Yes
------------------	-----

### Convenience

Display type	LCD display
Loader type	top

### Power

Battery type	D size (LR20)
Battery voltage	1.5 V
Number of batteries	6
Power type	AC/DC adaptor

### Accessories

Remote control	yes
Power cord	Yes
User Manual	yes
Warranty	Warranty leaflet

### Dimensions

Product dimensions (WxDxH)	435 x 271 x 170 mm
Packaging dimensions (WxDxH)	469x 197 x 311 mm
Product weight	2.9 kg
Weight incl. Packaging	4.11 kg



data subject to change  
2021, June 23

Version: 1.2.1  
EAN: 4895229103610

© 2021 Koninklijke Philips N.V.  
All rights reserved.

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

[www.philips.com](http://www.philips.com)