

Philips
DVD Micro Theater



MCD170

Enjoy DVD movie in great sound

Now you can truly experience the audio-visual thrill of the cinema in your living room! The stylish Philips DVD micro theater MCD170 features Dynamic Bass Boost for deep and rich bass sound.

Quality sound performance

- Digital Sound Control for optimized music style settings
- Dynamic Bass Boost for deep and dramatic sound
- Dolby Digital for ultimate movie experience

Multiple sources for more choices

- Cassette deck with auto stop
- Enjoy MP3/WMA music directly from your portable USB drives
- FM digital tuning to preset up to 20 stations
- Play DVD, DivX® Ultra, MP3/WMA-CD, CD and CD-RW

Enrich your sound experience

- 2x5W RMS/2x10W music power/400W PMPO

PHILIPS

Highlights

Dynamic Bass Boost

Dynamic Bass Boost maximizes your music enjoyment by emphasizing the bass content of the music throughout the range of volume settings - from low to high – at the touch of a button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.

Digital Sound Control

Digital Sound Control offers you a choice of pre-set Jazz, Rock, Pop and Classic controls you can use to optimise the frequency ranges for different musical styles. Each mode uses graphic equalizing technology to automatically adjust the sound balance and enhance the most important sound frequencies in your chosen music style. Ultimately, Digital Sound Control makes it easy for you get the most out of your

music by precisely adjusting the sound balance to match the type of music you are playing.

Dolby Digital

Because Dolby Digital, the world's leading digital multi-channel audio standards, make use of the way the human ear naturally processes sound, you experience superb quality surround sound audio with realistic spatial cues.



Specifications

Sound

- Output Power: 2x5W RMS / 400W PMPO
- Sound Enhancement: Digital Sound Control 4 modes, Dynamic Bass Boost
- Sound System: Dolby Digital

Loudspeakers

- Main Speaker: Bass Reflex Speaker System, 3" woofer

Video Playback

- Playback Media: DVD+RW, DVD-Video, Picture CD, Video CD/SVCD
- Disc Playback Modes: Angle, Slow Motion, Zoom, A-B Repeat, PBC, Parental control
- DVD Region.: 5
- USB Direct Playback: JPEG

Audio Playback

- Cassette Deck Technology: Mechanical
- Cassette Playback Modes: Electronic Speed Control
- Playback Media: MP3-CD, CD-RW, CD-R, CD, WMA-CD
- Disc Playback Modes: 20-Track Programmable, Repeat/one/all/program, Shuffle Play
- Loader Type: Top
- USB Direct Modes: Fast Backward/Fast Forward, Play/Pause, Previous/Next, Repeat, Shuffle

Audio Recording

- Recording Media: Tape
- Tape Recording Enhancement: CD Synchro Start Recording, Automatic Recording Level, One-Touch Recording

Tuner/Reception/Transmission

- Tuner Bands: FM Stereo, MW
- Auto digital tuning

- Station presets: 40
- Tuner Enhancements: Auto Store

Connectivity

- Video Output - Analog: Composite CVBS (yellow cinch), S-Video (on Hosiden)
- Other connections: Line out, FM Antenna, Digital coaxial out
- Headphone: 3.5 mm
- Audio Connections: 3.5mm Line in

Convenience

- Alarms: Sleep timer, CD Alarm, Radio Alarm
- Clock: On main display
- Display Type: LCD
- OSD Languages: English, Traditional Chinese, Portuguese, Spanish
- Backlight color: Blue

Accessories

- Included accessories: Composite video cable (Y), FM/MW Antenna, Guarantee booklet, Quick Use Guide, 3.5mm stereo line in cable
- Remote control: 40-key with Lithium batteries
- User Manual: English, Traditional Chinese
- Quick start guide: 16 languages
- User Manual: 16 languages

Dimensions

- Set dimensions (W x H x D): 147 x 231 x 209 mm
- Main speaker dimensions (W x H x D): 134 x 233 x 153 mm
- Packaging dimensions (W x H x D): 370 x 270 x 326 mm
- Weight incl. Packaging: 4.8 kg

Power

- Power supply: 220-240V



Issue date 2014-02-10

Version: 1.0.4

12 NC: 8670 000 55202
EAN: 87 12581 49586 2

© 2014 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com