



Philips  
Portable Radio

DAB/FM, Digital tuning  
20 presets  
Headphone jack  
Battery or AC operated

AE5010

## Great sound from DAB radio anywhere

Tune in to Philips portable radio with DAB reception for clear sound. Its classic desktop design as well as DAB and FM preset stations with quick scan DAB radio make this the ideal radio companion.

### Enjoy digital quality DAB radio

- DAB for clear and crackle-free radio experience
- DAB and FM compatible for a complete radio experience

### Easy to use

- Quick scan of DAB stations for extra convenience
- Large backlit LCD display for easy viewing in low light
- Stereo headphone
- 10 DAB and 10 FM preset stations

# PHILIPS

Portable Radio  
DAB/FM, Digital tuning 20 presets, Headphone jack, Battery or AC operated

# Specifications

## Tuner/Reception/Transmission

- DAB: info display, smart scan, menu
- Tuner bands: FM, DAB (Band III)
- Station presets: 20
- Antenna: FM antenna
- Tuner enhancement: auto digital tuning

## Sound

- Volume control: up/down
- Output power: 300 mW RMS

## Loudspeakers

- No. of built-in speakers: 1

## Connectivity

- Audio/Video output: Headphone (3.5mm)

## Convenience

- Display type: LCD display
- Backlight color: white



## Power

- Battery voltage: 1.5 V
- Number of batteries: 4
- Battery type: AA size (LR6)
- Power type: Mains and Battery

## Accessories

- Cables/Connection: AC-DC adapter
- Others: User Manual
- Warranty: Warranty Certificate

## Dimensions

- Main unit depth: 40 mm
- Main unit height: 105 mm
- Main unit width: 168 mm
- Packaging depth: 55 mm
- Packaging height: 125 mm
- Packaging width: 280 mm
- Gross weight: 0.6 kg
- Weight: 0.525 kg

AE5010/05

# Highlights

## DAB



DAB (Digital Audio Broadcasting) digital radio is, on top of FM analog transmission, a new way of broadcasting radio via a network of terrestrial transmitters. It provides listeners with more choices and information delivered in clear and crackle-free sound quality. The technology allows the receiver to lock on to the strongest signal it can find. With DAB digital stations there are no frequencies to remember, and sets are tuned by station name, so there is no returning on the move.

## 10 DAB and FM preset stations

10 DAB and 10 FM preset stations



Issue date 2014-08-09

Version: 1.0.4

12 NC: 8670 000 82779  
EAN: 08 71258 16229 61

© 2014 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)