

Philips Ultinon Pro7000 SI  
Superior brightness, safer  
drive

Type of lamp: P21/5W

12/24V, Intense Amber  
Advanced automotive system  
2+1-year warranty

11499AU70X2



## Enjoy superior brightness for a safer drive

### Superior brightness, safer drive

For unmatched visual comfort and safer driving, choose Philips Ultinon Pro7000 LED signaling bulbs. In exterior applications, their vibrant colors and crisp, amber light instantly improve driver visibility and wellbeing.

#### Superior visibility for safer driving

- Signal your intent with brighter exterior lighting
- Instant safety information for other drivers
- Ergonomic design with 360° beam pattern

#### High-end, stylish signaling

- Upgrade your lights, upgrade your style

#### Performance made to last

- Enhanced lifetime of up to 5,000 hours
- Aluminum heatsink to dissipate heat more efficiently

#### Simple plug-and-play replacement

- Easy to install and compatible with most car models
- Electrical compatibility with most cars and trucks
- Easy to install on your car

# PHILIPS

Superior brightness, safer drive  
Type of lamp: P21/5W 12/24V, Intense Amber, Advanced automotive system, 2+1-year warranty

LUM11499AU70X2/10

# Highlights

## Powerful brightness

Signaling the intended movement of your vehicle is vital to your safety. To avoid collisions, other people have to know what you're doing. And when poor weather reduces visibility, the need for bright and vibrant signaling becomes even greater. Philips Ultinon Pro7000 LED signaling lights provide intense amber light with 15 LEDs for your turn indicator and position signals. They will help other drivers to see you better, which is vital for them to react sooner. The earlier you are seen, the safer your drive will be!

## Instant-on technology

Compared to incandescent lamps, Philips Ultinon Pro7000 LEDs light up instantly to ensure that other drivers can react faster, keeping you safer.

## Uniform light distribution

For your turn indicator, reverse, rear fog and stop signals, the Philips Ultinon Pro7000 LED gives you uniform light distribution. Its 360° angle ensures that the light is projected where you need it. Not only can you see more of the road, but other drivers can also see more of you.

## Elegant LED light

While the main goal of exterior lighting is to help you see and be seen, there's no reason why you shouldn't look good at the same time. If you want to upgrade your style without buying a newer car, replacing your exterior lighting with Philips Ultinon Pro7000 LED signals is a smart way to spend your money.

## Lifetime of up to 5,000 hours

You want bright, stylish car lights but you don't want to keep replacing failed lamps. That's a major weakness of conventional bulbs - the more powerful the light, the shorter its lifespan. Even at a higher light intensity, LEDs last much longer. Philips Ultinon Pro7000 LED lights are built to last. Due to features

such as high-end LED technology and advanced heat-management systems, they last for up to 5,000 hours of operation and are covered by a 3-year warranty\*.

## Super-robust lamps made with aluminum

When operating, LEDs generate heat which reduces their brightness and overall lifespan. Philips Ultinon Pro7000 LED lights feature an aluminum heatsink which dissipates heat much faster than the conventional plastic base used by low-cost, inferior-quality bulbs. That makes our lamps more robust and longer-lasting.

## Ready, steady, installed!

Enjoy the plug-and-play experience: Philips Ultinon Pro7000 LED lights use the same standard caps as the conventional lamps on your car, enabling you to upgrade with no modification needed, so replacement is quick and easy.

## Electrical compatibility with most cars and trucks

LED retrofit and conventional bulbs differ from one another in terms of wattage, composition and power consumption. Replacing your conventional bulbs with other LEDs may prove problematic. Thanks to the built-in constant IC driver, Philips Ultinon Pro7000 bulbs work within 9-32 volt systems and are electrically compatible with most cars and trucks. Canbus adapters are available as accessories for troubleshooting if needed. We sell a complete solution.

## Polarity-free design

Enjoy the plug-and-play experience: the Philips Ultinon Pro7000 comes with polarity-free design, so you don't need to worry about polarity during installation. It will save you time and make installation easier.

# Specifications

## Marketing specifications

- Product highlight: Automotive Grade LED
- Powerful brightness Uniform light distribution
- Expected benefits: Brighter, elegant signals

## Product description

- Application: Front turn indicator, front position lights, rear turn indicator lights, rear position, tail lights
- Base: BAY15d
- Designation: P21/5W LED Amber 11499 AU70 12/24V X2
- Designation LED Type: LED-AMBER [≈P21/5W]
- Homologation ECE: NO
- Range: Ultinon Pro7000
- Technology: LED
- Type: P21/5W
- Voltage: 12V + 24V V

## Lifetime

- Life time: 5000 hrs

## Light characteristics

- Lumens: 250lm / 95lm (12V) 305lm / 150lm (24V)
- Color temperature: AMBER

## Electrical characteristics

- Voltage: 12/24 V
- Wattage: 2.7W / 0.9W (12V) 3.3W / 1.5W (24V)

## Ordering information

- Order entry: 11499AU70X2
- Ordering code: 02279030

## Logistic data

- Ordering code: 11499AU70X2
- EAN1: 8719018022790
- EAN3: 8719018022806

## Packaging Data

- EAN1: 8719018022790
- EAN3: 8719018022806
- Packaging type: X2

## Packed product information

- Length: 7,0 cm
- Width: 2,5 cm
- Height: 11,5 cm
- Pack Quantity: 2 pcs
- MOQ (for professionals): 10 packs
- Gross weight per piece [g]: 40 g

## Outerpack information

- Length: 19,5 cm
- Width: 15,5 cm
- Height: 8,5 cm
- Gross weight [kg]: 0,46 kg



Issue date 2024-08-12

Version: 3.3.1

EAN: 87 19018 02279 0

© 2024 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)

\* \*2-year standard warranty + 1 year extended. Visit [philips.com/auto-warranty](http://philips.com/auto-warranty) to know more about our warranty policy

\* Non-ECE compliant