



Philips
Portable CD Player

AX3315



Slim and Jogproof

Looking for a CD player that has great features and looks ultra cool? The AX3315 is just the ticket. The players are slim and ultra modern with a unique animated optical encasing and a variety of exciting colors for a fun music experience.

Stylish design

- Slim Portable CD Player with round and compact footprint
- Unique animated optical casing for fun and happiness

Jogproof

- 45-second ESP™

Enhanced bass performance

- Digital Dynamic Bass Boost for optimized bass at any volume
- Stereo headphone with handy volum control

Enjoy all kinds of discs

- Plays CD, CD-R and CD-RW discs

PHILIPS
sense and simplicity

Specifications

Sound

- Acoustic Feedback
- D/A converter: 1-bit
- Frequency response: 20 - 20 000 Hz
- Output Power: 2 x 5mW RMS
- Signal to noise ratio: > 85dB
- Sound Enhancement: Digital Dynamic Bass Boost
- Volume Control: digital

Audio Playback

- Playback Media: CD, CD-R, CD-RW
- Disc Playback Modes: 30-Track Programmable, Fast Forward/Backward, Hold, Introscan, Repeat Play, Resume Playback from stop, Shuffle Play
- Electronic Skip Protection(CD): 45

Connectivity

- DC in: 4.0 mm, 4.5V, centre +
- Headphone: 3.5 mm
- Line-out: 3,5 mm

Convenience

- Display Type: LCD
- Indications: battery status, Cd functions, DBB, ESP, time, track

Accessories

- Car kit: AY3501, AY3548
- Headphones: SBC HS383(neckband)
- Included Accessories: User Manual

Dimensions

- Ebox dimensions (W x H x D): 0 x 0 x 0 mm
- Housing: Heat Resistant Body, Lenticular Sheet
- Master carton dimensions: 254 x 345 x 256 mm
- Master carton weight: 2.3 kg
- Master carton quantity: 3
- Packaging dimensions (W x H x D): 216 x 305 x 69 mm
- Packaging type: Clamshell
- Product dimension (WxDxH) inch: 137.5x137.5x23.3mm
- Product weight: 0.2 kg

Power

- Battery Playing Time CD: 20
- Battery type: AA, AAA, LR03, LR6, UM3, UM4
- Kind of Battery: Rechargeable

Product highlights

Round, slim and compact

Animated optical casing

45-second ESP™

Electronic Skip Protection is a convenient feature that ensures skip-free music even when your CD player is subjected to knocks and jolts while you're jogging or on the move. Devices with Electronic Skip Protection have an intelligent electronic buffer that adjusts both its contents and laser spin speeds automatically to guarantee uninterrupted music listening.

Digital Dynamic Bass Boost

Digital Dynamic Bass Boost is an intelligent bass booster that delivers maximum bass enhancement at high volumes without sound distortion and at low volumes without compromising on bottom-end bass frequencies. Technologically advanced electronics constantly monitor volume and bass levels, precisely calibrating both to prevent sound distortion, thus producing optimized bass. Digital Dynamic Bass Boost enables the enjoyment of superb bass performance - regardless of the chosen volume level.

Headphone with volume control

Plays CDs, CD-R and CD-RW



Date of issue 2007-01-15

Version: 1.0

12 NC: 9073 101 00968

© 2007 Koninklijke Philips Electronics N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

www.philips.com