



Philips
wireless portable speaker

Bluetooth®

Gesture control, splash proof
Built-in microphone for calls
8W, rechargeable battery



SB7200

Big sound, shockingly clear

Tough it out loud and proud on the splash- and drop-proof Philips Shoxbox SB7200 series. Take your music outdoors on this rugged road warrior that lets you enjoy music wirelessly - and fearlessly - in big, deep yet clear sound.

Sound Performance

- Powered by 2 neodymium drivers
- Loud and clear sound
- Pair 2 shoxboxes into L-R speakers

Versatility

- Bluetooth streaming
- Swipe sensor to skip songs
- Built-in mic for speaker phone
- Voice prompt for feedback

Portability

- Drop it, splash it and just keep on using it
- Built-in lithium battery

PHILIPS

wireless portable speaker
Bluetooth® Gesture control, splash proof, Built-in microphone for calls, 8W, rechargeable battery

SB7200/12

Highlights

Powered by 2 neodymium drivers



It is built with 2 neodymium speaker drivers and wOOx system; simply the great sound you could ever expect from a speaker that small. Big sound, shocking clarity and deep bass to allow you to enjoy the best sound performance anywhere.

Bluetooth portable speakers

Bluetooth is a short range wireless communication technology that is both robust and energy-efficient. The technology allows easy wireless connection to other Bluetooth devices, so you can play your favorite music from any smartphones, tablets or even laptops including iPod or iPhone on Bluetooth-enabled speaker easily.

Drop and splash proof



This Philips SHOQBOX is made to withstand splash and drop, perfect for outdoor adventurers. No worries about rain or spills thanks to the splash protective design. The

rubber casing is a specialized tough material that can withstand drops and rough use. Simply drop it in your bag or hang it on your back pack. Perfect for the outdoors that requires an extra dose of ruggedness.

Motion sensor



SHOQBOX is equipped with a motion sensor. Simply swipe over the sensor from left to right or right to left, to skip to the next or last track. Put your hand over the sensor for a second to pause the music. Do it again to put it back on. Easy gesture control allows you to control your music the simplest way.

Built-in mic



With its built-in microphone, it also works as a speaker phone. When a call comes in, the music is put on pause and you can talk via the speaker. Call for a business meeting. Or, call your friend from a party. Either way, it works great.

Voice prompt



The voice prompt is available in different languages. It gives instant feedback on battery level or alert whether the speaker is connected properly to your device.

Pairing 2 shoqboxes



You can pair 2 SHOQBOX speakers with the smart sensor for a stereo system of Left and Right channels. Simply place the two speakers side by side and swipe your hands over both sensors from outside in simultaneously. Perfect for a party or gathering. Enjoy big stereo sound from music, movies and games.

wireless portable speaker

Bluetooth® Gesture control, splash proof, Built-in microphone for calls, 8W, rechargeable battery

SB7200/12

Specifications

Compatibility

- Works with: most Bluetooth smartphones, tablets, music devices
- iPad: iPad 1, iPad 2, new iPad
- iPhone: iPhone 3, iPhone 3GS, iPhone 4, iPhone 4S
- iPod touch: 3rd generation or later
- Android tablets & smartphones: with Android 2.1 and Bluetooth 2.1 or above
- other music devices: with Bluetooth 2.1 or above

Convenience

- Smart sensor: for skipping songs and pairing 2 Shoqboxes into L-R speaker
- Voice feedback: on battery level

Connectivity

- Audio Connections: 3.5mm Line in
- Bluetooth profiles: A2DP, AVRCP, HFP, HSP
- Bluetooth range: Line of sight, 10M or 30FT

Sound

- Output power (RMS): 2 x 4W

- Sound System: Stereo
- Speakers: 2 x 1"

Loudspeakers

- Loudspeaker enhancement: wOOx Bass Radiator
- Speaker drivers: Neodymium magnet system

Power

- Power supply: 100-240VAC, 50/60Hz
- Battery type: lithium (built-in)
- Operating time on battery: 8 hr

Accessories

- Included accessories: AC Power Cord, USB cable for PC charging, Warranty certificate, World Wide Warranty leaflet, Quick install guide

Dimensions

- Product dimensions (WxDxH): 72 x 68 x 179 mm
- Packaging dimensions (WxDxH): 133 x 100 x 200 mm
- Product weight: 0.488 kg
- Weight incl. Packaging: 0.953 kg



Issue date 2020-07-08

Version: 5.0.13

12 NC: 8670 000 87371
EAN: 87 12581 63611 1

© 2020 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com

* Drop proof is measured from approximate height of 0.8m. Drop protection varies depending on drop conditions.

* The body of SHOQBOX offers "splash-proof" water resistance equivalent to IEC 60529 IPX4. It is not waterproof and should never be immersed in water and should not be used in bathrooms.

* Battery life varies by use and settings.