

Philips
Micro Hi-Fi System

MP3/WMA-CD
USB

MCM765



Obsessed with sound

Relax with great music

Specifically designed for those who truly appreciate the ultimate in style and technology, Philips MCM765 exudes finesse and quality. Enjoy MP3/WMA music from your portable player with MP3 link and USB Direct playback.

Unlimited listening pleasure

- Enjoy MP3/WMA music directly from your portable USB drives
- Play MP3/WMA-CD, CD and CD-RW
- MP3 Link for portable music playback

Enrich your sound experience

- Incredible Surround™ for enhanced audio enjoyment
- Digital Sound Control for optimized music style settings
- Dynamic Bass Boost for deep and dramatic sound
- Enjoy 300 watts total output power

Start the day your way

- Wake up and sleep timer functions
- Logic tape deck

Refined in sound and look

- Elegant wood-finished speakers
- Motorized CD loader for convenience access

PHILIPS

Specifications

Sound

- Sound enhancement: incredible surround, digital sound control 4 modes, Dynamic Bass Boost
- Output power: 300 W RMS, 4000 W PMPO

Loudspeakers

- Speaker drivers: 5.25" woofer, Piezo tweeter
- Loudspeaker enhancement: 2-way, speaker grilles detachable
- Speaker types: bass reflex speaker system

Audio playback

- Playback media: CD, CD-R, CD-RW, MP3-CD, WMA-CD
- Disc playback modes: repeat/shuffle/program
- Others: ID3-tag support
- Cassette deck technology: full logical
- Cassette Playback Modes: electronic speed control, full auto stop, tape counter
- USB Direct playback modes: fast backward/fast forward, play/pause, previous/next, program play, repeat, shuffle, stop

Audio recording

- Recording media: tape
- Tape recording enhancement: CD synchro start recording, timer for recording from tuner, automatic recording level

Tuner/Reception/Transmission

- Tuner bands: FM stereo
- Station presets: 40
- Antenna: FM antenna
- Tuner enhancement: auto digital tuning, auto scan

Connectivity

- MP3 Link: 3.5mm stereo line in
- USB: USB host

Convenience

- Alarms: CD alarm, radio alarm, tape alarm, USB alarm
- Clock: on main display, sleep timer
- Loader type: motorised, tray
- Display type: VFD display

Accessories

- Cables/Connection: 3.5 mm stereo line in cable, power cord
- Remote control: 24-key with lithium battery
- Others: FM antenna, Quick start guide
- User Manual: Spanish

Dimensions

- Gross weight: 10.1 kg
- Main speaker dimensions (W x D): 175 x 214 mm
- Main speaker height: 252 mm
- Main unit depth: 360 mm
- Packaging width: 524 mm
- Main unit height: 252 mm
- Packaging height: 353 mm
- Main unit width: 175 mm
- Packaging depth: 408 mm

Power

- Power supply: 50/60 Hz
- Power supply: 110 - 240 V

Highlights

USB Direct for MP3/WMA music

Simply plug in your device to the USB port on your Philips Hi-Fi system. Your digital music will be played directly from the device. Now you can share your favorite moments with family and friends.

Incredible Surround™

Incredible Surround is an audio technology from Philips that dramatically magnifies the sound field to immerse you in the audio. Using state-of-the-art electronic phase shifting, Incredible Surround mixes sounds from left and right in such a way that it expands the virtual distance between the two speakers. This wider spread greatly enhances the stereo effect and creates a more natural sound dimension. Incredible Surround allows you to experience total surround with greater depth and width of sound, without the use of additional speakers.

Digital Sound Control

Digital Sound Control offers you a choice of pre-set Jazz, Rock, Pop and Classic controls you can use to optimise the frequency ranges for different musical styles. Each mode uses graphic equalizing technology to automatically adjust the sound balance and enhance the most important sound frequencies in your chosen music style. Ultimately, Digital Sound Control makes it easy for you get the most out of your music by precisely adjusting the sound balance to match the type of music you are playing.

Dynamic Bass Boost

Dynamic Bass Boost maximizes your music enjoyment by emphasizing the bass content of the music throughout the range of volume settings - from low to high - at the touch of a button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.

MP3 Link

The MP3 link connectivity allows direct playback of MP3 content from portable media players. Besides the benefit of enjoying your favorite music in the superior sound quality delivered by the audio system, the MP3 link is also extremely convenient as all you have to do is to plug your portable MP3 player to the audio system.



Issue date 2014-02-05

Version: 3.0.6

12 NC: 8670 000 40848
EAN: 87 12581 43185 3

© 2014 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com

* Avoid extensive use of the set in a volume higher than 85 decibel because this may damage your hearing.