

成品尺寸: 75\*90mm  
 材质: 128G铜版纸  
 印刷: 四色双面印刷+风琴折

**7** 来电操控

L / R

x2  
 触屏2次  
 接听/挂断电话

x1  
 触屏1次  
 长触2秒拒接电话

**8** Siri® 语音助手唤醒

L / R

x1  
 触屏1次  
 长触2秒唤醒语音助手

x1  
 触屏1次  
 关闭语音助手

**9** 重置耳机

x5

左右耳机开机状态下,同时连续触碰左右耳机5次,耳机进行初始化恢复出厂设置,设置成功后耳机自动进入蓝牙配对模式。

**PHILIPS**

Welcome to Philips!

Philips and the Philips Shield Emblem are registered trademarks of Koninklijke Philips N.V. and are used under license. This product has been manufactured by and is sold under the responsibility of MMD Hong Kong Holding Limited or one of its affiliates, and MMD Hong Kong Holding Limited is the warrantor in relation to this product.

欢迎光临飞利浦!

飞利浦和飞利浦盾徽是Koninklijke Philips N.V.的注册商标,并在许可下使用,本产品由MMD香港控股有限公司或其关联公司制造并在其责任下销售,而MMD香港控股有限公司是产品的保证人,使用设备前请仔细阅读本说明书。

Frequency range: 2.402-2.480GHz Transmitter power < 10dBm  
 频率范围: 2.402-2.480GHz 发射功率: < 10dBm

警告:小心使用和处置电池,不要将自由能电池或如放入生活垃圾中处理,随意丢弃会对环境和人类健康构成风险,为了最高品质和您的健康,飞利浦将在其产品的使用寿命内提供可充电电池,这些电池将促进环境正确的目的,飞利浦在技术援助方面有效果。

\* Full user manual in all languages available on: [2] 下列网站提供所有语言版的完整用户手册:  
[www.philips.com/support](http://www.philips.com/support)

**PHILIPS**

Headphones

1000 Series

TAT1168

www.philips.com/welcome

**1** 充电

①

②

充电时间约1.5小时

**2** 蓝牙配对

①

②

打开充电仓上盖,耳机灯白蓝交替闪烁,进入蓝牙配对

**3** 音乐播放/暂停

L / R

x2

触屏2次  
 音乐播放/暂停切换

**4** 音乐曲目切换

L

x3

触屏3次切换到上一曲

R

x3

触屏3次切换到下一曲

**5** 音量减小

L

x1  
 触屏1次,然后长触调小耳机音量

**6** 音量增加

R

x1  
 触屏1次,然后长触调大耳机音量