

Philips
Micro Hi-Fi System

MP3/WMA-CD playback
Compact design

MCM108



Compact audio system to match your lifestyle

Great sound in a compact, elegant design! The MCM108 delivers dynamic sound performance and the essential functionalities that will let you enjoy music just the way you like it.

Enrich your sound experience

- Play MP3/WMA-CD, CD and CD-RW
- Convenient line-in jack for portable music playback
- Dynamic Bass Boost for deep and dramatic sound
- Digital Sound Control for optimized music style settings
- 4W RMS total output power

Wake up to CD or radio tunes

- Wake up and sleep timer functions
- Stereo tuning with digital readout

Fits any space, any lifestyle

- Compact design

PHILIPS

Specifications

Sound

- Output Power: 2x2 watts RMS / 200 watts PMPO
- Sound Enhancement: Dynamic Bass Boost, Digital Sound Control
- Volume Control: Volume Control up/down

Loudspeakers

- Main Speaker: 3.5" woofer

Audio Playback

- Playback Media: CD, CD-R, CD-RW, MP3-CD, WMA-CD
- Disc Playback Modes: 20-Track Programmable, Repeat/one/all/program, Shuffle Play
- Loader Type: Top

Tuner/Reception/Transmission

- Tuner Bands: FM Stereo, MW

Connectivity

- Headphone: 3.5 mm
- Other connections: FM fixed pigtail antenna, MW

- Antenna
- Aux in: Line-in, 3.5 mm

Convenience

- Alarms: CD Alarm, Radio Alarm, Sleep timer
- Clock: On main display
- Display Type: LCD
- Backlight color: White

Accessories

- Remote control: 20-key with battery
- Included accessories: FM/MW Antenna
- Quick start guide: English, Spanish, Brazilian Portuguese
- User Manual: English, Spanish, Brazilian Portuguese

Dimensions

- Set dimensions (W x H x D): 150 x 150 x 200 mm
- Main speaker dimensions (W x H x D): 150 x 150 x 200 mm
- Packaging dimensions (W x H x D): 520 x 200 x 280 mm
- Weight incl. Packaging: 4.28 kg


Highlights

Dynamic Bass Boost

Dynamic Bass Boost maximizes your music enjoyment by emphasizing the bass content of the music throughout the range of volume settings - from low to high - at the touch of a button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.

Digital Sound Control

Digital Sound Control offers you a choice of pre-set Jazz, Rock, Pop and Classic controls you can use to optimise the frequency ranges for different musical styles. Each mode uses graphic equalizing technology to automatically adjust the sound balance and enhance the most important sound frequencies in your chosen music style. Ultimately, Digital Sound Control makes it easy for you get the most out of your music by precisely adjusting the sound balance to match the type of music you are playing.



Issue date 2014-02-05

Version: 1.1.8

12 NC: 8670 000 24999
EAN: 87 10895 99917 5

© 2014 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com

* Avoid extensive use of the set in a volume higher than 85 decibel because this may damage your hearing.