



Philips
Monolith design cordless
phone

60 min answering machine
2.0" display/ white backlight
Handsfree speakerphone



M9951B

Tap to talk

With its bold geometry and seamless profile, the Philips Monolith reflects the true art of communication. Smart touch technology, like Tap to Talk, is integrated in its genuine metal design for intuitive ease of use and superb comfort.

Exquisite design with high quality execution

- Sophisticated design with genuine metal frame
- Secondary display on the base shows caller ID and clock
- Charge handset either way around

Ultimate calling experience

- High resolution 5.1cm (2") TFT color display
- Tap handset for easy hands-free chats or extra sleep time.
- Up to 60 minutes of messages on your answering machine
- Assign ringtone to a specific contact
- Hearing aid compatible - reduces unwanted noise
- Black list, anonymous call, silence mode, call barring
- Baby monitor alerts you when baby needs your attention
- Talk up to 18 hours on a single charge

Eco-conscious product

- Zero power emission when ECO+ mode is activated

PHILIPS

Monolith design cordless phone
60 min answering machine 2.0" display/ white backlight, Handsfree speakerphone

M9951B/05

Highlights

5.1cm (2") TFT color display



High resolution 5.1cm (2") TFT color display

Baby monitor

Receive an alert when your baby needs you. Just place the DECT handset in the baby room and receive an alert on another DECT phone (i.e. another landline number) or mobile phone when the baby starts to cry.

ECO+ mode



Philips phones are energy efficient and designed to be respectful to the environment. When ECO mode is activated the emitted radiation is reduced by up to 60%, and up to 95% when the phone is charging. With ECO+ mode activation the radiation drops to zero.

Extended privacy settings

Black list restricts receiving calls from specific numbers or starting with certain digits, keeping you away from unwanted calls. You can block 4 sets of numbers. Each set of numbers can consist between 1 to 24 digits. When there is an incoming call that starts with one of these numbers or being one of 4 exact Caller numbers, the phone will not ring. With silence mode you can disable the ringtones for specific times to enjoy peace and silence. Thanks to Call barring you can avoid expensive phone bill surprise by blocking calls to specific numbers starting with certain digits.

Genuine metal frame



This sophisticated design features genuine die-cast metal that has been immaculately crafted and brushed for a truly refined look and feel.

Hassle-free charging

For reliability and convenience the handset can be charged in both directions of the docking station.

Hearing aid compatible



This feature enables the phone to couple with the hearing aid to amplify conversation while reducing ambient noise and the buzzing, humming, or whining noise that can otherwise occur.

Secondary display on the base



The Philips Monolith high contrast white-on-black display seamlessly and stylishly integrates with its base. The display shows the caller ID when there is an incoming call and the time when in idle mode. You can choose to turn off

the base display - so as not to be disturbed by any light - at any time.

Tap to talk. Tap to snooze.



Just tap the top of the handset when the phone is docked to answer an incoming call. Enjoy clear hands-free communication, thanks to the phone's built-in loudspeaker which comfortably amplifies the caller's voice. The secondary display shows the caller ID or phone number, so you can choose not to pick up unwanted calls. If you set the alarm and it goes off while the phone is docked, just tap the top of the handset to snooze for a few more minutes - for up to a maximum of 3 times.

Up to 18 hours talk time

Talk up to 18 hours on a single charge

Up to 60 min. recording

With 60 minutes recording time on your answering machine, you'll never miss an important message.

VIP Caller Identification

Assign a dedicated ringtone to your very important person the important people in your life. You would be warmly noticed whenever receive his or her phone call. It is possible to assign dedicated ringtones to up to 9 different contacts or group of contacts.

Specifications

Sound

- HQ-Sound
- Sound Profile: MySound
- Ringtones on handset: 10 HQ ringtones
- Hearing Aid Compatible
- Volume control on handset

Picture/Display

- Backlight: Yes
- Backlight color: White
- Base display size: 7.0 cm/2.77"
- Base display type: Reversed dot matrix
- Handset display size: 5.1cm/2.0"
- Handset display type: TFT 16-bit color
- Selectable Wallpaper: With off wallpaper option

Answering Machine

- Recording time capacity: Up to 60 minutes
- Pre-recorded OGM
- Answering machine control: From handset

Convenience

- Menu structure in the handset: Icon Menu
- Personalization: Silent mode
- Call barring: Restrict the phone from making specific outgoing calls
- Signal strength indicator: 3-bar indicator
- Battery level indicator: 5-bar battery icon
- Intercom - multiple handsets
- Room monitoring
- Date / Time display
- Battery charge indication
- Signal strength indication
- Programmable hot keys: Keys 1 to 9
- Call Management: Call Waiting*, Caller ID*, Microphone mute, Missed Calls, Received Calls, Dialed calls
- Keypad lock
- Key tone on/off
- Auto hang up
- Multi base capability: 1
- Multi handset capability: Up to 4 handset
- Number of keys: 23
- Backlit keypad: White
- Enlarge dialing digit
- Up to 18 hrs talk time
- Up to 250 hrs standby time
- Charge time: 8 hours
- Line cord length: 1.8m
- Power cord length: 1.8m

- Range: Open field <300m; in door <50m
- Alarms: Alarm Clock, Repeat alarm (snooze)
- Base station keys: Paging key
- Block callers/ Blacklist*: Restrict the phone from ringing on specific incoming numbers
- Event notifications: For events status
- Illuminated keypad
- Premium MMI: Standard
- Graphic, touchbased UI: Tap handset for easy hands-free chats or extra sleep time.
- Speakerphone - talk handsfree

Memory Capacity

- VIP Caller Identification
- Phonebook: 150 names and numbers
- Redial List Capacity: 20 entries
- Call log entries: 50 entries
- Phonebook store in the base
- Multiple phonebook entries: 3-field

Power

- Battery capacity: 600 mAh
- Battery type: NiMH Rechargeable
- Mains power: AC 100-240V ~50/60Hz
- Power Consumption: <1.4W

Security

- Transmission encryption

Network Features

- Compatible: GAP
- Network service menu

SAR Value

- Philips handsets: <0.1 W/kg

Eco Design

- Eco+
- Eco Mode: Automatic & manual

Packaging dimensions

- Packaging type: Carton
- Number of products included: 1
- Type of shelf placement: Laying
- Packaging dimensions (W x H x D): 31.8 x 9.5 x 8.1 cm
- Gross weight: 0.663 kg
- Nett weight: 0.514 kg
- Tare weight: 0.149 kg
- EAN: 48 95185 62478 5



Issue date 2017-06-28

Version: 3.1.4

12 NC: 8670 001 40823
EAN: 48 95185 62478 5

© 2017 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com

**This feature requires additional subscription of Caller ID service.
Please check with your local network operator for details.