

Philips CD Soundmachine with Dynamic Bass Boost

PSS010

# Sound Takes Shape

Sound takes shape and adds a new dimension to your audio experience. Intrigued by unique design and inspiring innovation, you'll be wowed by unexpected big sound from this small yet potent marvel, which complements your personal space.

## A new dimension to your audio experience

- Unique and innovative, 'soft' design
- Small footprint to blend into any lifestyle
- Sophisticated aluminum body

## **Unexpected power**

- Built-in speakers featuring XSL Acoustics for dynamic sound
- Dynamic Bass Boost for deep and dramatic sound

### Easy to use

- Touch screen for easy navigation
- Digital tuning with preset stations for extra convenience
- Motorized CD loader for convenience access
- Handy remote control



## Specifications

#### Sound

- Front Speakers Ways: 2
- Loudspeaker Enhancement: Detachable Cloth Grilles
- Loudspeaker types: Bass Reflex Speaker System
- Magnet type: Neodymium
- Output power (RMS): 2X2W+4W
- · Sound Enhancement: Advanced Sound System, Dynamic Bass Boost
- Sound System: Stereo
- Volume Control: digital
- Woofer: 1 inch

#### **Audio Playback**

- Playback Media: CD, CD-R, CD-RW
- Disc Playback Modes: Fast Forward/Backward, Next/Previous Track Search, Repeat Play, Shuffle Play
- Loader Type: Motorised
- Programmable Tracks: 20

#### **Tuner/Reception/Transmission**

- Antenna: FM Antenna
- Antenna location: External
- Auto digital tuning
- Tuner Bands: FM

DBB

## Connectivity

- DC in: 10V · Headphone: 3.5 mm

## Convenience

#### Backlight

- Backlight color: Blue
- Clock/Version: Digital
- Display Digits: 7
- Display Enhancements: Brightness Control, Function indication, Touch screen control
- Display Type: LCD

#### **Accessories** AC/DC Adaptor

- · Included accessories: User Manual, Warranty certificate
- Remote control: 17 Key

#### **Dimensions**

- Packaging dimensions (W x H x D):
- 413 x 278 x 313 mm • Product dimensions (W x H x D):
- 213 x 178 x 213 mm
- Weight: 3.4 kg
- Weight incl. Packaging: 4.4 kg

#### Power

Adaptor type: 10V 1200mA

## PSS010/01

## Highlights

#### Unique and innovative design Unique and innovative, 'soft' design

Small footprint Small footprint to blend into any lifestyle

#### Sophisticated aluminum body Sophisticated aluminum body

## XSL Acoustics

Enjoy dynamic sound and powerful bass performance from your ShoqBox with XSL Acoustics. Impressive sound is produced by combining bright, brisk treble and mid range sound with elastic, powerful bass. Innovative use of hightech materials like titanium cone and neodymium magnet deliver sound output that's nearly double the power of a traditional speaker driver of the same size. Precise tuning between the speaker driver, the small acoustic architecture and the circuitry ensures superbly dynamic sound and optimizes bass performance from the smallest sound enclosure.

### **Dynamic Bass Boost**

Dynamic Bass Boost maximizes your music enjoyment by emphasizing the bass content of the music throughout the range of volume settings from low to high – at the touch of a button! Bottomend bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.

#### Touch screen

Touch screen control allows you to control your device by simply pressing on-screen buttons rather than physical buttons on the device. Simply power up the device and the touch screen user interface will show up on the LCD display with all the control options for the device. Touch screen control combines LCD display technology with pressure sensors and a powerful digital micro processor. When you press on a specific area of the screen with your finger, the relevant signal is sent to the processor and the command is immediately executed.

#### **Digital tuning with presets**

Simply tune into the station that you want to preset, press and hold the preset button to memorize the frequency. With preset radio stations that can be stored, you can quickly access your favorite radio station without having to manually tune the frequencies each time.

#### **Motorized CD loader**

A motorized sliding front door adds even more panache to the already sleek design of this system. The stylish yet functional door housing the disc slides up and down vertically in a smooth motion at the touch of a button whenever you feel like changing your music selection. Just sit back and enjoy the dynamic sound performance while watching the disc play through the transparent window.

Handy remote control Handy remote control



Issue date 2014-02-05

© 2014 Koninklijke Philips N.V. All Rights reserved.

Version: 4.0.5

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V.

12 NC: 9073 101 01304 EAN: 87 10895 82168 1

or their respective owners.

www.philips.com