

Philips  
Portable DVD Player

PET835



## Slim set with DVD slot

with built-in digital TV receiver

The magic of movies and music comes to life on the tablet-style Philips PET835 with 8.5" LCD display. Enjoy free-to-air digital TV programmes with the built-in digital TV receiver. Comes with Smart Car Mount and USB connector.

### Immerse yourself in AV entertainment on the go

- Play DVD, DVD+/-R and DVD+/-RW, (S)VCD, DivX® & MPEG4 movies
- Play MP3/WMA-CD, CD and CD-RW
- Share JPEG image files with Picture CD

### Experience the digital interactive TV phenomenon

- Support DVB-T for free-to-air digital TV and radio channels
- 7-day Electronic Programme Guide (EPG)
- Direct Teletext and subtitle function support

### Optimised viewing anywhere

- Zero Bright Dot™ screen for optimal screen quality
- 8.5" TFT colour LCD display for high-quality viewing

### For ultimate convenience

- Up to 3 hours of playback with a built-in battery\*
- Smart Car Mount for ease of use
- USB connection for photo and music playback from USB devices



**PHILIPS**  
sense and simplicity

## Specifications

### Picture/Display

- **Display screen type:** LCD TFT
- **Diagonal screen size (inch):** 8.5 inch
- **Resolution:** 480(w) x 234(H) x 3(RGB)
- **Brightness:** 200 cd/m<sup>2</sup>
- **LCD panel type:** Anti-glare polariser
- **Contrast ratio (typical):** 250:1
- **Effective viewing area:** 187.2x105.3
- **Pixel pitch:** 0.13 (W) x 0.45 (H)
- **Response time (typical):** 30 ms

### Sound

- **Output Power:** 250 mW RMS (built-in speakers)
- **Output power (RMS):** 10 mW RMS (earphone)
- **Signal to noise ratio:** >76dB(line out), >62dB(built-in speakers)

### Video Playback

- **Playback Media:** DVD, Picture CD, SVCD, Video CD, DVD-R/-RW, MP3-CD, CD-R/CD-RW, WMA, DVD+R/+RW, CD
- **Disc Playback Modes:** A-B Repeat, Angle, Disc Menu, Fast Reverse, Fast Forward, OSD, Repeat, Shuffle Play, Slow Reverse, Slow Forward, Zoom
- **Video disc playback system:** NTSC, PAL
- **Compression formats:** MPEG4, Divx

### Audio Playback

- **Compression format:** Dolby Digital, MP3, WMA
- **MP3 bit rates:** 32 - 320 kbps
- **WMA bit rates:** 32 - 192 kbps
- **Playback Media:** CD, CD-R, CD-RW, MP3-CD, WMA-CD
- **File systems supported:** ISO-9660, Joliet

### Connectivity

- **DC in:** 9 V
- **AV output:** Composite (CVBS) x1

- **Headphone jack:** 3.5 mm Stereo Headphone x 2
- **AV input:** Composite (CVBS) x1
- **Audio Output - Digital:** Coaxial (cinch)

### Convenience

- Battery charging indication
- Shock proof

### Tuner/reception/transmission

- **DVB:** DVB Terrestrial\*

### Video Decoding

- **Aspect Ratio:** 16:9, 4:3, 4:3 Letterbox
- **Reception-Demodulation:** COFDM 2K/8K, MPEG-2 DVB compliant, Network: MFN/SFN, QPSK

### Accessories

- **AC/DC adapter:** DC-in 9 V; 100-240 v, 50/60 Hz
- **Cables:** 1 x AV Cables
- **Car kit:** cigarette outlet adapter, 12vDC
- **Remote control:** AY5506 slim remote
- **User manual:** 16 languages
- **Smart car mount:** 1 pcs
- **Pouch:** Protective pouch
- **Included Accessories:** Aerial antenna

### Dimensions

- **Product dimensions (W x H x D):** 255 x 170 x 31 mm
- **Product weight:** 1 kg
- **Packaging dimensions (W x H x D):** 310 x 200 x 145 mm
- **Master carton quantity:** 3
- **Master carton dimensions:** 333 x 236 x 458 mm
- **Master carton weight:** 7.58 kg
- **Packaging type:** D-box

## Product highlights

### Play DVD/DivX® & MPEG4

With DivX® support, you are able to enjoy DivX® encoded videos in the comfort of your living room. The DivX® media format is an MPEG4-based video compression technology that enables you to save large files like movies, trailers and music videos on media like CD-R/RW, memory cards and DVD-video. DivX® CDs can be played back on selected DVD players, DVD Recorders and Home Theatre Systems.

### Support DVB-T

Expand your entertainment experience and enjoy digital channel programmes - for free. With DVB-T (Digital Video Broadcasting - Terrestrial), you can receive free digital TV and radio programmes in Europe. The signal remains digital with no analogue steps in between, to preserve the highest quality.

### Zero Bright Dot™ screen

Enjoy highest-quality images that are free from annoying blank spots on the LCD screen. LCD displays commonly have imperfections, termed 'bright dots' by the LCD industry. A limited number of bright dots was once considered an inevitable side effect of LCD mass production. With Philips' strict quality control procedures used for our Portable DVD Players, our LCD displays are produced with zero tolerance for bright dots. Select Portable DVD Players come with Philips Zero Bright Dot™ Policy to guarantee optimal screen quality.

### Smart Car Mount

To enjoy entertainment on the go, why not take your portable DVD player from home on the road with you? A unique Car Mount system ensures safety and ease of use, with a quick-release arm that facilitates easy removal of the player when not in use. You can take the portable DVD player with you, leaving just the Mount behind in the car.

### USB connection for photo/music

Simply plug in your portable device to the USB connector on your Philips portable DVD player and playback directly from USB or select your digital music or photos. Now you can share your favourite moments with family and friends.



Issue date 2009-01-22

Version: 2.1.7

12 NC: 8670 000 28755  
EAN: 87 12581 33870 1

© 2009 Koninklijke Philips Electronics N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

[www.philips.com](http://www.philips.com)