

Philips
5.1 Home theatre

420 W RMS power
DVD playback
HDMI 1080p

HTS3270



Spectacular surround sound with superb clarity

Just like in the movies

High-quality surround sound and HDMI 1080p upscaling delivered by this system provides superb home entertainment. Playback from USB drives, portable media players and just about any type of disc lets you enjoy movies and music effortlessly.

Bring audio and video to life

- DTS, Dolby Digital and Pro Logic II surround sound
- Advanced Class D Amplifier for compact, powerful sound
- HDMI 1080p upscales to high definition for sharper pictures

Connect and enjoy multiple sources

- Hi-Speed USB 2.0 Link plays video/music from USB flash drives
- Multiple digital inputs for quality sound from other sources

Easy to set up and use

- EasyLink to control all HDMI CEC devices via a single remote

Play all your movies and music

- DivX Ultra Certified for enhanced playback of DivX videos
- Plays WMV, DivX, WMA, MP3 and JPEG digital camera photos
- Plays CD, (S)VCD, DVD, DVD+R/RW, DVD-R/RW, DVD+R DL

PHILIPS

Highlights

DTS, DolbyDigital, ProLogic II

A built-in DTS and Dolby Digital decoder eliminates the need for an external decoder by processing all six channels of audio information to provide a surround sound experience and an astoundingly natural sense of ambience and dynamic realism. Dolby Pro Logic II provides five channels of surround processing from any stereo source.

Advanced Class D Amplifier

Advanced Class D Amplifier for compact, powerful sound

HDMI 1080p

HDMI 1080p upscaling delivers images that are crystal clear. Movies in standard definition can now be enjoyed in true high definition resolution - ensuring more details and more true-to-life pictures. Progressive Scan (represented by "p" in "1080p") eliminates the line structure prevalent on TV screens, again ensuring relentlessly sharp images. To top it off, HDMI makes a direct digital connection that can carry uncompressed digital HD video as well as digital multi-channel audio, without conversions to analogue - delivering perfect

picture and sound quality, completely free from noise.

Hi-Speed USB 2.0 Link

The Universal Serial Bus or USB is a protocol standard that is conveniently used to link PCs, peripherals and consumer electronic equipment. Hi-Speed USB devices have a data transfer rate of up to 480 Mbps - up from the 12 Mbps in original USB ones. With Hi-Speed USB 2.0 Link, all you have to do is plug in your USB device, select the movie, music or photo and play away.

EasyLink

EasyLink lets you control multiple devices with one remote. It uses HDMI CEC industry-standard protocol to share functionality between devices through the HDMI cable. With one touch of a button, you can operate all your connected HDMI CEC-enabled equipment simultaneously. Functions like standby and play can now be carried out with absolute ease.

DivX Ultra Certified

With DivX support, you can enjoy DivX encoded videos in the comfort of your living

room. The DivX media format is an MPEG4-based video compression technology that enables you to save large files such as movies, trailers and music videos on media, e.g. CD-R/RW and DVD recordable discs. DivX Ultra merges DivX playback with great features including integrated subtitles, multiple audio languages, multiple tracks and menus into one convenient file format.

Plays it all

Play virtually any media format you want - whether they are WMV, DivX, MP3s or JPEGs. Experience the unbeatable convenience of great playability and the luxury of sharing media files on your TV or home theatre system - in the comfort of your living room.

Plays it all

Play virtually any disc you want - whether they are CDs, (S)VCDs, DVDs, DVD+R, DVD-R, DVD+RW, DVD-RW or DVD+R DL. Experience unbeatable flexibility and the convenience of playing all your discs on the one device.



Specifications

Picture/Display

- D/A converter: 12bit, 108MHz
- Picture enhancement: Progressive scan, High Def (720p, 1080i, 1080p), Video Upscaling (720p, 1080i/p)

Sound

- Total Power (RMS): 420 W
- Output power (RMS): 4 x 55 W, 2 x 100 W
- D/A converter: 24-bit, 192 kHz
- Frequency response: 40-20,000 Hz
- Signal to noise ratio: > 60 dB
- Sound System: Dolby Digital, Dolby Prologic II, DTS, Stereo
- Equalizer settings: Action, Classic, Concert, Drama, Gaming, Lounge, Rock, Sports
- Sound Enhancement: Class "D" Digital Amplifier, Night Mode

Video Playback

- Compression formats: MPEG1, MPEG2, DivX 3.11, DivX 4.x, DivX 5.x, DivX 6.0, DivX Ultra, WMV, MPEG4
- Playback Media: DVD-Video, DVD+R/+RW, DVD-R/-RW, Video CD/SVCD, CD-R/CD-RW
- Video disc playback system: NTSC, PAL

Audio Playback

- Compression format: MP3, WMA
- Playback Media: DVD+R/+RW, DVD-R/-RW
- MP3 bit rates: 32-256 kbps and VBR

Still Picture Playback

- Picture Compression Format: JPEG
- Playback Media: DVD+R/+RW, DVD-R/-RW, CD-R/RW, USB flash drive
- Picture Enhancement: Rotate, Zoom, Slideshow with music playback

Tuner/Reception/Transmission

- Tuner Bands: FM
- RDS: Station Name

Connectivity

- Rear Connections: AUX in, FM Antenna, Scart,

- Easy-Fit Speaker Connectors, Composite video (CVBS) output, HDMI output, Digital coaxial in, Digital optical in
- Front/Side connections: Hi-Speed USB, MP3 Line-in

Power

- Power supply: 50 Hz, 230 V
- Standby power consumption: < 1 W
- Power consumption: 80 W

Loudspeakers

- Satellite speaker drivers: 3" full-range woofer
- Satellite speaker impedance: 8 ohm
- Satellite speaker freq range: 150-20,000 Hz
- Centre speaker drivers: 3" full-range woofer
- Centre speaker impedance: 4 ohm
- Centre freq range: 150-20,000 Hz
- Subwoofer driver: 6.5" high-efficiency woofer
- Subwoofer type: Passive
- Subwoofer impedance: 4 ohm
- Subwoofer freq range: 40-150 Hz

Accessories

- Included accessories: Remote Control, 2 x AAA Batteries, FM antenna, User Manual, Quick start guide, World Wide Warranty leaflet, Scart Cable

Dimensions

- Set dimensions (W x H x D): 360 x 57 x 331 mm
- Set weight: 2.87 kg
- Surround Speaker dimensions (W x H x D): 100 x 100 x 75 mm
- Surround Speaker Weight: 0.39 kg
- Center speaker dimensions (W x H x D): 100 x 100 x 75 mm
- Centre Speaker Weight: 0.66 kg
- Subwoofer dimensions (W x H x D): 123 x 310 x 369 mm
- Subwoofer Weight: 3.85 kg
- Packaging dimensions (W x H x D): 567 x 298 x 395 mm
- Weight incl. Packaging: 11.5 kg



Issue date 2017-04-10

Version: 4.1.12

12 NC: 8670 000 48772
EAN: 87 12581 45931 4

© 2017 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com