

Enjoy your favorite DVD movies on the go

Sit back, relax and immerse in movies on the go with the ultra cool and compact PET700 with 7-inch color LCD display. Enjoy your favorite DVD movies, savor your MP3-CD and CD music or playback your JPEG still images anytime, anyplace.

Immerse in AV entertainment on the go

- Plays DVD, DVD+R and DVD+RW discs
- Savor CD, MP3-CD, CD-R and CD-RW music
- Enjoy JPEG still image files playback with Picture CD

Comfortable viewing anytime, anyplace

- 7" TFT color LCD display
- Watch movies in 16:9 widescreen format

The ultimate in convenience

- Car adaptor and handy remote control
- Enjoy up to 3 hours playback time with rechargeable battery*
- Dual headphone jacks for simple AV sharing
- Travel bag included



PHILIPS

Technical specifications

Picture / Display

- LCD panel type: New Generation LCD panel (TFT active matrix, Anti-glare treatment, RGB vertical stripe)
- Panel size: 7"
- Effective viewing area: 154.1 x 86.6 mm
- Number of dots: 480 (w) x 234 (H) x 3 (RGB)
- Dot Pitch: 0.107 (w) x 0.370 (H) mm
- Brightness: 400
- Contrast Ratio: 250:1
- Response time: 30 ms

Sound

- Output power: 10 mW RMS (earphone)
250 mW RMS (built-in speakers)
- Signal to noise ratio: >80 dB (earphone)
>62 dB (built-in speaker)
- Volume control: Digital

Video Playback

- Disc playback media: DVD video, DVD+R, DVD+RW, VCD, SVCD, JPEG
- Disc Playback Modes (DVD): Multi-angle selection, Subtitle selection, Multi-language OSD
Aspect Ratio Conversion (Widescreen Movie Modes): 16:9, 4:3 letter box, 4:3 Pan Scan
Disc menu support
Parent control
Repeat track/disc/A-B
Zoom
- Video output signal: PAL/NTSC/Auto (TFT)
- Video DAC: 12 bit / 54 Mhz

Audio Playback

- Disc playback media: CD, CD-R, CD-RW, MP3-CD
- MP3 bitrates: 32-320 kbps
- Disc Playback Enhancement: Support ISO-9660 and Joliet format
Multi-Session
UDF
Variable bit rate per track
- Audio A/D converter: 192 kHz / 24 bit
- Digital Audio output: AC-3 / DTS Digital coaxial output

Electronic Skip Protection

- MP3-CD: 10 seconds
- Audio CD: 10 seconds
- VCD: 5 seconds
- DVD: 2 seconds

Connectivity

- Headphone: 3.5 mm x 2
- Line out (AV): 3.5 mm, Audio (L / R) / Video (composite) Output jack
- DC in: 9 v
- Digital Audio output: Coaxial

Accessories

- Rechargeable battery pack: DC 7.4 V, Lithium-ion rechargeable battery
- AC/DC adapter: 110-240 v, 50-60 hz
- Palm-sized Remote Control (Incl. battery)
- Car outlet adapter
- AV cable
- Printed user guide
- Travel Bag: 1 pc

Dimensions

- Master carton dimensions (WxHxD): 555 x 395 x 175 mm
- Master carton quantity: 2
- Packaging dimensions (WxHxD): 330 x 148 x 218 mm (with blister)
- Packaging type: D-box
- Product dimension (WxHxD): 190 x 29 x 146 mm
- Product weight: 750 g (excl. battery)

Power Supply

- Power requirement: 110-240 v, 50-60 hz
- Batteries: DC 7.4 V, Lithium-ion rechargeable battery
- Power consumption: 20 w
- Battery playing time: Up to 3 hours* (movie playback)
- Battery charging time: 3.5 hours

Product highlights

New generation LCD panel

New generation LCD Panel offers superior entertainment with a wider viewing angle, a faster response time and natural brilliant colours. Minimal 'colour shift' i.e. uniform natural colours when viewed from different angles.

Widescreen 16:9 display

The display has a widescreen (16:9) format, thus offering a wide screen picture, without black bars on the top and bottom of the picture, at maximum brightness of the picture.

Widescreen movie modes

Enhance your viewing experience with Widescreen Movie Modes, which lets you choose the screen format from various options. View your movie the way it is meant to be.

Dolby digital

Because Dolby Digital and DTS, the world's leading digital multi-channel audio standards, make use of the way the human ear naturally processes sound, you experience superb quality surround sound audio with realistic spatial cues.

* Battery life varies with use

