

Philips
Portable Speaker System



SBA2900



Powerful stereo sound stage

Powerful XSL Acoustics

The slim mono-body of the SBA2900 portable speaker system slips easily into your pocket or bag. Share the powerful and realistic stereo sound stage with friends wherever you are, and experience amazing rich bass quality even at low volume.

Powerful Sound

- Built-in speakers featuring XSL Acoustics for dynamic sound
- Dynamic Bass Boost electronically enhances the low tones
- Incredible Surround™ enhances the sound stage

Take your music with you

- Universal use with all portable entertainment equipment
- Ultra slim mono body fit easily into pockets and bags
- Carrying pouch to protect your speakers when not in use

Always ready to go

- Cable neatly stored when not in use

PHILIPS

Specifications

Sound

- Frequency response: 100 - 20 000 Hz
- Impedance: 3 ohm
- RMS Power rating: 2x3W (6W)
- Sensitivity: 80 dB
- Sound Enhancement: Dynamic Bass Boost, Incredible Surround
- Speaker diameter: 40 mm
- Type: Neodymium

Connectivity

- Cable length: 0.3 m
- Connector: 3.5 mm stereo
- Finishing of connector: Nickel plated

Convenience

- Bass level control
- Operating time: 6 hours
- Power on indication
- Volume control

Accessories

- AC/DC Adaptor
- Pouch

Power

- Adaptor type: 9V 500mA
- Battery type: AAA, LR03
- Battery voltage: 1.5 V
- Number of batteries: 6

Inner Carton

- Gross weight: 1.746 kg
- Inner carton (L x W x H): 22.4 x 17.8 x 20.6 cm
- Nett weight: 1.106 kg

- Tare weight: 0.64 kg
- Number of consumer packagings: 2
- Gross weight: 3.849 lb
- GTIN: 2 06 09585 16849 1
- Inner carton (L x W x H): 8.8 x 7.0 x 8.1 inch
- Nett weight: 2.438 lb
- Tare weight: 1.411 lb

Outer Carton

- Gross weight: 5.49 kg
- Outer carton (L x W x H): 56 x 25 x 23 cm
- Nett weight: 3.318 kg
- Tare weight: 2.172 kg
- Number of consumer packagings: 6
- Gross weight: 12.103 lb
- GTIN: 1 06 09585 16849 4
- Outer carton (L x W x H): 22.0 x 9.8 x 9.1 inch
- Nett weight: 7.315 lb
- Tare weight: 4.788 lb

Packaging dimensions

- Packaging dimensions (W x H x D): 22 x 21.5 x 8.6 cm
- Gross weight: 0.796 kg
- Nett weight: 0.553 kg
- Tare weight: 0.243 kg
- Number of products included: 1
- Packaging type: Carton
- Packaging dimensions (W x H x D): 8.7 x 8.5 x 3.4 inch
- Gross weight: 1.755 lb
- Nett weight: 1.219 lb
- Tare weight: 0.536 lb
- UPC: 6 09585 16849 7

Highlights

XSL Acoustics

Enjoy dynamic sound and powerful bass performance from your ShoqBox with XSL Acoustics. Impressive sound is produced by combining bright, brisk treble and mid range sound with elastic, powerful bass. Innovative use of high-tech materials like titanium cone and neodymium magnet deliver sound output that's nearly double the power of a traditional speaker driver of the same size. Precise tuning between the speaker driver, the small acoustic architecture and the circuitry ensures superbly dynamic sound and optimizes bass performance from the smallest sound enclosure.

DBB Dynamic Bass Boost

Activate the Dynamic Bass Boost (DBB), and the low-end bass frequencies are electronically enhanced to achieve consistent sound reproduction, especially when the speaker volume is set at a low level. You hear impressive bass at all times.

Incredible Surround™

Incredible Surround™ widens the sound stage, giving you the impression of having extra speakers all around you.

For portable equipment

Universal use with all portable entertainment equipment. Simply connect using the 3.5mm plug.

Ultra-compact and lightweight

Super slim and lightweight you'll hardly notice it's with you. Pop it in your pocket or bag and take it anywhere. Ultimate portability.

Carrying pouch

Look after your speaker and stop the cable getting tangled by storing it in this handy soft pouch when not in use.

Speaker cable management

With it's unique design, cable storage is no longer an issues. Simply pack and go.



Issue date 2013-05-13

Version: 1.2.3

12 NC: 8670 000 51541
UPC: 6 09585 16849 7

© 2013 Koninklijke Philips Electronics N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

www.philips.com