



In-ear true wireless headphones

- 6 mm drivers/closed-back
- Bluetooth®

TAT2205RD/00

Always ready to go

Is there anything more useful than true wireless headphones with a charging case that fits in the pocket of your slim-fit jeans? These splash- and sweat-resistant in-ear headphones give you great sound and up to 12 hours of play time.

Benefits

Extremely convenient, super-small charging case

- IPX4 splash- and sweat-resistant
- Super-small charging case for up to 12 hours of play time
- 4 hrs per charge. 15 min charge for 1 hr play time
- 6 mm neodymium drivers. Clear sound, punchy bass

Snug, lightweight design

- Secure, comfortable fit
- Soft ear-tip covers in small, medium and large

Easy pairing. Voice control.

- Earbud switches to control music and calls
- Easily wake your smartphone's voice assistant
- Smart pairing. Automatically find your Bluetooth device
- Switch from music to phone calls with built-in microphone

Features

IPX4

The small charging case couldn't be more convenient, and these true wireless headphones are also resistant to splashing from any direction. They won't mind a little sweat, and you don't need to worry about getting caught out in the rain.

Super-small charging case

Hit the road with multiple charges in your pocket. You get up to 4 hours of play time from a single charge, plus 8 extra hours from a fully charged case. A short 15 minute charge in the case gives you an hour of play time. A full charge of the case takes 2 hours via USB-C.

PHILIPS

Secure, comfortable fit

You get great sound from the 6 mm neodymium drivers and you can rock your tunes in real comfort thanks to the snug, lightweight design. Soft, interchangeable ear-tip covers help you find a comfortable in-ear fit.

Earbud switches

A button on each earbud makes it easy to control your listening. Skip or pause tracks, take or reject calls and more.

Voice assistant

Wake your phone's voice assistant without touching your phone. Ask smartphone's voice assistant to play music, get directions and check information and more.

Smart Bluetooth pairing.

These earphones are ready to pair the instant you take them out of their charging case. Once they're paired, the earphones remember the last device they were paired with.

Specifications

Please note that this is a pre-sales leaflet. The contents of this leaflet reflect the best of our knowledge per date and country mentioned above. The contents of this leaflet are subject to change without notice. Philips does not accept any liability as to the contents of this leaflet.

Connectivity

Microphone	Built-in microphone
Bluetooth profiles	A2DP HFP HSP AVRCP
Bluetooth version	5.1
Maximum range	Up to 10 m

GTIN	2 48 95229 10994 4
Height	10.4 cm
Length	18.7 cm
Net weight	0.096 kg
Number of consumer packages	3
Tare weight	0.404 kg
Width	12.8 cm

Design

Colour	Red
--------	-----

Accessories

Quick Start Guide	Yes
USB cable	USB (Type-A to Type-C) cable
Ear caps	3 Sizes

Outer Carton

Gross weight	4.25 kg
GTIN	1 48 95229 10994 7
Height	24.5 cm
Length	37.5 cm
Net weight	0.768 kg
Number of consumer packages	24
Tare weight	3.482 kg
Width	27.5 cm

Convenience

Call Management	Answer/End Call Reject Call Switch between 2 calls
-----------------	--

Packaging dimensions

Depth	4 cm
EAN	48 95229 10994 0
Gross weight	0.153 kg
Height	18 cm
Net weight	0.032 kg
Number of products included	1
Tare weight	0.121 kg
Width	9.5 cm

Power

Battery type	Lithium-ion
Music play time	4 + 8 hr
Standby time	50 hr
Talk time	3 hr
Rechargeable	Yes

Product dimensions

Depth	3.7 cm
Height	2.9 cm
Weight	0.032 kg
Width	5.5 cm

Sound

Acoustic system	Closed
Diaphragm	PET
Magnet type	NdFeB
Speaker diameter	6 mm
Frequency response	20 - 20,000 Hz
Impedance	16 Ohm
Sensitivity	90 dB

UPC

UPC	8 40063 20126 2
-----	-----------------

Inner Carton

Gross weight	0.5 kg
--------------	--------



data subject to change
2023, June 18

Version: 7.6.4
EAN: 4895229109940

© 2023 Koninklijke Philips N.V.
All rights reserved.

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

www.philips.com