

Philips  
CD Soundmachine with  
Dynamic Bass Boost



AZ2060

## Enriched Bass Sound

Uncomplicated yet comprehensive, you will appreciate the rugged AZ2060 with quality 2-way speakers for superb sound performance. Enjoy your favorite CD or 30 preset FM stations on the digital tuner in enriched sound - anytime, anywhere!

### **Bass sound experience**

- Dynamic Bass Boost for deep and dramatic sound
- Bass Reflex Speaker System delivers a powerful, deeper bass

### **Enjoy digital tuning**

- Digital tuning with preset stations for extra convenience
- Autostore Programming for one-touch radio tuning

### **Easy to use**

- CD Shuffle/Repeat for personalized music enjoyment
- Stereo headphone socket
- Line-in connection
- Handy remote control

**PHILIPS**

# Specifications

## Sound

- Loudspeaker Enhancement: Piezo
- Loudspeaker types: 2-way Bass Reflex Speaker
- Output power (RMS): 2X2W
- Sound Enhancement: Dynamic bass boost 2 steps
- Sound System: Stereo
- Speaker diameter: 4"
- Volume Control: Volume Control rotary/encoder

## Loudspeakers

- Built-in speakers: 2

## Audio Playback

- Cassette Deck Technology: Mechanical
- Playback Media: CD, CD-R, CD-RW
- Disc Playback Modes: Fast Forward/Backward, Next/Previous Track Search, Repeat Play, Shuffle Play
- Loader Type: Top
- Number of decks: 1
- Programmable Tracks: 20

## Tuner/Reception/Transmission

- Antenna: AM Antenna, FM Antenna
- Auto digital tuning
- Tuner Bands: FM, MW



## Connectivity

- Aux in: Line in
- Headphone: 3.5 mm

## Convenience

- Display Digits: 7
- Display Type: LCD

## Accessories

- Included accessories: AC Power Cord, User Manual, Warranty certificate

## Dimensions

- Packaging dimensions (W x H x D): 493 x 210 x 314 mm
- Product dimensions (W x H x D): 435 x 174 x 263 mm
- Weight: 3.3 kg
- Weight incl. Packaging: 4.4 kg

## Power

- Battery type: LR20
- Battery voltage: 1.5 V
- Mains power
- Number of batteries: 6

# Highlights

## Dynamic Bass Boost

Dynamic Bass Boost maximizes your music enjoyment by emphasizing the bass content of the music throughout the range of volume settings - from low to high - at the touch of a button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.

## Bass Reflex Speaker System

Bass Reflex Speaker System delivers a deep bass experience from a compact loudspeaker box system. It differs from a conventional loudspeaker box system in the addition of a bass pipe that is acoustically aligned to the woofer to optimize the low frequency roll-off of the system. The result is deeper controlled bass and lower distortion. The system works by resonating the air mass in the bass pipe to vibrate like a conventional woofer. Combined with the response of the woofer, the system extends the overall low frequency sounds to create a whole new dimension of deep bass.

## Digital tuning with presets

Simply tune into the station that you want to preset, press and hold the preset button to memorize the frequency. With preset radio stations that can be stored, you can quickly access your favorite radio station without having to manually tune the frequencies each time.

## Autostore programming

Autostore Programming is a convenient feature that allows you to tune in to your favorite stations and set station presets by simply pressing a button. Autostore Programming does away with the hassle of manual radio station tuning and setting of presets. A built-in electrical circuit automatically scans local radio station frequencies, locks on to the strongest radio station signals, and assigns them to specific presets.

## CD Shuffle/Repeat

The "Shuffle/Repeat" function helps you to get rid of the boredom of hearing your music played in the same order all the time. After loading your favorite songs to the player, all you have to do is to select one of the modes - "Shuffle" or "Repeat" for your tunes to be played in different modes order. Enjoy the different and unique music experience every time you hook up to your player.

## Stereo headphone socket

Connect your own headphone for a more personal listening experience whenever you want it. You can enjoy your favorite music in great sound without disturbing others by connecting your headphones to the player.

## Line-in connection

Line-in connection

## Handy remote control

Handy remote control



Issue date 2014-02-05

Version: 3.0.4

12 NC: 9073 101 01067  
EAN: 87 10895 80748 7

© 2014 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)